



ref#	item #	description
1	ER199	upper handle, chrome w/grip
2	ER198	cord spring
3	ER197A	cord hook set, complete, black
4	ER20	nut and bolt set, handle
5	ER200	lower handle, chrome
6	M1376	cord, 50', 18/3 SJT, beige
7	ER135	handle socket, chrome, w/o spring
8	ER325	motor screw
9	59.319	nut
11	ER205	shoulder screw
12	ER514	height adjustment knob assembly
13	ER826	hood and graphics assembly
14	P6	wire nut
16	ER305	motor mounting screw
18	ER885	switch button S649
19	ER884	switch clip
20	ER946	switch step-on, plastic
22	ER632	motor assembly
23	ER35	gasket, motor to main casting
26	ER2	handle release lever, foot pedal
27	ER127	bag adapter retainer spring
28	ER307	screw, rear axle
29	ER829	base assembly
30	ER3	handle release spring, foot pedal
32	ER332	front axle screw and clamp assembly
33	ER333	wheel cover, upright (2)
34	ER679	screw, hood

ref#	item #	description
37	ER353	front axle, upright
38	ER37	front wheel, upright
39	ER308	axle spring, upright
40	ER214	bottom plate assembly
41	ER133	gasket/base plate 38 1/4"
42	ER390	brushroll end cap cover w/holes rubber hex
43	10.089	brushroll
44	F631	belt, long life
45	27.073	rear axle
47	ER71	rear wheel
48	ER319	axle clip
49	ER331	strain relief bushing
50	ER886	bushing bracket motor gasket
56	ER442	carbon brush assembly
57	ER344	metal washer
57A	ER17A	fiber fan washer
59	ER17	lexan fan
60	ER202	pulley

**NOT ILLUSTRATED**

ER991 cloth bag w/ screw on connector, black

\*call for pricing and availability of all referenced parts