** USER'S MANUAL **

FCC ID: HQXPC97010-38

Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions. May cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Warning: A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.

Use only shielded cables to connect I/O devices to this equipment.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

To install the mouse, you need the following items ready for use.

Computer ----- Pentium compatible and higher.

Disk ----- A floppy disk or including a fixed disk.

Windows ----- Windows 95 (most OEM-B, all with OSR2.X) and Windows 98

Memory ----- 8M RAM or above.

USB port ----- For USB mouse use.

Monitor card ---- IBM Color Graphics Adapter, IBM Enhanced Graphics Adapter with Enhanced Color Monitor or other compatibles.

Installing a USB mouse driver under Windows 95

- a) Start Windows 95
- b) Connect USB mouse into USB port on PC.
- c) Add New Hardware Wizard dialog is appeared on the screen. Please press the "ENTER"key on keyboard or click "NEXT" button on screen if another mouse has already installed.
- d) Please put the USB mouse driver diskette into floppy driver A and press the "ENTER" or click "NEXT" button.
- e) "USB Mouse" message is appeared on the dialog. Pressing the "ENTER" or click "NEXT" button to complete the installation.

The mouse's ball, the rollers against which the ball presses, and the mouse housing will all become dirty with time. These parts should be cleaned regularly with a lintfree cloth.

- 1. Turn off the computer.
- 2. Turn the mouse upsidedown and remove the ball cover.
- 3. Remove the ball itself, and wipe off the ball, the rollers, and the housing with a cloth that has been wetted with water or a mild soap solution. You may wish to use a swab instead of a cloth to clean the rollers.
- 4. Replace the ball and the cover.

If the screen cursor doesn't move in response to the mouse, do the following

- * Check the communications interface. Do you have the mouse hooked to the right port(USB port)? Is the connection firm? You may want to tighten the connector.
- * Verify that you have loaded the mouse driver. Load the mouse driver by changing to the MOUSE directory.
- * Verify that the mouse is operating in the proper mode. There are application programs which require a particular operating mode.
- * Check the settings in a particular graphical user interface such as Windows to verify that they will allow the mouse to be used.