


## Quick Start



- Left soft key
- Messages key
- Call key: Call logs (idle screen); send call
- Right soft key
- Back/clear key
- End/power key: End call; Power on/off (long press); Return to idle screen
- Center soft key: Confirm an option (press the middle of the key); Navigation key

alcatel XXX™



## Find More Information

### Manage Your Account with myAT&T

- On your phone: **Apps** > myAT&T
- On the web: [att.com/myAT&T](http://att.com/myAT&T)



With myAT&T, you can:

- Add money to your account
- Track your usage
- Shop for equipment and accessories
- Suspend service if your phone is stolen
- and more

Compatible device and online account required.

Data and messaging rates may apply for download and app usage.

### Need More Help?

- On your phone: **Settings** > Help
- On the web: [att.com/DeviceHowTo](http://att.com/DeviceHowTo)



### Give us a call

- 800.901.9878
- 611 from any AT&T wireless phone

### Accessories

- [att.com/WirelessAccessories](http://att.com/WirelessAccessories)
- Visit your AT&T store

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. ALCATEL is a trademark of Alcatel-Lucent used under license by TCL Communication LTD. ONETOUCH and ALLURA are trademarks of TCL Communication LTD. © 2016 AT&T Intellectual Property. All right reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T.

Printed in China




XXXXXXXXXXXX

## Setting Up Your Phone

You'll need to set up your device before you can explore all its great features.

### Installing a SIM Card and microSD Card

- Remove the back cover via the notch at the bottom-left of the phone.
- Insert and click the battery into place, then close the phone cover. Unclip the cover, then remove the battery.
- To insert a SIM card, push the SIM into the card slot with the gold-colored contacts facing down.
- Insert the microSD card with the gold-colored contacts facing down.
- Replace the back cover.



## Bluetooth and Wi-Fi

Pair with other Bluetooth devices or connect to a Wi-Fi network.

### Connect to a Bluetooth Headset

- From the Home screen, press **OK** / **Settings** / **Network & Connectivity/Bluetooth**.
- Press **Bluetooth** and choose **On** or **Off**.
- Your phone will automatically search for device by pressing **Bluetooth/Devices in the Area**. Choose the name of the device to pair and connect with it.

### Connect to Wi-Fi Network

- From the Home screen, tap **OK** / **Settings** / **Network & Connectivity/Wi-Fi**.
- Choose **On** or **Off** to turn **Wi-Fi** on/off.
- Press **Available Networks** and choose a network name, enter a password if required and then press **↵** to connect.

## Network Indicator

To connect to the Internet with this phone, you can use 4G/4G LTE/GPRS/EDGE/3G networks or Wi-Fi, whichever is most convenient.

**4G LTE** 4G LTE<sup>1</sup>: Connected to the AT&T 4G LTE network.

**4G** 4G: Connected to the AT&T 4G network.

**G** GPRS: Connected to GPRS network.

**E** EDGE: Connected to the AT&T 4G LTE EDGE/2G network.

**H** HSPA: Connected to the AT&T HSPA network.

Actual data upload and download speeds depend on various factors, including the device, network utilization, fire characteristics, terrain, etc.

## Browsing the Web

Use the Browser to view web pages and search for information.

### Opening a Web Page

- From the Home screen press the **OK** key and select **Browser**.
- Press **↵** and enter the website you want to browser, and press **OK**.
- Press **↵** to open **Options** menu for further operation.

<sup>1</sup> 4G LTE is not available everywhere. LTE is a trademark of ETSI. LEARN more at [att.com/network](http://att.com/network).

## Contacts and Phone calls

Keep the contact information of your friends in **Contacts** and synchronize these with applications on the web or on your phone. Call friends and check voicemail in **Phone**.

### Consulting your contacts

You can access your call memory by pressing **↵** from the Home screen, or press the **OK** key and select the **☺** icon from the menu.

In this menu, you will see all call contacts.

### Add a Contact

- From the Home screen press the **OK** key and select **☺**.
- Press **↵** to add a new contact. Enter a name and details and press **↵** again to save.

### Delete a Contact

- Select the contact you want to delete and press **↵** to select **Options**.
- Select **Delete** to remove the contact.

### Make a Call

Dial the desired number, press the **↵** or **OK** key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the **↶** key. To hang up the call, press the **↵** key.

## Messages

Send text or multimedia message to communicate privately and quickly.

### Send a Text/Multimedia Message

- From the Home screen press the **OK** key and select **✉**.
- Press **↵** to write a new message.
- Enter the phone number of the recipient in the **To:** bar or press **↵** to add recipients. Press the **SMS** bar to enter the text of the message.
- Press **↵** to open **Options** menu, and then choose **Add Subject** or **Add Attachment** to create a multimedia message.
- Press **↵** to send the text or multimedia message.

### Delete a Message

- From the Home screen press the **OK** key and select **✉**.
- Press the message you want to delete.
- Press **↵** to open **Options** menu, and then choose **Select Messages** to choose the message you want to delete, press **↵** to delete. Press **Delete Thread** in **Options** menu to delete whole thread messages.

## Camera and Video

Take pictures and record videos right from your phone with the camera and camcorder and then share them with friends and family.

### Take a Picture

- From the Home screen press the **OK** key and select **📷**.
- Press **↵** to adjust your camera settings.
- Press **OK** to take a photo.

### Record a Video

- From the Home screen press the **OK** key and select **📹**, press **Right Navigation** key to enter camcorder.
- Press **OK** to start recording.
- Press **OK** again to stop recording.

### Share a Picture or Video

- From the Home screen press the **OK** key and select **📷**.
- Choose a photo or video, press **↵** to open **Options** menu. Press **Share** for sharing.