


FORMAT		74 X 105 MM
SIZE	EXPLODED	210 X 518 MM
	ROW / COLUMN	2 X 7



山折

谷折


山折

谷折

山折

谷折

山折



山折

谷折

山折

谷折

山折


谷折

山折

■ワイヤレススノーグロースピーカー取扱説明書

ワイヤレススノーグロースピーカーの操作方法と安全にお取り扱いいただくための注意事項を記載していますので、ご使用前に必ずお読みください。また読み終わった後も大切に保管しておいてください。

※この取扱説明書では一部の表記を除き、ワイヤレススノーグロースピーカーを「本製品」と表記しています。



ワイヤレススノーグロースピーカー 1個 micro USBケーブル 1本 取扱説明書(本書) 1部

■安全上のご注意

- 同梱の充電用ケーブルを使用して下さい。
- 分解・改造・修理をしないで下さい。火災・感電・故障などの原因となります。また故障時の保証対象外となります。
- 本製品の異常に気付いたら使用を中止下さい。
- 内蔵の充電電池より液漏れがみられる場合は使用を中止ください。
- 本製品が発熱している、煙が出ている、異臭がしているなどの異常がある場合は、すぐに使用を中止下さい。
- 本製品を落としたり、ぶついたりしないで下さい。万一、本製品が破損した場合は使用を中止し、本製品の電源をOFFにして下さい。その後買い上げの店舗までご連絡下さい。
- 本製品は防水仕様ではありませんので、水などの液体がかからない環境下で使用または保存して下さい。
- 本製品を廃棄するときは、お住まいの地域の条例及び法令に則り処分して下さい。
- 本製品が汚れたときは、乾いたやわらかい布などで拭き取って下さい。


対象年齢14歳以上 (乳幼児対象外商品)

▲注意

本製品を次のようなことに置かないでください。

- 日のあたる自動車内、直射日光のあたる場所
- 暖房器具の周辺など高温となる場所
- 多湿な場所、結露をおこす場所
- 平坦でない場所、振動が発生する場所
- マグネットの近くなどの磁場が発生する場所
- ほこりの多いところ

■各部の名称



■充電する/電源を入れる/ペアリングする

本製品を使用するには、接続機器がBluetoothに対応している必要があります。

1.充電する
初回使用時や長時間ご使用にならなかった場合は、必ず充電してからご使用ください。充電には付属のUSBケーブルを使用します。

2.電源を入れる
本製品を使用するときは、本体の電源を入れます。一度もペアリングしていない場合は、ペアリング待機状態になり状態表示ランプが青色で点滅します。以前にペアリングした機器の場合、電源キーを押し電源を入れると自動的に接続します。

3.Bluetoothでペアリングする
本製品と接続機器をBluetoothで接続するには、ペアリングをする必要があります。必要もペアリングしていない場合、ペアリングキーを押すと青ランプ早く点滅します。使用するデバイスでBluetoothを有効にして、Bluetoothデバイスを検索します。使用するデバイスで[imp_SNOWGLOBE]を選択して、ペアリングと接続を開始します。ペアリングと接続が正常に完了するとピー音が鳴り、ガラスドームがグラデーションもしくは白色に点灯します。

■Bluetooth®無線についてのご注意

1.本製品は2,400-2,483.5GHzを使用する無線設備です。移動体識別装置の帯域が回避可能です。電波方式はGFSK方式を採用し、干渉距離は約10mです。2.4GHz帯は、医療機器やIEEE802.11b/g/n規格の無線LAN機器などでも使用されています。

2.本製品を使用する前に、近くで他の無線局(※)が運営されていないか確認してください。万一、本製品と他の無線局(※)の間に電波干渉が発生した場合は、使用場所を変更するか、または本製品の使用を停止して下さい。

他の無線局(※)…本製品と同じ2.4GHz帯を使用する産業・科学・医療機器のほか、他の同種無線局、工場の生産ラインなどで使用される免許を要する移動体識別用校内無線局、免許を要しない特定小電力無線局、アマチュア無線局をさします。

▲警告

- 誤作動により重大な影響を及ぼす恐れのある機器では使用しないでください。まれに外部から同じ周波数の電波や携帯電話の電波の影響を受け、誤作動する、動作が低下する、または動作しなくなることがあります。
- 病院など、電波使用が禁止されている場所では本製品を使用しないでください。本製品の電波で電子機器や医療機器(例えばペースメーカー)などに影響を及ぼす恐れがあります。
- 航空機の安全運航に支障をきたすおそれがあるため、無線式キーボードを航空機内で使用することは、航空法で禁止されています。ご搭乗前に本製品の電源を切り、ご搭乗後は常にご使用しないようお願いいたします。

※本製品の故障等により事故や社会的な損害などが生じても、弊社ではいかなる責任も負いかねますので、ご了承ください。

■製品仕様

製品名	WIRELESS SNOWGLOBE SPEAKER
型番	IMP-201
対応機種	※動作確認機種はホームページをご覧ください。 www.imp.ne.jp
接続方法	Bluetooth 無線方式
適合規格	Bluetooth Version 2.1EDR
出力チャンネル数	79
周波数ホッピング	AFH
電波周波数	2,400-2,483.5GHz
電波方式	GFSK/n/4DQPSK/BDPSK
アンテナ利得	1.96 dBi
電波到達距離	10m
外形寸法	φ100mm×H144mm
重量	900g
動作温度	0℃～40℃(ただし結露なきこと)
保存温度	-5℃～60℃(ただし結露なきこと)
最大充電回数	約500回
充電時間	約3時間
動作時間	約2時間

■インジケータについて

USB充電時	
充電完了	ON OFF ペアリング時/正常動作時に準ずる 消灯
充電時	ON OFF ペアリング時/正常動作時に準ずる 赤点灯

非接続時	0.5秒 青点滅
ペアリング中	0.2秒 青点滅
接続完了	グラデーション点灯/白点灯

正常動作時	0.5秒 赤点滅
AUX接続時	グラデーション点灯/白点灯
Bluetooth未接続時	0.5秒 青点滅

■スノーグロブについてのご注意

▲警告

- 本品は火気の側に置いたり、車の中等直射日光の当たる場所や高温多湿の場所に放置されますと、中の水が蒸発する可能性があります。
- 高い所や不安定な場所では使用しないで下さい。転倒や落下の原因となり危険です。
- 割れ、ヒビが生じた場合はすぐに使用をお止め下さい。
- 中に入っている液体が目や口に入った場合は、すぐに水で洗い流し、かかりつけの医院にご相談ください。
- 時間が経つと水が減少したり、気泡が発生する場合があります。
- 本品はガラスで出来ており、重たく、割れやすい素材で出来ています。
- レンズ効果により火災の原因になるおそれがありますので、窓際や直射日光の当たる場所には置かないで下さい。
- 加熱により気泡が生じ、中の水がくもる事がありますので電気製品や熱源から離して下さい。
- 小さなお子様の手の届くところでの使用はお避けください。
- この商品の対象年齢は14歳以上です。それ未満のお子様には絶対に与えないで下さい。

保証規定
1.弊社が定める保証期間(本製品ご購入日から起算されます。)内に、適切な使用環境で発生した本製品の故障に限り無償で本製品を修理または交換いたします。

無償保証範囲

- 以下の場合には、保証対象外となります。
 - 保証書および故障した本製品をご提出いただけない場合。
 - 保証書に販売店ならびに購入年月日をご提示いただけない場合、またはご購入日が確認できる保証書(レシート、納品書など)をご提示いただけない場合。
 - 保証書に偽造・改変などが認められた場合。
 - 弊社および弊社が指定する機関以外の第三者ならびにお客様による改造、分解、修理により故障した場合。

- 弊社が定める機器以外に接続、または組み込んで使用し、故障または破損した場合。
- 通常一般家庭内で想定される使用環境の範囲を超える温度、湿度、振動等により故障した場合。
- 本製品をご購入いただいた後の輸送中に発生した衝撃、落下等により故障した場合。
- 地震、火災、落雷、風水害、その他の天災地災、公害、異常電圧などの外的要因により故障した場合。
- その他、無償修理または交換が認められない事由が発見された場合。

■修理

- 取扱説明書、本体貼付ラベルなどの注意書に従って正常な使用状態で故障した場合は、お買い上げ年月日より保証期間、無料修理いたします。
- 保証期間内に故障して無料修理を受ける場合には、お買い求めの販売店にご依頼の上、修理に際して本書をご提示ください。なお持込修理となっており、出張修理は行なっていません。
- 転居の場合は事前にお買い求めの販売店にご連絡ください。
- 保証期間内でも次の場合には有料修理になります。
 - 使用上の誤り及び不当な修理や改造による故障及び損害。
 - お買い上げ後の落下などによる故障・修理。
 - 地震・火災・落雷・水害・爆発・有毒ガス・落下などによる故障・損害。
 - 本書の提示がない場合。
 - 本書にお買い上げの年月日、お客様名、販売店名の記入のない場合、あるいは字句を書き替えられた場合。
 - 交換部品の取り替えを要する場合。

■免責事項

- 本製品の故障について、弊社に故意または重大な過失がある場合を除き、弊社の債務不履行および不正行為等損害賠償責任は、本製品購入代金を上限とさせていただきます。
- 本製品の故障に起因する派生的、付随的、間接的および精神的損害、免失利益、ならびにデータ損害の保証等につきましては、弊社は一切責任を負いかねます。


■有効範囲

- この保証書は、日本国内においてのみ有効です。
- 本保証書は再発行いたしませんので、大切に保管してください。

保証書	
お客様名	様
住所	
電話番号	()
型番	IMP-201
製品名	WIRELESS SNOWGLOBE SPEAKER ワイヤレススノーグロースピーカー
購入日	西暦 年 月 日 / 保証期間 本体6ヶ月間
販売元	

製造元・問い合わせ先
amadana お客様サポートセンター TEL: 0570-077-773
受付時間: 月～金(土、日、祝日を除く) 10:00～19:00

FORMAT		74 X 105 MM
SIZE	EXPLODED	210 X 518 MM
	ROW / COLUMN	2 X 7



谷折

山折

谷折

山折

谷折

山折




imp.

© &™ Lucasfilm Ltd.

■ WIRELESS SNOWGLOBE SPEAKER Manual Guide

Please read the instructions in this manual carefully. It will help you set up and operate the product properly. Please save this manual for future reference.

*WIRELESS SNOWGLOBE SPEAKER is referred to as "the product."



■ WARNING For your safety

- 1) Please use charging cable provided in the package.
- 2) Do not attempt to repair or disassemble the product. It can cause bodily harm, including fire and electric shock. Any sign of tampering of the product will void warranty.
- 3) Stop using the product and contact the manufacturer immediately if you observe battery leakage.
- 4) Please keep away from water and any liquid. This product is not water-proof.
- 5) Please keep away from high temperature, humidity and avoid direct sunlight.
- 6) Please keep product on flat surface and avoid placing it on moving objects.
- 7) This product is not a toy. Please keep product out of the reach of children. Recommended age is 14+.
- 8) Do not drop or bump the product with any objects. Glass may shatter upon impact.
- 9) Please dispose the product properly according to your local regulation on recycling of electronic products.


Please keep away from infants and baby.

Qualifying age over 14

▲ Warning
Please do not keep the product at: following.

- Inside on the car, hit by the sun lights directly.
- Anywhere gets high temperature. (ex: besides of heater)
- Anywhere high humidity, nor gets condensation.
- Anywhere not flat, nor steady surface.
- Anywhere around magnets or can be happen magnetic fields.
- Anywhere dusty

■ Identifying Parts



■ Recharge/Powering on/Pairing with audio device.

In order to use the product, your audio device must support bluetooth.

1. Charging the Product

Please use the supplied Micro USB cable to charge the battery. Please refer to LED indicator for charging status. Make sure to fully charge the battery before first use.

2. Powering on and off

Simply press the power button to turn on power. Press the power button again to turn off power.

3. Bluetooth Pairing

This product requires a Bluetooth connection. Connecting device must be Bluetooth-HID capable. Push the pairing button on back of the product. Blinking blue light indicates pairing mode. Search for "imp, SNOWGLOBE" in settings of your connecting device and tap on device name when found (for more information on how to access Bluetooth settings on your connecting device, please contact the manufacturer). Successful pairing is indicated by an audible beep.

■ Warning about Bluetooth® wireless connection

- 1) Bluetooth is a wireless equipment using the 2,400-2,4835GHz band throughout. Bandwidth of mobile identification device is possible to avoid. The radio system GFSK method is used, and the interfering distance is about 10m.
- 2) 2.4GHz band is used at many location, such as medical equipment and IEEE802.11b / 11g / 11n standard of wireless LAN equipment.
- 3) Before you use the product, please check whether other radio stations (※) has not been operated in the vicinity. Should the radio wave interference occurs between this product and other radio stations (※), you can either change the place of use, or stop the use of this product.

(※) ... other industrial, scientific and medical devices that use the same 2.4GHz band as this product, other similar radio stations, mobile identification for school it takes a license, such as those used in factory production lines radio stations, specified low-power radio stations do not require a license, we will refer to the amateur radio station

▲ Warning

- Do not use a huge impact of certain equipment taken up malfunction, Radio waves of the same frequency rarely receive a radio wave and effect the mobile phones, malfunctions, operation is reduced, or it may not operate.
- The location prohibited to use the product, such as hospital, please do not use the product. Electronics and medical radio waves of this product. There may affect in such equipment (ex, pacemakers).
- It may interfere with safe operation of the aircraft, the use of wireless keyboard in an airplane, is prohibited. Turn off the power of the product before boarding, after boarding will always not allowed to use.

※ If there is an accident and social damage due to failure of the product, you can not assume any responsibility at our company, please understand.

■ Product Specifications

Product name	WIRELESS SNOWGLOBE SPEAKER
Model No.	IMP-201
Compatible models	※Please refer to the website to see the Operation checked models. (www.imp.ne.jp)
Connection method	Bluetooth wireless system
Regulatory Compliance	Bluetooth Version 2.1+EDR
Channel	79
Frequency hopping	AFH
Radio frequency	2,400-2,4835GHz
Radio system	GFSK / n / 4DQPSK / 8DPSK
Antenna	1.36 dBi
Radio waves reaching distance	10m
External dimensions	φ100mm X H144mm
Weight	900g
Operating temperature	0°C -40°C
Storage temperature	-5°C -60°C
The maximum number of charges	About 500 times
Charging time	About 3 hours
Operation time	About 2 hours

■ About indicator

	During USB Charging
Recharge max	<p>Follow movement of While Pairing and While In Use</p> <p>Recharge light off</p>
Recharging	<p>Follow movement of While Pairing and While In Use</p> <p>Red lights</p>

	While Pairing
Not connected	<p>Blue light blinks in short intervals (0,5 sec)</p>
Pairing Mode	<p>Blue light blinks in shorter intervals (0,2 sec)</p>
Connected	<p>Gradient / White lights</p>

	While In Use
Low battery	<p>Red light blinks in short intervals (0,5 sec)</p>
AUX IN	<p>Gradient / White lights</p>
No Bluetooth Connection	<p>Blue light blinks in short intervals (0,5 sec)</p>

■ Snow globe instruction

▲ Warning

- Dome is made of glass, a fragile material filled with water! Stop using the product immediately if glass is cracked.
- Place the product on flat surfaces to avoid a fall and potentially shattering the glass.
- Keep away from heat source. Prolong exposure to heat may evaporate water, turn water murky and create bubbles.
- With any glass, it may cause a lens effect. Please avoid exposure to direct or indirect sunlight.
- As with any glass product, please keep away from children under 14 years of age.

■ Contact

amadana corp. Jinnan Bld. 5F 1-3-4 Jinnan Shibuya-ku Tokyo 150-0041 Japan
URL: http://www.imp
E-mail: support@imp.ne.jp
Local support E-mail: support@smoothy-us.com

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

FCC Radiation Exposure Statement:

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. To comply with FCC RF exposure compliance requirements, this grant is applicable to only Mobile Configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

山折

山折

谷折

山折

谷折

山折

谷折

山折