


1 Your mobile


Keys in idle mode



OT-V270A
ALCATEL
mobile phones


2 Getting started

2.1 Removing the battery cover



2.2 Inserting your SIM Card

To insert your SIM card, turn off your phone by holding down the key. Fit the SIM card with the chip (indicated by the gold connectors) facing downwards. Slide the SIM card into its compartment taking care of the correct orientation with the angled corner. Push the SIM card with your finger to release it.



2.3 Inserting and removing the battery

To insert the battery, place the top of the battery in first as shown and press down gently. To remove the battery, pull battery up from bottom using index finger.



2.4 Power charging

If the battery is completely empty, it may probably take 20 minutes before the charging indicator appears on the display or any calls can be made.

If the battery temperature is beyond the range about 0-45°C, the battery can't be charged; and if it's beyond the range about -20-60°C, the handset will power off automatically.

3 Menu.....

Select the menu of selection you would like by using the navigation keys (▲, ▼), then press the left softkey to confirm.

- Display:** Change the main screen wallpaper, colors/reverse, power on/off screen, screensaver and contrast.
- Call services:** Access functions such as: voicemail number, call memory, call settings, network, forward and call barring.
- Games:** Play the 2 games embedded in your telephone.
- Sounds:** Change the mode, volume, ringtones, alerts, power on/off sounds and key beep.
- Directory:** Access/create directory files and make calls from your directory.
- Messages:** Read, write and send SMS messages in your inbox or outbox. Adjust the settings and activate/deactivate SMS CB (M) message reception.
- Settings:** Set the time, date, language, security mode, answer mode, etc...
- Services (M):** Access operator services.
- Tools:** Access the Alarm and Calculator functions.

4 Main screen icons

- Battery charge level.**
- Vibrate mode**
- Silence mode**
- Unread message.**
- Message list is full**
- Voicemail message arrived.**
- Missed call**
- Call forwarding activated:** your calls are forwarded
- Alarm programmed**
- Home zone indicator.**
- Signal strength indicator.**

5 Tools

5.1 Alarm

When the phone is switched off, the alarm will ring.

5.2 Calculator

Access the Alarm and Calculator functions.

6 Calls

6.1 Making a call

Dial number then press . To hang up, press . If you make a mistake, press . Press and hold the key to delete all digits.

Making an emergency call

Dial 911 or other local emergency number and press . Emergency calls can be performed at anytime without your SIM card or PIN code. Once the call has been made, the screen will display: "SOS".

Making an international call

Hold down 0 when "+" is displayed, enter the country and area codes, then complete the number and send the call.

Calling a number from the directory

Press ▼ to access the directory.

Select the desired phone number and press .

6.2 Calling your voicemail (M)

Press and hold the 1 key until connected.

6.3 Available functions during the call

Access the available options during a call by pressing .

7 Messages

Press ▲ or press and select .

7.1 Create an SMS

and choose your action: **Send:** send the message to a recipient. **Send to many:** send the message to a group of people you have defined **Send to email:** send a message to an email address (M). **Save:** save the message in the unsent box and send it later. **Templates:** use or modify an existing message. **Discard:** discard the message. **Predictive (T9):** select this mode to enter the words more quickly. **I23:** switch to numeric mode **T9 help:** help menu for the predictive mode

7.2 Read an SMS

In the inbox, read and unread messages are shown with different icons. The outbox includes sent and unsent messages.

7.3 Inbox/Outbox

Select the message and press and choose your option: Reply/Delete/Forward message/Archives/Modify/Extract number/Call number.

8 Directory.....

You may store up to 250 entries in the phone memory.

8.1 Directory menu

View: access your stored contact list (alphabetic order). **Create:** enter number and name of a new contact. **Delete:** delete the selected contact. **Copy:** copy the selected contact from the SIM memory to the phone memory and vice versa. **Caller group:** group associated names by category. **Select Dir.:** select the SIM directory, Phone directory or both at the same time. **Memory status:** check the numbers of contacts and the memory space left. **My number:** enter your own phone numbers for future reference. **Speed Dial:** set up speed dial for each key from 2 to 9.

8.2 Creating a contact

select "create" and enter number and name of a new contact.

8.3 Viewing your saved directory contacts

Select "Dir." then "View" to access the list of your contacts **Available options in the contact list** Once you have selected a name, press to access the following options: Call number/Send message/Details/Modify/Delete/Copy/Caller group/Search number.

Caller group

You can group associated by groups and select a unique ringtone. For each group, you can select the following options: Modify/Ringtone/SMS alert/Members/Add member/Delete all.

9 Sounds.....

From the main screen, press and select one of the following options in order to customize your telephone.

9.1 Mode

Ringtone: only the tone is played. **Vibrate:** only vibrator is set (but the alarms and low battery sound will be played anyway). **Vibrate & ring:** vibrator and tone at the same time. **Vibrate then ring:** vibrator then tone. **Vibrate.Beep.Ring:** vibrator then warning beep, then tone. **Silence:** no sound no beep (but the alarms and low battery sound will be played anyway).

9.2 Volume

The volume can be adjusted to one of the set levels.

10 Display

10.1 Wall paper

Select the image you wish to be displayed as the idle screen.

10.2 Colors/Reverse

Choose different colors for the presentation of the screen.

10.3 Backlight

Select the display backlight duration : 7s, 15s, 20s, 30s.

11 Settings.....

11.1 Clock

Set time and date, time format, display (show or hide the clock).

11.1.1 Auto update/Nitz

Your phone will automatically adjust to the correct time zone when you travel to different time zones. **Note:** This option is on by default; you can access it and change it in "Settings/Clock/Auto update".

11.2 TTY/TTD

This handset is TTY Compatible. You only can enable TTY/TTD mode here after plug in TTY adapter of your phone.

11.3 Languages

Select your preferred phone's language.

11.4 Dictionary

Create, modify or delete a word in your personal dictionary. When creating an SMS, words typed are predicted from this dictionary and are automatically predicted in predictive mode (T9).

11.5 Auto power

11.6 Answer mode

11.7 Master reset/Master clear

All based configuration and settings will be back to their default values and all terminal based private user data will be purged.

The default code to use master reset/clear function is 00000. This code can be changed with user's new phone code.

If and only if a SIM/UICC is not present, when a user enters a specific code (*#1234#) via the keypad, the Master Clear function shall be invoked without user confirmation and without requiring the user to enter the terminal security code.

12 Call services

12.1 Call memory

From the main screen, press and your phone display a call list. Each call is displayed with an icon indicating the type of the call.

Select a phone number from the list and press to redial it or press to access the following options : **Details:** display the information of the call selected. **Save number:** store the number in your directory. **Send message:** create an SMS. **Call number:** call the selected number. **Modify:** modify the number, then call it or save it. **Delete:** delete the number selected. **Delete all:** delete the entire list.

12.2 Call settings (M)

Minute alert/Call waiting/Auto redial/Billing/Duration/Amount/Hide my ID.

12.3 Voicemail (M)


MWI – "Message Waiting Indicator". This icon will alert you when you have a new message in your voice mailbox. Make a long keypress on the 1 key to access your voice mailbox.

13 Games

13.1 Russia

The object of this game is to complete as many complete lines of bricks as possible.

Key functions:




13.2 Bricks

The object of this game is to break as many bricks as possible with a bat and ball.

3 lives per game. Miss a ball = lose a life

Bonus depending on the position in which the ball hits the bricks.

Key functions:



ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.

All rights reserved © Copyright 2008 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

Safety and use

We recommend that you read this chapter carefully before using your cellphone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained in this manual.

TRAFFIC SAFETY:

Recent studies show that using a cellphone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (headset,...), drivers are requested to refrain from using their cellphone when the vehicle is not parked. Check the laws and regulations on the use of wireless telephones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.

When switched on, your cellphone emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem:

- do not place your cellphone on top of the dashboard or within an airbag deployment area.
- check with your dealer or car manufacturer to make sure that the car's electronics devices are well shielded.

CONDITIONS OF USE:

You are advised to switch off your cellphone from time to time to optimize performance.

Switch the cellphone off before boarding aircraft.

Switch the cellphone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, cellphones can interfere with other electrical or electronic devices, or equipment using radio frequency.

Switch the cellphone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, gas station, or chemical plant, or in any potentially explosive atmosphere.

When the cellphone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump. When using the cellphone you should hold it against the ear on the opposite side to the device, if any. To avoid hearing impairment, press to answer the call before holding your cellphone to your ear. Also move the handset away from your ear while using the "hands-free" option because the amplified volume might cause hearing damage.

Do not let small children use the cellphone without supervision.

When replacing the cover please note that your cellphone may contain substances that could create an allergic reaction.

Always handle your cellphone with care and keep it in a clean and dust-free place. Do not allow your cellphone to be exposed to unfavorable environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc).

13

Telephone warranty

Congratulations on choosing this mobile phone - we hope that you will be completely satisfied with it.

Your phone is guaranteed against any deviation from technical specifications for a period of twelve (12) months from the date specified on your original invoice ⁽¹⁾. The warranty terms defined in the manual also apply to the battery and accessories sold with the phone but for a period of six (6) months ⁽²⁾ from the date of purchase shown on your original invoice.

Under the terms of this warranty, you must immediately inform your vendor (or any repair center approved by TCT Mobile Limited or its affiliates, which are listed on our website http://www.alcatel-mobilephones.com) in case of a conformity defect on your phone, you must present the invoice given to you at the time of purchase. The vendor or maintenance center will decide whether to replace or repair, as appropriate, all or any part of the telephone or accessory found to be defective; this warranty covers the cost of parts and labor but excludes any other costs. Repair or replacement may be carried out using reconditioned components offering equivalent functionality.

Service under the terms of this warranty, especially repair, modification or replacement of products, shall entitle to a ONE (1) month ⁽³⁾ warranty unless there are statutory provisions to the contrary.

This warranty shall not apply to damage or defects to your telephone and/or accessory caused by:

- 1) failure to follow the instructions for use or installation,
- 2) failure to comply with technical and safety standards applicable in the geographical area where the equipment is used.

The manufacturer's recommended operating temperature range is -20°C to +55°C. Over 55°C the legibility of the cellphone's display may be impaired, though this is temporary and not serious.

Emergency call numbers may not be reachable on all cellular networks. You should never rely only on your cellphone for emergency calls.

Do not open, dismantle or attempt to repair your cellphone yourself.

Do not drop, throw or try to bend your cellphone.

Do not paint it.

Use only Alcatel batteries, battery chargers, and accessories that are compatible with your cellphone model. TCT Mobile Limited or its affiliates disclaim any liability for damage caused by the use of non approved batteries or accessories.


Your cellphone should not be disposed of in a municipal dump. Please check local regulations for disposal of electronic products.

Remember to make back-up copies or keep a written record of all important information stored in your cellphone.

Some people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing videos games on your cellphone or enabling a flashing-lights feature on your cellphone. Parents should monitor their children's use of video games or other features that incorporate flashing lights on the cellphones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety precautions:

- Do not play or use a flashing-lights feature if you are tired or need sleep.
- Take a minimum of a 15 minute break hourly.
- Play in a well lit room.
- Play at the farthest distance possible from the screen.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.

When you play games on your cellphone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow the instructions to avoid problems such as tendonitis, carpal tunnel syndrome, or other musculoskeletal disorders.



This symbol found on your cellphone, battery and accessories means that these products must be taken to collection points at the end of their life:

- Municipal waste disposal centers with specific bins for these items of equipment
- Collection bins at points of sale.

14

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

In European Union countries:

These collection points are accessible free of charge. All products with this sign must be brought to these collection points.

In non European Union countries:

Items of equipment with this symbol are not to be thrown into ordinary bins if your country or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

In the United States you may learn more about CTIA's Recycling Program at www.recyclewirelessphones.com

PRIVACY:

Please note that you must respect the laws and regulations in force in your country regarding taking photographs and recording sounds with your cellphone. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and duplicate or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorization be obtained, if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller or vendor of your cellphone (including the operator) disclaim any liability which may result from the improper use of the cellphone.

BATTERY:

Before removing the battery from your cellphone, please make sure that the cellphone is switched off. Take precautions with the battery and do not attempt to open the battery (chemical substances may cause burns).

Do not pierce, disassemble nor cause a short-circuit in a battery. Do not burn or dispose of a used battery in household waste or store it at temperatures above 60 °C. Batteries must be disposed of in accordance with locally applicable environmental legislation.

Batteries should not be used for any other purpose than the one intended. Never use damaged batteries or not recommended by TCT Mobile Limited and/or its affiliates.

CHARGERS:


Home chargers will operate within the temperature range of 0 °C to 40 °C. The chargers designed for your mobile phone meet with the standard for safety of information technology equipment and office equipment use. They should be used for this purpose only.

The charger in this package shall ONLY be used with Alcatel OT-E270A. The use on any other product or equipment including Alcatel products is strictly prohibited. TCT Mobile Limited cannot be held liable for any damages due to use contrary to the above mentioned stipulation.


15

Troubleshooting.....

Before contacting the manufacturer or repair center, you are advised to follow the instructions below:

- You are advised to switch off the telephone from time to time to optimize its performance.
- You are advised to fully charge the battery () for optimal operation.
- Avoid storing large amounts of data in your telephone as this may affect the performance of your telephone.

My mobile phone does not switch on

- Press and hold  until the screen comes on
- Check the battery charge level
- Check the battery contacts, remove and reinstall your battery, then turn your telephone back on

My screen is difficult to read

- Clean your screen
- Use your mobile phone in accordance with the recommended conditions of use

My mobile phone turns off by itself

- Check that your keypad is locked when you are not using your mobile phone
- Check the battery charge level
- Check that the function "Auto OFF" is not activated.

General characteristic of power supply (depending on the country):

110V charger (Used in Mexico / USA):

Input: 100-240 VAC, 50/60 Hz, 100 mA

Output: 4.5 VDC, 300 mA

Battery: Lithium-ion 750 mAh

RADIO WAVES:

THIS CELLPHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your cellphone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio-frequency (RF) energy. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. These guidelines include a substantial safety margin designed to ensure the safety of all persons, regardless of age and health.

The exposure standard for cellphones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by public authorities such as the Federal Communications Commission of the US Government (FCC) or by Industry Canada, is 1.6 W/kg averaged over 1 gram of body tissue. Tests for SAR are conducted using standard operating positions with the cellphone transmitting at its highest certified power level in all tested frequency bands.

Although the SAR is determined at the highest certified power level, the actual SAR level of the cellphone while operating can be well below the maximum value. This is because the cellphone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the cellphone. Before a cellphone model is available for sale to the public, compliance with national regulations and standards must be shown.

The highest SAR value for this cellphone when tested is 0.96 W/kg for use at the ear and 0.43 W/kg for use close to the body.

While there may be differences between the SAR levels of various cellphones and at various positions, they all meet the government requirement for RF exposure. For body-worn operation, the cellphone meets FCC RF exposure guidelines provided that it is used with a non-metallic accessory with the handset at least 2 cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

The World Health Organization (WHO) considers that present scientific information does not indicate the need for any special precautions for use of cellphones. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep cellphones away from the head and body (fact sheet n°193). Additional WHO information about electromagnetic fields and public health are available on the following website: http://www.who.int/peh-emf.

16

My mobile phone does not charge properly

- Make sure that your battery is not completely discharged; the battery charge indicator can take several minutes and may be accompanied by a quiet hissing sound.
- Make sure charging is carried out under normal conditions (0°C +40°C)
- Make sure your battery is inserted. It must be inserted before plugging in the charger
- Make sure you are using an Alcatel battery and charger
- When abroad, check that the electrical current is compatible


My mobile phone does not connect to a network

- Try connecting in another location
- Verify the network coverage with your operator
- Check with your operator that your SIM card is valid
- Try selecting the available network(s) manually
- Try connecting at a later time if the network is overloaded

SIM card error

- Make sure the SIM card was correctly inserted
- Verify with your operator that your SIM card is 3V compatible; older 5V SIM cards are not compatible.
- Make sure the chip on your SIM card is not damaged or scratched

Unable to make outgoing calls

- Make sure you have dialed a valid number and pressed the  key
- For international calls, make sure you have entered the country and area codes
- Make sure your mobile phone is connected to a network, and that the network is not overloaded or unavailable
- Check your subscription with your operator (credit, SIM card valid, etc.)
- Make sure you have not barred outgoing calls

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not in-stalled and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference and,
- 2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Your telephone is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it.


General information

- **Website:** www.alcatel-mobilephones.com

- **Hot Line Number:** see the "TCT Mobile Services" leaflet or go to our Internet site.

On our Internet site, you will find our FAQ (Frequently Asked Questions) section. You can also contact us by e-mail to ask any questions you may have.

Your telephone is a transceiver that operates on GSM networks with 850 and 1900 MHz bands.

The  marking indicates that your telephone complies with "1999/5/EC (R&TE)" directive and that the accessories concerned comply with current EC directives. The entire copy of the Declaration of Conformity for your telephone can be obtained through our website: www.alcatel-mobilephones.com.

We, TCT Mobile,


Declared that the product is installed with battery separately in the box. The FCC ID label is placed on the mobile phone clearly visible to all persons at the time of purchase.

Protection against theft ⁽¹⁾

Your telephone is identified by an IMEI (phone serial number) shown on the packaging label and in the product's memory. We recommend that you note the number the first time you use your telephone by entering *,#, 0, 6, # and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen. This number allows your mobile telephone to be blocked preventing a third person from using it, even with a different SIM card.

Disclaimer

There may be certain differences between the user manual description and the phone's operation, depending on the software release of your telephone or specific operator services.



T9 Text Input is licensed under one or more of the following: U.S. Pat. Nos. 5,187,480, 5,818,437, 5,945,928, 5,953,541, 6,011,554, 6,286,064, 6,307,548, 6,307,549, and 6,636,162, 6,646,573; European Pat. Nos. 0 842 463 (96927260.8), 1 010 057 (98903671.0), 1 018 069 (98950708.2); and additional patents are pending worldwide

⁽¹⁾ Contact your network operator for service availability.

17

I am unable to create a file in my directory

- Make sure that your directory is not full; delete some files or save the files in the product directory

My callers are unable to leave messages on my voicemail

- Contact your network operator to check service availability

I can't access my voicemail

- Make sure your operator's voicemail number is correctly entered in "Call services/Voicemail"
- Try later if the network is busy


I am unable to send and receive messages

- Check your phone memory as it might be full, if necessary, delete some messages
- Contact your network operator to check service availability, see the messages settings
- Verify the server center number with your operator
- The server center may be busy, try again later

I have already entered 3 incorrect PIN codes

- Contact your network operator to obtain the PUK code (Personal Unblocking Key)

- Please pay attention to the microphone hole. Blocking it up with fingers will affect phone call quality.



⁽¹⁾ The mandatory period may vary if overriding statutory provisions are applicable in your country.

⁽²⁾ The life of a rechargeable Alcatel cellphone battery in terms of conversation time, standby time, and total service life, will depend on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your Alcatel phone during the first six months after purchase and for approximately 200 more recharges.

19

20

21

22

23

24