


1 Your cellphone.....



- 1 Left softkey
- 2 Pick up/Send call
- 3 Call memory
- 4 Voicemail
- 5 Right softkey
- 6 Switch on/Switch off
- 7 End call
- 8 Vibration alert
- 9 Navigation key (1) (2): Menu/Confirm an option (1) (2)
- 10 Directory ▲
- 11 Profiles ▼
- 12 Camera
- 13 Calendar
- 14 Lock/Unlock
- 15 Switch on/off LCD torch (long keypress)
- 16 Activate fake call (long keypress)

OT-305A
OT-508A
ALCATEL mobile phones

(1) Depending on your network operator.
(2) OT-305 only.
(3) Disabled when "Homescreen" is on.

- ### 1.1 Keys
- Navigation key (1) (2)
Confirm an option (press the middle of the key)
Access wallpaper settings (long keypress)
 - Pick up
Send a call
Access call memory (Redial) (short keypress)
 - Switch on/Switch off the telephone (long keypress)
End call
Return to the main screen
 - Left softkey
 - Right softkey
 - Access your voicemail (long keypress)
 - In Edit mode:
- Short keypress: access the language list
- Long keypress: enter zero
 - In Edit mode:
- Short keypress: change input methods
- Long keypress: access the Symbols table
 - From main screen
- Short keypress: #
- Long keypress: activate/deactivate the vibrator
In Edit mode:
- Short keypress: (space)
- Long keypress: add a word
 - Camera key (3) : access "Camera" (short keypress)
 - Music key (3) : access "Music player" (short keypress)

(1) Depending on your network operator.
(2) OT-305 only.
(3) OT-505 only.

- ### 1.2 Main screen icons
- Battery charge level.**
 - Vibration alert:** your phone vibrates, but neither rings nor beeps except for the alarms.
 - Bluetooth is active (1).
 - Headset connected.**
 - Call forwarding activated:** your calls are forwarded.
 - Alarm clock programmed.**
 - Voicemail message arrived.**
 - FM radio is on.**
 - Missed calls.**
 - WAP alerts (2).**
 - Roaming.**
 - Line switching (3):** indicates the selected line.
 - GPRS active connection status (Blue - Activated).**
Shown only in no ciphering mode while calling, sending/receiving SMS.
 - Level of network reception.**
 - Reception of a message in progress.**
 - Sending a message.**
 - Silence mode:** your phone neither rings, beeps nor vibrates except for the alarms.
 - Message unread.**
 - Message list is full:** your terminal cannot accept any new messages. You must access the message list and delete at least one message on your SIM card.
 - SIM card unavailable.**
 - Memory card scanning in progress.**
 - Memory card scanning completed.**
 - Flight mode.**

(1) OT-505/OT-508 only. (2) Depending on your network operator. (3)

2 Getting started

- ### 2.1 Set-up
- Removing and installing the back cover**
 - Installing and removing the battery**
 - Inserting and removing the SIM Card**
- ### 2.2 Power on your phone
- Hold down the key until the phone powers on.
- ### 2.3 Power off your phone
- Hold down the key from the main screen.

3 Calls

- ### 3.1 Making a call
- Dial the desired number then press the key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the right softkey.
- To hang up the call, press the key.
- Making an emergency call**
- If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.
- ### 3.2 Calling your voicemail (1)
- To access your voicemail, hold down the key.
- ### 3.3 Receiving a call
- When you receive an incoming call, press the key to talk and then hang up using the key.
- ### 3.4 Available functions during the call
- During a call, you can use your directory, your diary, short messages, etc. without losing your correspondent by pressing the key.

(1) Contact your network operator to check service availability.

4 Call register

- ### 4.1 Call memory
- You can access your call memory by pressing the key from the main screen.
- ### 4.2 Billing
- You can access different items with this option: Amount, Duration, GPRS counter, Beep duration.
- ### 4.3 Call settings
- You can access a number of items with this option: Call waiting, Call forwarding, Call barring, Caller ID, Line switching, Auto redial.

5 Directory.....

- ### 5.1 Consulting your directory
- To access the **directory** from the main screen, press the key and select the icon from the menu.
- ### 5.2 Add contact
- Select the directory in which you wish to add contact, press the "Options" softkey, select "Add contact" then .

6 Messages

- ### 6.1 Create message
- From the main menu select "Messages" to create text/multimedia message. You can type a message and you can also modify a predefined message in **Templates** or customize your message by adding pictures, photos, sounds, titles, etc (only available while editing a MMS). While writing a message, select "Options" to access all the messaging options. You can save your messages that you send often to **Drafts** or **Templates** (MMS only).

7 Settings

- ### 7.1 Home screen
- From home screen, you can quickly access the features that you use the most.
- When activated, press keys to scroll up/down application shortcuts one by one, and press keys to access a list of available actions of the selected applications. To close the list, press key.
- This feature is activated by default. To exit this function, you can set it off from "Settings\Home screen\OFF".

8 Tools

- ### 8.1 Bluetooth™ (1)
- Access this feature by selecting "Bluetooth" from the main menu.

(1) OT-505/OT-508 only.

8.2 Calendar

Once you enter this menu from "Tools", there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked in color.

8.3 Alarm

Your cellphone has a built-in alarm clock with a snooze feature.

8.4 Calculator

Hold down the # key to get the decimal point. Confirm with the key or the left softkey.

8.5 Converter

Unit converter and Currency converter.

8.6 Voice memo

This feature enables you to record a call by selecting "Voice memo" while communicating. To record a sound, select "Voice memo", then "New record".

8.7 Memory card

8.8 Fake call

This program enables you to call yourself by simulating a caller number/name, ringtone, contact photo at a scheduled time. It helps you to politely escape from social situations at any time you wish. This call can be rejected by key.

- Settings**
- Predefined settings of Caller name/number, Call time, Ringtone, Image (Contact photo).
- Activate**
- Activate a fake call by "Settings\Call register\Fake call\Activate" or by a long press of the # key on the main screen. The call will then be made at the predetermined time.

8.9 Memory status

It will indicate how much space is used and how much is currently free on your phone.

8.10 My shortcuts

Access the shortcuts already programmed. To programme new shortcuts: select "My shortcuts" if you want to create a quick access to a function, Directory, or WAP Bookmarks, etc.

9 WAP

Access Wap options: Homepage, Bookmarks, Recent pages, Offline pages, Go to URL and Profiles.

10 File manager

You will have an access to all audio and visual files stored in phone in File manager.

10.1 My audios

Choose an audio for an incoming call, a message alert, power on/off ringtone or an alarm and scheduler.

10.2 My images

You can select an image or a photo as wallpaper or the ON/OFF screen.

10.3 My creations

This feature stores all the photos captured by your cellphone.

10.4 Unknown files

Store files of unsupported format.

10.5 Formats and compatibility

- Sounds: midi, amr, MP3, ...
- Images: jpg, gif

11 Music player

Access this feature from the main menu by selecting "Music player" or directly by pressing the Side key.

12 FUN

12.1 Games

Your Alcatel phone may include some games.

12.2 FM radio

Your phone is equipped with an FM radio (1) with RDS functionality. You can use the application as a traditional FM radio with automatic tuning and saved channels or with parallel visual information related to the radio program on the display, if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.

(1) The quality of the radio depends on the coverage of the radio station in that particular area.

13 Camera

- Your cellphone is fitted with a camera for taking photos that you can use in different ways:
- store them in your "File manager".
 - send them in a multimedia message (MMS) to a cellphone or an email address.
 - customize your main screen.
 - select them as incoming call image to a contact in your directory.

14 Profiles.....

With this menu, you may personalize ringtones for different events and environments.

15 Latin input mode

- To write messages, there are two writing methods:
- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key.
 - Predictive with the Zi mode: this mode speeds up the writing of your text.
 - + key in edit mode
Short keypress: access the language list
Long keypress: enter zero

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.

All rights reserved © Copyright 2010 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

