


Quick Start Guide

For more information about how to use the phone, please go to www.alcatelontouch.com to download complete user manual (English version only). Also on our website you can find helpful FAQs (English version only).

1 Your mobile.....



1.1 Keys

- Menu key
 - Options menu
- Home key
 - Return to the Home screen
- Back key
 - Return to previous menu
- Power key
 - Lock the screen (press)
 - Turn your screen on/off (press)
 - Power on/off (press and hold)
 - Mute an incoming call

1.2 Main screen icons ⁽¹⁾

- Battery charge level
- Vibrate alert: your phone vibrates, but does not ring or beep.
- Bluetooth status (Activated).
- Headset connected.
- Screen locked.
- Call forwarding activated: your calls are forwarded.
- Alarm or appointments programed.
- Level of network reception.
- Voicemail message arrived.
- Missed calls.

⁽¹⁾ The icons and illustrations in this guide are provided for information purposes only.


- Radio is on.
- Wap alerts ⁽¹⁾.
- Roaming.
- SIM card missing.
- GPRS connection status (Activated).
- GPRS connecting.
- Sending a MMS.
- MMS receiving.
- Silence mode: your phone does not ring, beep or vibrate with the exception of the alarm.
- SMS unread.
- MMS unread.
- Flight mode.
- microSD card inserted.

⁽¹⁾ Depending on your network operator.


2 Getting started

2.1 Set-up


Removing and installing the back cover



Removing and installing the battery




Inserting and removing the SIM card



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press it and slide it out.

Charging the battery ⁽¹⁾



Connect the battery charger to your phone and outlet respectively.

- The charging may take about 20 minutes to start if the battery is flat.
- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger.
- The outlet must be near to the phone and easily accessible (avoid electric extension cables).
- When using your telephone for the first time, charge the battery fully (approximately 3 hours). You are advised to fully charge the battery ().
- To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; switch off Bluetooth when not in use, etc.

The charge is complete when the animation stops.

2.2 Power on your phone

Hold down the key until the phone powers on.

2.3 Power off your phone

Hold down the key until the phone powers off.

⁽¹⁾ Depending on your country.

PROTECT YOUR HEARING
To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

9 Fake call.....

Protect yourself from annoying situations with the "Fake call". In this menu, you can choose "Set caller name", "Set active time", "Ringtone" etc.

10 Camera.....

Your mobile phone is fitted with a camera for taking photos and shooting videos that you can use in different ways:

- store them in your "My files\My images".
- send them directly by MMS or Bluetooth.
- customize your main screen.
- select them as incoming call image to a contact in your directory.

11 SyncML.....

SyncML could launch synchronization with the account you've set.

12 Images.....

A library links to the images in "My images" in phone to be shown in list, slide, set as Wallpaper, Power on/off display, and contact image or sent by MMS, Bluetooth.

13 Music.....

Access this feature from the main menu by selecting "Music". You will have full flexibility of managing music both on your mobile and memory card.

14 Video.....

"My videos" album contains video clips recorded, received or downloaded.

15 FM radio.....

Your phone is equipped with a radio ⁽¹⁾ with RDS ⁽²⁾ functionality. You can use the application as a traditional radio with saved channels or with parallel visual information related to the radio program on the display if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.

16 Recorder.....

Accessing "Recorder" from the main menu allows you to make voice or sound recordings.

⁽¹⁾ The quality of the radio depends on the coverage of the radio station in that particular area.
⁽²⁾ Depending on your network operator and market.

17 Settings.....

From the main menu, select the menu icon and select the function of your choice in order to customize your telephone: **Phone settings, Call settings, Call filter, Network, Connectivity, Security and Restore default.**

18 Call log.....

You may access this function from the main menu "Call log".

- Missed calls/ Rejected calls
- Outgoing calls (Redial)
- Answered calls

19 Calendar.....

Once you enter this menu from the main menu, there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked.

Voice alarm
You can record a reminder using your voice at the date/time you choose!

20 Tasks.....

Enables you to easily manage and track the progress of a task with priorities. All the tasks will be sorted by due date.

21 Notes.....

You can create a note in text format by accessing "Notes" from the main menu.

22 Calculator.....

Enter a number, select the type of operation to be performed, and enter the second number, then press "=" to display the result.

23 My files.....

You will have access to all audio and visual files stored in phone or memory card in My files. You can access a number of items with this option: **Phone, SD card and Memory status.**

Installing and removing the memory card:



To release the microSD card holder, slide it in the direction of the arrow and lift it. Then insert the microSD card with the golden contact downward. Finally, turn down the microSD holder and slide it in the opposite direction to lock it.

24 Converter.....

You can use the Weight and Length conversion by selecting the unit you wish to convert via , then touch to input the digits. Finally confirm with "OK".

25 Stopwatch.....

The stopwatch is a simple application for measuring time with the possibility to register several results and suspend/resume measurement.

26 Ebook.....

A bookshelf contains the electronic books (.txt file only). While reading the book, you may add bookmarks, or reach the text by searching words, phrases.

27 Alarm.....

Your mobile phone has a built-in alarm clock with a snooze feature.

28 World clock.....

The World clock shows current local time and the time zone in different cities.

2.4 Using the touchscreen

- Touch** To access an application, touch it with your finger.
- Drag** Place your finger on the screen to drag the object to the destination.
- Scroll** Slide the screen to scroll up and down the applications, images, web pages... at your convenience.

3 Making a call.....

Touch on the tool bar to place a call. If you make a mistake, you can delete the incorrect digits by pressing .

To hang up the call, press the key.

29 Wap ⁽¹⁾.....

Access Wap options: **Homepage, Bookmarks, Recent pages, Go to URL, Settings** etc.

30 Bluetooth™.....

Access this feature by pressing to enter the main menu, then selecting "Bluetooth".

31 Services.....

Contact your network operator to check service availability.

32 Profiles.....

With this menu, you may personalize ringtones for different events and environments.

⁽¹⁾ You can stop loading webpage by touching .

4 Contacts.....

4.1 Consulting your Contacts

To access the Contacts, touch from tool bar to enter the main menu, and select "Contacts" or touch from tool bar.

4.2 Adding a contact

You can add a new contact by touching .

5 Messaging.....

5.1 Create message

From the main menu select "Messaging" or touch from tool bar to create text/multimedia message. You can type a message and you can also modify a predefined message or customize your message by adding pictures, photos, sounds, titles, etc (only available while editing a MMS). You can view your messages with chat mode in chronological order.

Specific letters (accent) will increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

⁽¹⁾ Depending on your network operator.

⁽¹⁾ You need to download the application to your phone for the first time. Some data charges may apply during the downloading.

⁽²⁾ 3042G only

6 Apps ⁽¹⁾.....

Apps is an online software store, where you can download and install applications and games to your phone. All downloaded files can be found in "Apps Mgr" that can be accessed from main menu.

7 Wi-Fi.....

To access this function, tap to enter the main menu, and select .

8 Facebook.....

Facebook is a social utility that connects people with friends and others who work, study and live around them. It provides a number of features with which users interact, such as VWall, etc. To open an account online, please go to: <http://m.facebook.com>

⁽¹⁾ Depending on your network operator.

37 Making the most of your mobile.....

PC suite

You can download software upgrade for free from the website. The PC suite includes:

- Backup/restore

You can backup the important data in your mobile and restore them when needed.

- GPRS modem

Use your mobile phone to connect PC to the internet.

- Multimedia Personalization

Customize your mobile with images, animations and melodies.

- Messages

You can compose SMS/MMS easily on your PC and transfer them to your phone.

Supported Operating Systems
Windows XP/Vista/Windows 7.

ONE TOUCH Upgrade

Using ONE TOUCH Upgrade tool you can update your phone's software from your PC.

Download ONE TOUCH Upgrade from ALCATEL website (www.alcatelontouch.com) and install it on your PC. Launch the tool and update your phone by following the step by step instructions (refer to the User Guide provided together with the tool).

Your phone's software will now have the latest software.

