

# RtR A1

# High Performance Bluetooth Speaker

# 1.Accessory



# 2.Illustration



- 1 Volume +/Next Track
- ② Play/Pause/Answer or Reject Phone callo
- ③ Volume -/Previous Track
- Sound effect/mode switching
- ⑤ Power ON/OFF/TW
- 6 AUX In
- ⑦ Charging Port
- ® Micro SD Port

# 3.Parameter

Wireless Version	V5.3 v	
Receiving Range	s30M(Open Field)	
Rated Power	50W (RMS)	
Battery Capacity	Built-in 2500 mAh	
Power Supply	Micro DC 5V/2.1A	
Frequency Response	80 Hz-18KHz	
Charging Port	Tepy-C USB	
Driver Unit	50W x 2	
Playing Time	UP to 12 hours	
Charging Time	2.5 hours	
Waterproof	IPX6	

#### 4. Function Key

Key	Operation	Function
ტ	ON/OFF/TWS	Short press to turm on.     After power ON the speaker quick press 2 times will shift to TWS mode.     Long press for 3 seconds to turn off
<b>&gt;</b>	Play/Pause	1. Press once when music is playing/pause, answer incoming call or hand up a phone call 2. Press and hold for 2 seconds to reject the incoming call. 3. Hold for 3 seconds to disconnect Wireless. 4. In the mobile phone bluetooth has been connected state: quick double click. back to dial the last phone call.
_	Volume -/ Previous Track	Press once to decrease to volume.     Hold for 2 seconds to previous track.
+	Volume +/Next Track	Press once to increase to volume.     Hold for 2 seconds to next track.
М	Sound effect/ mode switching	Play mode switching: Bluetooth, Aux-in , MicroSD card     EQ switching: Heavy bass, Pop & Vocal     Long press for 5 seconds to reset

### 5. Wireless Pairing:

1. Power on speaker the blue LED will blinks, go to wireless setting on your device, find A1 and select to pair.

#### 6.Micro SD Mode:

- 1. Max support reading 64GB Micro SD catd.
- 2. Insert any Micro SD card, the speaker will playing the audio files in the Micro SD card automatically.
- 3. If the wireless of the mobile phone has been connected to the " A1 " speaker box, press the "on/off" button to switch TF card to play.

#### What is TWS?

TWS means "True Wireless Stereo". The technology enables two wireless speakers to be paired and to perform stereo music.

#### How to pair your device?

- 1. Turn on both A1 speakers (if any of the two A1 is connected, disconnect the speakers first from the Bluetooth device, ex:
- your phone).

  2. Quickly double-click the "Power" button on one of the A1. A voice prompt will indicate it has entered pairing mode.

  3. When pairing is successful, a voice promptwill be played.

  4. Turn on the Bluetooth function on your device (for exmaple: your phone). It will search for and find a Bluetooth device

- Turn on the Bluetooth function on your device (for extriagre, your priorie), it will search for all the bluetooth turned on the same of the bluetooth function of your device (for extriagre, your priorie), it will search for all the bluetooth of the search of the bluetooth of the bl

## Friendly Reminder:

Due to the powerful output of this speaker, do not listen too close to the speaker. Please maintain an appropriate distance while listening! To avoid discomfort from excessive volume, please use an appropriate volume level when enjoying your favorite music!

#### FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarant ee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environm ent. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

#### RF exposure warning:

This equipment complies with radiation exposure limits set forth for an uncontrolled envir onment. This equipment should be installed and operated with Minimum distance 20cm b etween the radiator and your body.

L'environnement du millipascal incontrôlés, leurs conditions normales d'utilisation de mai ntenir, aumoins 20cm avec les utilisateurs.