

User Manual

Mobile Phone
FCCID: 2ADYY-H7

TECNO MOBILE LIMITED

ROOMS 05-15, 13A/F., SOUTH TOWER, WORLD
FINANCE CENTRE, HARBOUR CITY,
17 CANTON ROAD, TSIM SHA TSUI,
KOWLOON, HONG KONG

Please read these instructions for use and have a good look at the illustration before using.



Warning :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Information:

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device Types Mobile Phone (FCC ID: 2ADYY-H7) has also been tested against this SAR limit.

This device was tested for typical body worn operations with the back of the handset kept 10mm from the body.

To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Note: The SAR values meet the limit of FCC.

Please refer to the FCC database([https://apps.fcc.gov/oetcf/eas/reports/Generic Search.cfm](https://apps.fcc.gov/oetcf/eas/reports/GenericSearch.cfm)) to search for FCC ID: 2ADYY-H7 to get detailed information about RF Exposure(SAR).

Note:

the FCC ID lable inside the battery compartment, than the device must be marketed without battery inserted.

TECNO mobile


1 Box

In the box has a mobile phone, charger, USB line, Headset, instructions for use and etc.




TECNO mobile

2 Know your phone



3 Insert SIM card & Memory card

1. Switch off the phone and remove the rear cover and battery.
2. Insert the SIM card(s) & Memory card correctly in the card slot(s).



3. Finally insert the rear cover of the phone.
-
-

4 Main screen

Main screen can be placed on the most commonly used applications, you can also display daily information such as the time, the weather (need third-party applications), date, etc.




5 Make Calls

Enter dial interface and enter a complete phone number to make a call.



6 Notification


Notification icons inform you of new messages and events. When you receive a notification, its icon appears in the status bar, along with a summary that appears only briefly.




7 Messages

You can use Messaging to exchange text and multimedia messages with your friends.

**Touch to open
a messaging
conversation**



**Touch to compose
a new text or
multimedia
message.**




**Search SMS
messages.**

8 Camera

Your camera pictures and videos can be stored in SD card, so you must insert one to use the Camera. You can copy pictures and videos from the SD card to a PC and vice versa.

**Front Camera
and Back
Camera switch**




**Touch to
change settings**

**Touch to take
picture/ video.**

9 Gallery


You use Gallery to view pictures that you've taken with Camera, downloaded, or copied onto your SD card or USB storage; you can also view pictures in a Picasa web album. You can perform basic editing tasks on pictures and set them as your wallpaper or contact picture. You can also share your pictures with friends, via email or messaging, or by uploading them to the Picasa and YouTube web sites

**Single image
preview**




10 Wi-Fi

To browse the web, you need switch on Data connection. If there is Wi-Fi around, you can switch on Wi-Fi to use it browse the web. Some may need password.



11 Music

When you copy music to your SD card, the Music player searches the card for music files and builds a catalog of your music, based on information about each file that is stored in the file itself.



12 Taking Care of Your Device

Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:

- Keep the device dry. Precipitation, humidity, and all types of liquid or moisture can contain minerals that will rust electronic circuits. If your device gets wet, remove the battery and refrain from turning on the device, wipe it with dry cloth and take it to the service center.
 - Do not store the device in high or cold temperature. High temperature can shorten the life of electronic devices and damage batteries.
 - Do not use or store the device in dusty or dirty areas. Its moving parts and electronic components may be damaged.
 - Do not attempt to open the device other than as instructed in this guide. Repairing of phone by yourself and others than our authorized service agent/center is against the warranty rules.
 - Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
 - Do not use harsh chemicals, cleaning solvents, or strong
-
-

TECNO mobile

detergents to clean the device. Use a soft, clean and dry cloth to clean the surface of the device.

Battery& Chargers Safety:

- Do not place the battery in fire; follow local laws and ordinances in disposing used battery.
- Check the model number of the charger before using it to charge the mobile.
- Only use **original** battery, charger and accessories applicable to the specific mobile model. Using other types of battery, charger and accessories may violate the certification or warranty terms of the equipment and may result in danger.
- Return waste and used batteries to the supplier or specified recovery site.

CAUTION!

- There are risks of explosion if battery is replaced by a non-original one.
- Dispose of used batteries according to the instructions.

***Note:** The socket-outlet shall be installed near the equipment and shall be easily accessible.
