bluetooth speaker, G-sound 15084BT



INSTRUCTION MANUAL PLEASE READ ALL INSTRUCTIONS CAREFULLY & RETAIN FOR FUTURE USE

Getting Started

Remove the unit from the box. Remove any packaging from the product. Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents


MINI Bluetooth BRICK Speaker USB charging cable 3.5mm Aux cable Instruction manual

Features

 Water Resistant Speaker
Wireless Bluetooth connectivity to iPad, iPod Touch, Android, Windows Phone, Blackberry, smartphones, tablets, computers and more.
Stream Music/Audio wirelessly
Built-in Mic for hands-free calling
Rechargeable built-in battery

Specifications

Bluetooth Version:2.1+EDR Wireless distance: 26 to 33 feet Speaker :3Watts Power input :DC 5V Built -In Rechargeable Li-ion battery Play time : up to 1 hours Charging time: up to 3 hours



- 1.Mic -Built in microphone for hands free conversation.
- 2.Carabiner-secure, hang the speaker anywhere you like.
- 3.Multi- function button(MFB)- answer call/ hang up/ redial /power ON or OFF button.
- 4.AUX-input port -play music through AUX.
- 5.LED light- charge indicator.
- 6.Micro USB charging Port -charge the speaker
- 7.LED light -operation indicator.

Instructions for use BT mode

1.Turn on the speaker ,a deep sound and flashing blue LED light indicate that you're in Bluetooth Pairing mode .

2.Once you have activated Bluetooth on your mobile phone /tablet etc,select the device " 17-B68" from the list of available Bluetooth devices. 3.Once paired successfully, the LED light flashes slowly 4.Choose music from your Bluetooth device and play music wireless through the speaker.

Talking using the Bluetooth speaker

Please ensure that you are paired with the Bluetooth speaker to use the below functions.

1. Answer incoming call- press the MFB once to answer an incoming call

2.Reject incoming call -long press the MFB button 3.End call- after your phone conversation ,shot press the MFB button.

4.Redial last number- short press the MFB button twice. Note :MFB stands for multi-functional button.

Listening to Music Wirelessly

Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired with the Bluetooth Speaker to stream music wirelessly. Once it is paired, play music from your device.

1.Pause—A short press on the MFB button will pause the music 2.Play— A short press on the MFB button will resume the music

Play music using "Aux-In"

1.Press and hold the MFB button (Power) for 2-3 seconds until

you hear the indication tone.

2.Insert the 3.5 mm Aux in cable (included) in the Aux-in jack of the speaker. And, the other end of the cable, to the audio device (such as computer / tablet etc.).

3.The Blue LED will stay on.

4.Select your favorite song at the source device.

(Note: When you insert 3.5 mm Aux in cable into the Aux-in jack of the speaker, the Bluetooth of the speaker will Turn Off, automatically. Functions except Volume Increase or Volume Decrease can be only controlled through source devices, while playing music in Auxiliary mode. An indication tone will alert you when the volume is adjusted to the maximum level.)

Charging the speaker

This speaker has built in rechargeable battery, When the battery in drained out , device would turn off automatically . You would have to recharge the battery.

Plug the micro USB end of the included USB cable into the charging port. Plug the other end into a USB port on your computer or other devices suitable for USB charging .The red LED light illuminates indicating that the device is being charged.

It takes up to 3 hours to fully charge the device. Once the device is fully charged , LED light would turn OFF

Care and Maintenance

Clean the unit with a soft, damp cloth. Never use chemicals or hard abrasives.

Keep this unit away from wet or damp surroundings.

The crossed out wheelie bin symbol on this item indicates that this product needs to be disposed of in an environmentally friendly way when it becomes of no further use or has worn out. Contact your local authorities for details of where to take the item for re-cycling.

Note: iPod and iPhone are trademarks of Apple Inc, registered in the US, and other countries.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.