

SOUNDLOGIC™ | XT

**521075BT
Bluetooth Speaker**



INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE USE

Getting started

- Remove the Ornament Speaker & accessories from the box.
- Remove all packaging from the Ball Speaker.
- Place the packaging inside the box to either store or dispose of safely.

In the Box

- Bluetooth Ornament Speaker
- Hanging Ribbon
- Hanging Hook
- USB Charging Cable
- Instruction Manual


Features

- Handsome glitter finish that blends perfectly with your other ornaments
- Streams wireless music from up to 30 feet away
- Rich, crisp sound. Perfect for your favorite holiday tunes!
- Works with all Bluetooth-enabled devices: smart phones, tablets and more
- Rechargeable batteries built-in (Charging cable included)

Safety Instructions

- Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not use the unit with wet hands.
- Do not put objects into any of the openings.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach of children.
- This product is not a toy.

Description of Parts



1	Hanging Ribbon
2	Speaker
3	USB Charging Port
4	ON/OFF Switch
5	Hanging Hook
6	LED Indicator
7	Bluetooth Antenna (Do not fold or cut)

Important: Bluetooth Antenna is an extremely important component to stream wireless music. Any damage to it will deteriorate streaming & sound quality, significantly.

INSTRUCTIONS FOR USE

Charging Instructions

- The speaker is built in with rechargeable battery. Please charge the battery fully, before its first use.
- Insert the USB end of the charging cable (included) to a computer USB port or USB wall charger, and the Micro USB end to the charging port located on the back of the speaker.
- LED light turns red while the speaker is being charged. It takes around 2 hours for the speaker to charge fully. When the battery is fully charged the red LED light turns off. When the battery is low, please recharge the speaker.

Turning On/Off the speaker

There is an on/off switch at the back of the speaker. You can turn the speaker on/off by pressing this switch. In order to save power, turn the speaker off, when not in use.

Playing Music from your Bluetooth Devices:

- Turn on the speaker.
- Place the speaker and Bluetooth device (phone or music device) not more than 3 feet apart from each other.
- Activate the Bluetooth function on your Bluetooth device (phone or music device). Please refer to the manufacturer's instructions for instructions on enabling Bluetooth on your device.
- Once you have activated Bluetooth on your device, select the speaker "SL Holiday Tunes" from the list of available Bluetooth devices.
- If required, enter the password '0000' to confirm pairing.
- Once paired successfully, blue LED flashes every second.
- You can play music from your paired device (phone or music device) through the speaker.
- If pairing is unsuccessful, turn off the speaker and then re-pair following the above steps.
- Once speaker has been paired with your mobile phone etc, it will automatically pair with it, the next time your device is in proximity with the speaker. Hence above steps are likely to be followed only while pairing with a device for the first time.

Function Summary

Listening to Music

- Once the speaker is paired with your device you can stream music wirelessly through the speaker.
- Select the track you wish to listen to and it will be streamed to your Bluetooth speaker.
- Adjust the sound volume from your device.
- Should you encounter any problems while streaming please refer your device's user manual for further information.

LED indicator

Please refer to the below tables for a list of the LED statuses whilst using the speaker.

Battery Charging Indication

LED indicator	Status of the speaker
Red LED	Charging
Red LED turns off	Charging Completed

LED Indication

LED indicator	Status of the speakers
Blue LED flashes rapidly	Pairing mode On (searching for Bluetooth device)
Blue LED flashes every one second	Paired successfully

Specifications

Bluetooth specification	Bluetooth V2.1
Operating distance	33 Feet, Class II
Speaker	3W
Speaker output	2.5W
Working time	Up to 1.5 hour
Charging input voltage	DC 5V
Charging time	About 2 hours
Dimensions	2.76" x 2.76" x 3.19"
Weight	2.8 Oz

Note: Battery life & charging time may vary based on individual handling & other conditions.

Troubleshooting

Problem	Possible Cause	Solution
Low sound level	Source (Tablet, Mobile Phone, Laptop, etc.) volume too low. Battery dead	Adjust source volume. Charge speaker battery.
Sound distorted	Battery nearly dead	Charge speaker battery
No sound	Source (Tablet, Mobile Phone, and Laptop.) turned off. Speaker turned off. Media paused on source.	Turn the source on. Turn the speaker on. Play media from source.
Unable to Pair	Bluetooth Disconnected	Turn OFF and then turn ON the Speaker; after about 30 seconds. Keep your Bluetooth Speaker and Bluetooth enabled device within 3 feet of each other during the pairing process. After a successful pairing, the Blue LED indicator light will flash every one second.

Care and Maintenance

Read the following recommendations before using the speaker. Following these you will be able to enjoy the product for many years.

- Do not expose the speaker to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Don't use abrasive cleaning solvents to clean the speaker.
- Do not expose the speaker to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't dispose of the speaker in a fire as it will result in an explosion.
- Don't expose the speaker to contact with sharp objects as this will cause scratches and damage.

- Don't let the speaker fall on the floor. The internal circuit might get damaged.
- Don't attempt to disassemble the speaker as it may get damaged if you are not professional.

In case the speaker doesn't function properly, send it to the store you bought it. The staff will help you to the problem.

FCC statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate this equipment. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device is measured RF output power is less than the SAR exclusion threshold value for human head and body . Therefore, SAR test is not necessary.