BLUETOOTH SPEAKER 8B020BT



Operation Manual

Thank you for purchasing the Bluetooth headsets, please read all instructions carefully before using and retain this manual for future use and reference.

PACKAGE CONTENTS

- Sport Armband USB Charging Cable

CHARGING YOUR HEADSET

- Plug the micro-USB Charging cable into your headsets.
- 2. Plug the USB port on a computer or power adapter
- 3. Charge for 2-3 hours or until the red charging indicator light shuts
- 4. Unplug your headsets, It is now ready for use.

CAUTION

When not in use for a prolonged period, It is recommended that you turn off the headset to lengthen battery life.

Bluetooth Version: V2.1+FDR Bluetooth version. V2:112BN Bluetooth profiles supported:HSP,HFP,A2DP Operation range:up to 10 meters Battery:3.7V/150mAh Charging time:about 2-3 hours

Playing time:up to 4 hours Talk time:up to 3 hours

Volume Up:Short press"+" Volume Down: Short press"-"

Previous Track:Long press"+" Next Track:Long press"-"

Weight:27.5a

USING YOUR BLUETOOTH HEADSET



2.Play/Pause/Power Switch 3 Volume up&Next sona

5.USB Charging Socket

Press and hold the "I◄ "button for 3 seconds until the blue and red light turn on at the same time

Turn off headset:

Press and hold the " ■ "button for 3 seconds. The red light will flash 3 times, then the device will shut off.

Paring: Ensure Bluetooth is enabled on your mobile device or tablet. Make sure your device and your headset are no more than 3ft apart during this pairing process. Press and hold the "III" "button for 6 seconds. The blue and red light will flash alternately. Se-

- lect"11-B20A"from the list of available Bluetooth devices to pair. Answer a call:
- Press the" II◄ "button quickly to answer an incoming call.

- Press and hold the" I "button to reject a call. Play/Pause music
- Press the" II◀ "button to play/pause music Volume Control
- Short press the Volume up or down button to adjust the volume
- Previous or Next sona
- Long press the the Previous or Next song button to select your optimal performance when music playing.

Sport Armband



Strap your phone to your armband and pop on the comfortable headset&enjoy wireless music on the go. Fits most of your Android or Apple smartphone up to 5 inches screen size.

Warning
This device complies with Part 15 of the FCC Rules. Operation is subject to the followin two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a class digital device, pursuant to Part 15 of the FCC Rolles. These limits are designed to provi reasonable protection against harmful interference in a residential installation. This equipment experientes, uses and can radiate radio frequency energy and, if not installe and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quanartee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the
- Consult the dealer or an experienced radio/TV technician for help

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Auriculares Bluetooth& MuñegueraDeportiva A11-B20A-7&A11-B20A-1



Manual de operación

Gracias por la compra de losauricularesBluetooth. Lea todas las instruccionescuidadosamente antes de usar y conservareste manual para usofuturo y de referencia.

Contenido del paquete

- Auriculares Bluetooth
 Muñequeradeportiva
- · El cable de carga USB

CARGA DE LOS AURICULARES.

- 1. Enchufe el cable de carga micro-USB ensusauriculares.
- Conecte el puerto USB de un ordenador o adaptador de corriente.
- 3. Cargapor 2-3 horas o hasta que el indicadorluminosorojo de carga se apaga.
- Desconectesusauriculares, ahoraestálisto para usar

 Cuando no se utilicedurante un períodoprolongado, se recomiendaapagar el auricular para alargar la vidaútil de la batería

La Especificación

Batería: 3.7V/100mAh.

Versión Bluetooth: V2.1 EDR. Perfiles Bluetooth compatibles: HSP, HFP, A2DP. Rango de funcionamiento: Hasta 10 metros

Tiempo de carga: aproximadamente 2-3 horas.

Tiempo de juego: hasta 4 horas. Tiempo de conversación: hasta 3 horas.

Volumenarriba:pulsacióncorta"+".

Bajarvolumen: la pulsacióncorta"-".

Pista anterior:pulsaciónLarga"+ ". Siguientepista:pulsaciónLarga"-".

Usando el auricular Bluetooth



1.El volumenabajo&canción anterior. 2.Play/Pause/interruptor de alimentació 3.Sube Volume & la próximacanción. 4.La luz indicadora LED. 5.Toma de carga USB.

Pulse y mantengapulsado el botón " ■ " durante 3 segundos hasta que la luz roja y azul se activan al mismotiempo Apagar el auricular:

Pulse y mantengapulsado el botón " ■ " durante 3 segundos la luz ojaparpadeará 3 veces, luego el dispositivo se apagará Empareiamiento:

Asegúrese de que Bluetooth estáactivadoensudispositivomóvil o tablet. Asegúrese de que el dispositivo y losauriculares no son más que 3 pies apartedurante este proceso de emparejamiento. Presione y mantengapresionado el botón " II⊲ " durante 6 segundos.El azul y la luz rojaparpadearáalternativamente.Seleccione"11-B20A"de la lista de dispositivos Bluetooth disponibles para emparejar.

Contestarunallamada: Pulse el botón″ II◀ "rápidamente para responder a

Rechazarunallamada: Pulse y mantengapulsado el " ■ "botón para rechazarunallamada. Reproducir/Pausa musical:

Pulse el botón" II "play/pausa musical

· Control de volumen

pulse brevemente el botón de volumenhaciaarriba o haciaabajo para ajustar el volumen.

Canción anterior o siguiente

Mantengapulsado el botón de la canción anterior o siguiente para seleccionar el óptimorendimientocuando reproduce música.

Muñequeradeportiva



Correa del teléfono a subrazalete y pop enloscómodosauriculares&disfrutar de músicainalámbricaenlosdesplazamientos. Se adapta a la mayoría de su smartphone Android o Apple hasta 5 pulgadas de tamaño de pantalla.