

102.50 mm

410.00 mm

Tenda


Install Guide

Please visit [www.tendacorp.com](http://www.tendacorp.com) for more detailed setup of the router.



1 Connect Your Router

Your WAN medium from ISP may be A or B as below.

A. Telephone Line/FTTH/Fiber To The Home/Cable Access



Or B. Ethernet Access



Attach the Removable Stand



- 1. Antennas direction tip: For best wireless signal, orient the three antennas as shown on the figure.
2. No cable setup: Use your mobile to connect to the SSID of the router (Appendix 1 Join in Your WiFi).
3. DO NOT remove the USB drive when it is working to avoid data missing or other damages.

2 Configure Your Router


Step 1 Access the wireless router




Step 2 Access the Internet



Step 3 DHCP



Step 4 Wireless Setting



Step 5 (For more functions)



Appendix 1 Join in Your WiFi

Windows 7




MAC



Tenda

Install Guide

iPhone/iPad




Windows 8




Appendix 2 Configure Your PC

Windows 7



MAC



FAQs

- Q1: Where should I place my wireless router for optimum performance?
A1: To ensure optimum performance, please refer to the following points.
a. Place it around the central area which your laptops, mobile phones and other devices are used.
b. It is not an ideal location for the router to be placed in a room with a lot of furniture, especially in a room with a lot of furniture, as this may block the signal.
c. Avoid placing the router in a room with a lot of furniture, as this may block the signal.
d. Avoid placing the router in a room with a lot of furniture, as this may block the signal.
e. Avoid placing the router in a room with a lot of furniture, as this may block the signal.

Table with 3 columns: LED Indicator, Status, Description. Rows include Power, Internet, 2.4GHz, 5GHz, WPS, USB, LAN 2, LAN 3.

CE

CE Mark Warning: Operations in the 5.15-5.25GHz band are restricted to indoor use only. This is a Class B product. In a domestic environment, the product may cause radio interference, in which case the user may be required to take adequate measures.

FC

FC Statement: This device is restricted to be used in the indoor. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Shenzhen Tenda Technology Co., Ltd. 6A Floor, Tower E3 No. 1001, Zhongguo Sheji Yuan Road, Nanshan District, Shenzhen, China 518002