


Release the tractor locking levers by pulling them up. Once the right forms tractor is positioned, lock it by pushing down its locking lever.



Raise the tractor doors and fit the first two paper feed holes onto the right tractor pins.

