

# C800 series Smart Projector



Please read the instructions carefully before using this product,  
and properly kept for future reference.

# WARNING

1. Use this unit only for its intended use as described in this manual.
2. Unplug this unit during lightning storms or when unused for long periods of time.
3. The unit should be situated away from direct sunlight or heat sources such as radiators, electric heaters, heat registers, stoves, or other units (including amplifiers) that produce heat. Avoid placing on top of stereo equipment that radiates heat.
4. Never block the air openings of the unit with materials such as plastic bags, clothing or papers, or place it on a soft surface such as a bed or a couch, where the air openings may be blocked. Doing so may result in overheating and damage to the unit.
5. Do not overload electrical outlet. Use only the power source as indicated.
6. Never operate this unit if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water. If the unit's power supply cord or plug is damaged, do not attempt to fix it yourself.
7. To avoid the risk of electric shock, do not disassemble or attempt to repair the unit. Incorrect repair can cause risk of electric shock or injury to persons when unit is used.
8. Keep product out of reach of children.
9. Never dispose of the product in fire or water, which may result in explosion and / or injury.
10. Don't block the air inlet so as not to cause overheating of the machine

# IN THE BOX



Projector



Remote



Tripod




Quick  
user manual




Adapter


# PRODUCT OVERVIEW



# DEVICE CONNECTION



# REMOTE ILLUSTRATION




Mouse (optional) helps control the smart projector conveniently.


1. Click the Left button to enter the menu.
2. Click the Right button to close the window.

## Entering Text

You can enter text using the on-screen keyboard, which provides a layout similar to a desktop computer keyboard. Some apps open it automatically. In others, open it by entering where you want to type.



# POWERING ON/OFF



## 1. Connect to power:

Plug the DC adapter into the projector's DC IN (5V) power outlet.

We present you a USB-4.1mm portable source charging cable to make you can use portable source to power supply. Remember the portable source must be 5V-2A output above.

## 2. Turn On/Turn Off:

Press and hold Power button on your projector for 3 seconds to turn it on.

Press the power button on the projector long, turn off the device after 1 seconds, or press the power button on the remote controller for 1 seconds to turn off the device.

When the machine is not able to enter the desktop, you can use a needle to stab the reset hole.

## 3. Battery:

For safety reasons, the projector has a built-in lithium battery that can not be power on by remote control.

Built in battery life is generally about two hours.

When the battery is low, the brightness drops automatically.

## Access USB SD card operation

- 1.This machine has only one USB 2 interface because of the size limit.If you need to expand, you can extend the USB using HUB.
- 2.The built-in resource management software, when inserted into the external device, you can go to the explorer, open the U disk, or SD card content to play.
- 3.Mx player is a shortcut to open the TF card content, the system will default to read U disk inside the video file, click, can directly play.Maximum support for 1080P decoding.
- 4.When you need to use Office, you can select the document that needs to be opened through the built-in WPS office application and operate by remote control or mouse.

## charge

- 1.Shutdown, the red panel flashing when charged, yellow when full, about 4 hours full.
- 2.When in use, it can be played while charging and has no influence on the equipment.
- 3.In play, the current is limited on the basis of security considerations. At this point, use when charging,It takes about 8 hours to fill.



# PROJECTION / SOURCE



## Projecting from a USB flash drive/microSD card

You can project from a USB flash drive/microSD card if you have one installed.

- 1, Turn on the projector.
- 2, Enter Home Screen > Source > USB/SD.
- 3, Open the file you want to project.

# BROWSER

Use Browser or Google Chrome to view web pages and search for information.

Browser: Home Screen > Browser

Chrome: Home Screen > Apps > Chrome



View videos and share your own with your friends, family and the world with YouTube.

YouTube: Home Screen > Apps > YouTube

The screenshot shows the YouTube Home interface. At the top is a red navigation bar with the word 'Home' on the left and icons for Home, Trending, and Profile on the right. Below the bar is a section titled 'Popular Videos - Movies & Frozen' by #Movies. This section contains five video thumbnails with their titles, channel names, and view counts. Below this is a 'Recommended channel' section for AdeleVEVO, featuring six video thumbnails with their titles and view counts.

**Home**

**Popular Videos - Movies & Frozen**  
by #Movies

- 9 INAPPROPRIATE JOKES in Kid Movies**  
Just A Boy  
2 months ago · 631K views
- Play Doh Cinderella Movies Barbie Princess Power...**  
FunToyzCollector  
4 months ago · 1M views
- 5 Moments in Disney Movies That Ruined Our Lives**  
CleverTV  
1 year ago · 259K views
- 10 Movie Mistakes That Slipped Through Editing**  
Screen Rant  
6 months ago · 24M views
- Ten Hidden Details in Disney Movies**  
Blanch Lafferty  
4 months ago · 26K views

**AdeleVEVO**  
Recommended channel

- Adele - Hello**  
AdeleVEVO  
2 months ago · 954M views
- Adele - Skyfall (Lyric Video)**  
AdeleVEVO  
3 years ago · 174M views
- Adele - Rolling in the Deep**  
AdeleVEVO  
5 years ago · 813M views
- Adele - When We Were Young (Live at The Church...)**  
AdeleVEVO  
1 month ago · 63M views
- Adele - Set Fire To The Rain (Live at The Royal Albert...)**  
AdeleVEVO  
4 years ago · 208M views

# PLAY STORE

Play Store gives you access to thousands of free and paid apps, games, and music or TV programs.

Play Store: Home Screen > Apps > Play Store

The screenshot shows the 'TOP FREE' section of the Google Play Store. At the top, there are navigation tabs: CATEGORIES, HOME, TOP FREE (selected), TOP NEW FREE, and TRENDING. Below the tabs is a grid of 10 app cards, each with an icon, title, developer, and rating. The apps are:

Rank	App Name	Developer	Price
1.	360 Security - Antivirus Boost	360 Mobile Security Limited	FREE
2.	Toy Truck Rally 3D	3dinteger	FREE
3.	SWAT Sniper Anti-terrorist	ReadUpdates	FREE
4.	Tiny Flashlight + LED	Nikolay Ananiev	FREE
5.	Truck Driver 3D: Offroad	Rooster Games	FREE
6.	Google Play Games	Google Inc.	FREE
7.	Slot Car Racing 3D UAE	Gamer Guyz	FREE
8.	360 Security Lite Speed Boost	360 Mobile Security Limited	FREE
9.	Police Car Driver	GameDivision	FREE
10.	MX Player	J2 Interactive	FREE

All installed Apps, like Play Store, YouTube, Gmail can be found in this directory.

APPS: Home Screen > Apps

Tips:1.Long press the OK key to uninstall the selected APK.

2. In the main interface state, press the menu button, you can change the background picture.



# SAME SCREEN

AirPlay Mirroring and third-party same screen applications like *HappyCast*, *WifiDisplay*, etc.

*HappyCast*, *WifiDisplay* and other APK can make your phone available to use wi fi to connect with the projector. And with Airplay Mirroring, you can display your phone screen on your projector.






## HappyCast Operation Guide

1. *Main menu > Mobile screen > HappyCast*  
Or *Main Menu > My Applications > HappyCast*
2. You can download *HappyCast* and other APK by scanning the two-dimensional code with the mobile phone or visit the website.
3. Connect your phone and your projector to the same Wi-Fi network. See <Wi-Fi> on page 19 for more information.
4. Open *HappyCast* app on your phone and the device name should be appear at the bottom of the screen, click connect and and select the content you want to play. See page 14 for details.





## IOS system AirPlay mirror operation guide

1. Connect your IOS device and projector to a common Wi-Fi network.
2. Slide from bottom to top, open the "Control Center" on the IOS device.
3. Click the "AirPlay" .
4. Click the required name of the projection equipment, such as cast07, the common screen can be realized after 5 seconds.





# Airplay Mirroring




## Attentions:



At present, only the following devices can support the AirPlay functions: iPhone5 and other above devices, iPad 2 and other above devices, iPod touch ( 5generations and above ) devices.

## Android Mobile Phone Wireless Mirroring-Screen

1. Turn on wifi both your phone and projector, needn't connect to the network.
2. Turn on Wifidisplay, and stay on this interface.




3. Open the "wireless sharing" or "multi screen interaction" function of the mobile phone (Android system phones are too many, the name of this function may differ.) At this time on the phone will automatically search, and display the name of the projector equipment.
4. Click the device name, wait a few seconds, realize the Mirroring-screen.
5. Note that under the same screen can not operate with the mouse, and if you need to exit, you can disconnect wifi, or click on multi screen interaction in your phone, choose to disconnect.



# SETTING

Click *Home* > *Setting* to find all the tools for customizing and configuring your device.

Including: WLAN, Bluetooth, USB, display, storage, application, language and input method, backup and reset, date and time, and projector.



## Connecting to Wi-Fi

Wi-Fi is a wireless networking technology that can provide wireless Internet access.

- 1, Enter *Home Screen* > *Setting* > *Wi-Fi*.
- 2, Slide the Wi-Fi switch to the ON position to turn on Wi-Fi.
- 3, The projector will scan for available Wi-Fi networks.
- 4, Choose a network name to connect to it.
- 5, If the network is secured, enter the password and enter Connect.



## NOTES:

Your projector automatically connects to the previously used Wi-Fi network when they are in range. When Wi-Fi is connected, your projector can notify you by showing \* ( 📶 ) in the status bar.

## Connection of the HD high definition multimedia interface

The first method:

1. Main menu > high definition import > HD icon > Click to enter
2. Connect the high definition multimedia HD line to the HD interface of the equipment.
3. HD imported picture will be displayed on the projector.
4. Press the return button of the remote controller to return to the main menu.


The second method:

1. Connect the high definition multimedia HD line to the HD interface of the equipment.
2. HD imported signal will be displayed the projection picture automatically in 5 seconds.
3. Press the return button of the remote controller to return to the main menu.  
(Attention: When the projection picture is the HD picture, the sound can not transmit to the BT stereo equipment by the BT, but it can realize the sound transmission by 3.5MM earphone interface. The ladder correction function is not available when using the HD function)

## Connect to the BT device

BT is a kind of short-distance wireless technology. This equipment is the agreement of the BT single launch, the projector only can connect to the BT stereo equipment, it can not realize the same screen function by connecting the mobile phone.

1. Open the home page > Setting > BT > open the BT
2. Must make sure the BT stereo equipment can be searched by the projector within 10 meters.
3. Select the required connected BT device, click OK to finish the connection.
4. After the BT device is opened, but it can not be searched, can click the Refresh option, and search the required connected BT stereo equipment again.




## Application Management

You can browse and manage apps on your device. You can do things like stop, move storage, unmount, clear data and cache on the device.

**Display:** You can select the brightness, font size, screen zoom and screen mode.

1. Brightness > Remote Control / Mouse Adjusts the brightness level
2. Font size > include small, normal, large, very large
3. Screen Zoom > Remote Control / Mouse Adjust the screen aspect ratio
4. Screen Mode > Select Sample Picture > Select includes Soft, Normal, Dynamic





USB: Connect your PC (Notebook)

Storage: View storage capacity

App: Check downloaded app information

Language and input method: including the system language, keyboard, mouse

1. Keyboard: including Android keyboard, Google Pinyin input method and Japanese input method

2. Mouse: Adjusts the pointer speed

Backup and Reset: Back up data and restore factory settings

Date and time: Select the time and date and format


About the Projector: System updates and legal information

# DOWNLOAD APPLICATION

After the Wi-Fi is connected, you can log in Google play store by the network, and download your required APK applications.

1. Log in Google store by the account.
2. Select the TV version of APK is required, the projector is used by the platform of Android TV version, all the downloaded APK must be the TV version. If the remote controller can not operate the downloaded APK, which shows the downloaded APK version is wrong, it may be the APK of mobile phone or ipad, please unload it, and download the TV version of APK again.
3. TV BOX version APK is the best choice for downloading, because it is fully suitable for the remote controller operation.
4. This machine can provide the free mass downloading of all the applications, because a FREECLICK APK application is built in the machine.

View the device status, legal information and other information. You can also update your system with an updated package copied into the USB flash disk.



THANK YOU FOR CHOOSING US

**The product provides 1 year free warranty service.**

If you encounter any questions about the product during the using time, the first step is to contact the seller directly at the following email address to resolve your concerns. We will reply within 24 hours after receiving the email.

Consumer service mailbox: [support@toumeipro.com](mailto:support@toumeipro.com)

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.