# Android POS Terminal Model-Z600 Quick start guide

Thanks for your purchase of Product Descrption. Please read this guide first before you use the device, and it will ensure your safety and the proper use of equipment. About the equipment configuration, please check with the relevant contracts of the device or consult the seller who sells the equipment to you.

The pictures in this guide are for reference only, if some pictures do not match the physical product, please in kind prevail. Many network function which is described in this manual is the specific service by the network service providers. Whether use these functions, it depends on the Internet service provider who services for you.

Without the company's permission, anyone should not use any forms or any ways to copy, excerpts, backup, modify, spread, translated into other languages, all or partly used for commercial

# Indicator icon



Marning: may hurt themselves orothers

Caution: may damage your equipment r other devices

Note: the annotations, use hints or additional information

# Toknowtheproduct

Front view



2 Back View



# Charging for the battery

Before using the device for the first time or the battery for a long time did not make Unavailable, you must first to charge the battery.

Only use the company matching chargers, battery and data cables. Using the charger or data cable without permission will cause the battery explosion or will damage the equipment. In the condition of charging, LED light shows red;When the LED light shows green,it expresses that the battery has been

## Boot/Shutdown the machine

When you boot up the device, Please install the battery. Then wait for some time, when it appears the boot screen,it will lead the progress to complete and go into Android operating system.lt needs a certain period of time at the beginning of the equipment initialization, so please kindly wait for it patiently. When shutdown the device, please remove the battery

# Using the touchscreen

# Click

Touch once, select or openthefunction menu, options or



- This device may not cause harmful interference, and (2) this device must accept any interference received,
- ation. If this equipment does cause harmful interference to radio or television reception, which can be ed by turning the equipment off and on, the user is encouraged to try to correct the interference
- Regrient or relocate the receiving antenna.

consult the dealer or an experienced radio/ TV technician for help.

- Changes or modifications not expressly approved by the manufacturer could void the user's authority to
  operate the equipment.

e compliance requirements, this grant is applicable to only Mobile Configurations. The antennas used for the transmitter must be installed to provide a separation distance of at least 20cm from all

# Use Notes

## The operating environment

- Please do not use this device in the thunderstorm weather, because the thunderstorm weather may result in the equipment failure, or click the danger. • Please put the equipment from rain, moisture and liquids
- containing acidic substances, or it will make the electronic circuit boards corrosion. • Don't store the device in overheating, high temperature,
- or it will shorten the life of electronic devices.
- Don't store the device in a too cold place, because when the device's temperature rises, moisture can form inside, and it might damage the circuit board.
- Do not attempt to disassemble the device, non-professional personnel handling can damage it.
- Do not throw, beat or intense crash the device, because rough treatment will destroy the device's parts, and it may cause the device failure.

### Children's health

- Please put the device, its components and accessories in the place where children can't touch.
- This device is not toys, so children should be under adult supervision to use it.

### The charger security

- When charging the device, power sockets should be installed near the device and should be easy to hit.And the areas must be far away from the debris, flammable
- Please do not fall or crash the charger. When the charger shell damaged, please ask the vendor for replacement.
- If the charger or the power cord is damaged, please do not continue to use, so as to avoid electric shock or fire.

- Please do not fall or crash the charger. When the charger shell damaged, please ask the vendor for replacement.
- Please do not use wet hand to touch the power cord, or with power supply cable way out the charger.
- The charger must meet the "2.5 restricted power" in the request of the standard <GB4943.1 information technology equipment safety
- IF the device needs to connect USB port, please make sure the SUB contains USB port - IF logo and its performance is in accordance with the relevant specification of the USB - IF.

# The battery safety

- Do not use the battery short circuit, or use a metal or other conductive objects to contact with the battery terminal.
- Please do not disassemble, squeeze, twist, pierce or cut
- Please do not insert foreign body in the battery,contact the battery with water or other liquid, make the cells exposed to fire, explosion or other risk sources.
- Do not put or store the battery in high temperature
- Please do not put the battery in a microwave or in the dryer Please do not throw the battery into the fire
- If there is a battery leak, do not let the liquid on the skin or eyes, and if accidentally touched, please rinse with plenty of water, and seek for medical advice immediately.
- When a device in standby time obviously shorter than in the normal time, please replace the battery

### Repair and Maintenance

- Don't use strong chemicals or powerful detergent to clean the device. If it is dirty, please use a soft cloth to clean the surface with a very dilute solution of glass cleaner.
- Screen can be wiped with alcohol cloth, but be careful not to let the fluid accumulate around the screen. Dry the display with a soft non-woven cloth immediately, in order to prevent the screen from leaving the strip traces.