

DO NOT RETURN THE PRODUCT TO THE STORE!

Log on: Click "Service" at www.taiyoedge.com
E-mail: help@taiyoedge.com
TOLL-FREE CONSUMER HELPLINE
1-866-4-EDGE-RC (1-866-433-4372)

OWNER'S MANUAL

Important! Please read your Owner's Manual all the way through before operating your vehicle. Contains important information—keep for future reference.

Safety First

- · Adult supervision is recommended.
- Drive your vehicle in a safe area away from people, pets, cars, etc. Not in streets!
- · Don't touch or try to pick up vehicle when it is in motion. Wait until it stops completely.
- Keep hair, fingers, face and loose clothing away from the wheels, spokes and tires while the vehicle is switched on or while the transmitter is operating.
- Be a responsible Freestyle[™] BMX operator!

Note: Always wear a helmet and elbow and knee pads while riding a real BMX bike.

Batteries Required (not included)

5 "AA" Alkaline or Rechargeable Cells for Bike and One 9-Volt Alkaline Battery for Transmitter.

(See next page for information on rechargeable batteries. Rechargeable batteries and charger not included.)

Battery Installation

Battery Cautions

CAUTION: TO AVOID BATTERY LEAKAGE

- 1. Make sure the batteries are inserted correctly and follow the toy and battery manufacturer's instructions.
- 2. Do not mix old and new batteries.
- 3. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium, nickel-metal hydride or other) batteries.
- 4. Remove weak or dead batteries from product.

More Important Battery Information


- Make sure battery polarity (direction) is correct.
- · Use only battery type(s) recommended.
- Remove batteries from the product if it will not be used for a long period of time.
- · For best performance, use Alkaline batteries. Battery life may vary with the brand used.
- Do not recharge non-rechargeable batteries.
- Remove rechargeable batteries from the product before charging. Recharge batteries only under adult supervision and follow the battery and charger manufacturers' instructions.
- Do not short-circuit battery terminals.
- Keep Bike and Transmitter dry. If they get wet, turn off Bike switch and IMMEDIATELY remove batteries. Wipe off excess moisture and allow to air dry for at least 24 hours.
- Dispose of batteries safely and properly.


Bike Battery Installation


- 1. Lift LATCHES on UPPER BATTERY DOOR and remove door (Fig. 1).
- 2. Insert 2 fresh, new "AA" ALKALINE* BATTERIES in the directions shown on label inside compartment (Fig. 2).
- 3. Snap UPPER BATTERY DOOR securely back into place.
- 4. Turn Bike over, lift LATCHES on LOWER BATTERY DOOR, remove door (Fig. 3).
- 5. Lower compartment takes 3 batteries. First insert 2 fresh, new "AA" ALKALINE BATTERIES in the direction shown on the label inside the compartment. Then insert one fresh, new "AA" ALKALINE BATTERY on top of the first two, facing in the opposite direction as the first two, as shown on the label (Fig 4). Snap LOWER BATTERY DOOR securely back into place.
- 6. Make sure that (+) and (-) on batteries are matched to (+) and (-) on battery compartment labels.

Note: Keep Bike power off to save battery power until you're ready to run.











Transmitter Battery Installation

- 1. Slide open BATTERY DOOR on back of TRANSMITTER (Fig. 5).
- 2. Insert a fresh, new 9-VOLT ALKALINE BATTERY with the polarity (+/-) as shown on the bottom of battery compartment (Fig 6).
- 3. Hold battery in place with thumb and slide battery door all the way closed to secure battery. (Fig. 6A).
- 4. Check for transmitter operation by looking for the red "POWER ON" LIGHT on front to light when a STICK is moved. If LIGHT does not come on, check battery polarity. If LIGHT still does not light, install a brand-new battery.









*Using Rechargeable Cells

(Batteries and Charger not included.) Rechargeable "AA" size batteries may be used in Bike. You'll still need to purchase a 9-Volt Alkaline battery for the transmitter. FOR SAFETY AND BATTERY CHARGING INFORMATION, PLEASE READ AND FOLLOW THE INSTRUCTIONS THAT CAME WITH YOUR RECHARGEABLE BATTERIES AND RECHARGER. ADULT SUPERVISION OF BATTERY CHARGING IS RECOMMENDED.