



PLATINUM

This keyboard folio features a unique, reusable adhesive that securely holds your tablet in place, yet allows it to be removed without residue. You'll be sure to protect your tablet from scratches and other damage with this stylish cover.

PACKAGE CONTENTS

- 10" tablet folio and keyboard
- Micro USB charging cable
- *Quick Setup Guide*

TABLET SYSTEM REQUIREMENTS

- Minimum OS requirement: Android 4.1 or above
- Bluetooth 3.0

FEATURES

- Low-profile keys provide tactile feedback to improve accuracy and speed
- Keyboard has up to 90 hours of battery life and recharges with a USB cable (included)
- Android keyboard shortcuts improve your tablet experience
- Magnetized folio and keyboard hold everything in place
- Removable keyboard offers easy portability

CHARGING YOUR KEYBOARD

Note: The keyboard battery should be fully charged before using it for the first time.

The LED blinks blue when the battery level is below %15. To maximize battery life, the keyboard goes into sleep mode after it is idle for 10 minutes.

- Connect the micro USB charging cable (included) from the keyboard's charging port (⚡) to a computer. The LED turns off when charging is complete.

Note: It will take about 4 hours to charge your keyboard for the first time.


ATTACHING AND REMOVING YOUR TABLET

- 1 Lay the folio on a flat surface, then carefully remove the plastic cover from the two adhesive strips.
- 2 Align the back of your tablet with the adhesive, then press down gently to secure it. **Note:** If the adhesive loses its stickiness, carefully wipe it with a damp, lint-free cloth, then let it air dry to refresh its stickiness.
- 3 To remove your tablet, hold the folio in place, then gently lift one edge of your tablet up to peel it off the adhesive.
- 4 To refresh the adhesive, gently wipe with a water-based wet wipe or damp sponge and let air dry. Reapply your tablet as many times as necessary.




USING YOUR FOLIO AS A STAND

- 1 Attach your tablet to the folio. See "Attaching and removing your tablet" for instructions.
- 2 Place the keyboard on the magnetized back of the folio, then rest the bottom of the tablet on the keyboard's built-in stand.
- 3 Slide the magnetic keyboard back and forth to find a comfortable viewing angle.



BLUETOOTH / BATTERY LED

WHAT IS THE LED DOING?	WHAT IT MEANS
Blinking every second after pressing the pairing button	The keyboard is in pairing mode.
Blinking every second	The battery level is below %15.
Continuously lit	The battery is charging. The LED turns off when charging is complete.



PT-UN10K2B
SLIM FOLIO FOR 10" TABLETS
QUICK SETUP GUIDE

Before using your new product, please read these instructions to prevent any damage.

PT-UN10K2B SLIM FOLIO FOR 10" TABLETS

UNDERSTANDING YOUR KEYBOARD

ICON (*press with Fn key)	DESCRIPTION	ICON (*press with Fn key)	DESCRIPTION	ICON (*press with Fn key)	DESCRIPTION
	Language shift		Previous track		Home
	Select all		Play/ Pause		Email
	Select left		Next track		Page up
	Select right		Stop		Page down
	Cut		Volume down		Home
	Copy		Volume up		End
	Paste		Lock		

Notes:

- If used with products other than Samsung Android Tablets, some function keys will not work.
- Your keyboard is magnetically attached to your case, so you can adjust it or remove it from the case. Place it back in the case for storage.

PAIRING YOUR KEYBOARD TO A TABLET

- 1 Slide the power switch on the left side of your keyboard to **ON**.
- 2 Press the pairing button () on the left side of your keyboard. The LED blinks blue.
- 3 Navigate to your tablet's Bluetooth settings, turn on Bluetooth, then search for available devices. For more information, see the documentation that came with your tablet.
- 4 Select "Platinum Keyboard" from the list of available devices on your tablet.
- 5 On your keyboard, type the password that your tablet displays, then press **ENTER**. The keyboard pairs to your tablet and the LED turns off.

RECONNECTING TO A PAIRED TABLET

- Turn on your keyboard and press any keys twice, then make sure that the tablet's Bluetooth is turned on. The keyboard automatically pairs to the last connected tablet if it is within 33 feet (10 meters) of the keyboard.

Note: If your keyboard does not pair, try pressing the pairing button on the left side and selecting "Bluetooth Keyboard" from the list of devices on your tablet.

CARE AND MAINTENANCE

- Carefully wipe the adhesive with a water-based wet wipe (recommended) or a damp, lint-free cloth, then let it air dry to refresh its adhesive properties.
- Do not use soap or chemicals on the adhesive. This may cause the adhesive to lose stickiness and make it unable to hold your tablet in place.

LEGAL NOTICES

FCC caution

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and

This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ONE-YEAR LIMITED WARRANTY

CONTACT PLATINUM

For customer service, call 1-800-499-3964

Distributed by Best Buy Purchasing, LLC, 7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2014 BBY Solutions, Inc. All Rights Reserved.



QDID: B017616



FCC ID: OXM000062