

The Instruction of Alcatel Wi-Fi camera

2016/3/14

1. Download and install APK : Alcatel_1.0.0.7.apk

2. Execute app, Click on “Equipment”, “+”



3. Enable smart phone Wi-Fi and connect to camera AP(MAC ID:CamAP20:F4:1B:07:5F:9A)

4. To scan QR code via APP(Fig.2)



5. Camera(Red LED indication flashes)

5-1.Type in UID

(DBUUB96CVD3W8M6GYHWJ)

5-2.Equipment Password (Default: 888888)

5-3.Click on top-right “V” to finish setting



P.S. When APP asks for changing password, please follow to change it.

6. Setting Done(Camera already connected)



7. Click on "camera" to enable camera video, The bar at bottom side is video apps



8. APP shows that IP cam was connected and click on  to enable camera Wi-Fi settings



9. Choose an appropriate Wi-Fi for camera connection. Type in Wi-Fi password to finish internet setting (cam LED in red)



FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

CAUTION:

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.