



Solus Series iConnect

USER MANUAL

iConnect





**CAUTION**

RISK OF ELECTRIC SHOCK.  
DO NOT OPEN.

**Caution:** To reduce the risk of electric shock, do not remove cover (or back). No user serviceable parts inside. Refer servicing to qualified service personnel.

**WARNING:** To reduce the risk of fire or electric shock, do not expose this product to rain or moisture. The apparatus shall not be exposed to dripping or splashing. No objects filled with liquids, such as vases, shall be placed on the apparatus.

**Important Safety Instructions**

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings.
- 4 Follow all instructions.
- 5 Do not use this apparatus near water.
- 6 Clean only with dry cloth.
- 7 Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9 Protect the power cord from being walked on or pinched

particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

- 10 Unplug this apparatus during lightning storms or when unused for long periods of time.
- 11 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.


### **FCC Information**

FCC Regulations state that unauthorized changes or modifications to this equipment may void the user's authority to operate it.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

## Step 1: UNPACKING

Make sure you find the following pieces in your iConnect package:




Plus:

Combo USB/standard power adapter cable

3.5mm stereo audio cable

## Step 2: DOCKING

Plug the iConnect transmitter's dock connector into your iPod's 30-pin connector.



iPod is a registered trademark of Apple Inc.

### Step 3: LINKING

The iConnect dock and receiver usually link automatically once you've docked your iPod and plugged in the receiver. A solid blue LED on the dock and the receiver indicates that the two pieces are linked.

If you get a blinking blue LED on the dock and/or receiver, try the following steps to link the two manually:

- 1 Take the iConnect dock and iPod next to the receiver—keep the dock and iPod connected.
- 2 Find the LINK buttons on the back panel of the receiver and on the side of the dock.



iConnect dock, side view


- 3 Press and hold the LINK buttons on the receiver and dock for 5 seconds. The blue LEDs on each blink while the two pieces are linking. These LEDs stay solid blue when the two have linked.

Now you're ready to enjoy music from your iPod over your home stereo with no wires attached! Just use your iPod like you normally would to select songs, playlists, etc. And enjoy!

# iConnect Buttons and Jacks

## Dock Buttons and Jacks

iConnect dock: connects to iPod models with 30-pin dock connector



Link button: manually links the dock to the receiver

