

2-Line Wireless Desk Phone with Intercom *User's Guide*



25260

Equipment Approval Information

Your telephone equipment is approved for connection to the Public Switched Telephone Network and is in compliance with parts 15 and 68, FCC Rules and Regulations and the Technical Requirements for Telephone Terminal Equipment published by ACTA.

1 Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the US number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

Notes

- This equipment may not be used on coin service provided by the telephone company.
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.
- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.
- If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

US Number is located on the cabinet bottom

REN number is located on the cabinet bottom

2 Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

Interference Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

warning: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Licensing

Licensed under US Patent 6,427,009.

Hearing Aid Compatibility

This telephone system meets FCC standards for Hearing Aid Compatibility.

FCC RF Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

Information for DECT Product



This telephone is compliant with the DECT 6.0 standard which operates in the 1.92GHz to 1.93GHz frequency range.

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.



 <p>THE LIGHTNING FLASH AND ARROW HEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF "DANGEROUS VOLTAGE" INSIDE THE PRODUCT.</p>	<p>CAUTION: RISK OF ELECTRIC SHOCK DO NOT OPEN</p> <p>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.</p>	 <p>THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF IMPORTANT INSTRUCTIONS ACCOMPANYING THE PRODUCT.</p>
SEE MARKING ON BOTTOM / BACK OF PRODUCT		

Table of Contents

Equipment Approval Information	2	Telephone Operation	22
Interference Information	3	-Making calls with the cordless handset	22
Licensing	3	-Making calls with the corded handset (from the base)	22
Hearing Aid Compatibility	3	-Making calls in the speakerphone mode (from the base)	22
FCC RF Radiation Exposure Statement	4	-Making calls in the speakerphone mode (from the handset)	22
Information for DECT Product	4	-Making Calls with the RCA Wireless Headset	22
Introduction	7	-Making Calls with a Wired Headset	22
Parts Checklist	7	-Pre-Dialing	23
-Telephone Jack Requirements		-Answering a Call	23
Installation	8	-Switching between the speakerphone, handset & headset mode	23
-Digital Security System		-Mute	24
Important Installation Guidelines	8	-Do not disturb	24
Base Layout	9	-Flash	24
Base Station	10	-Inserting a pause in the dialing sequence	24
Installing the Phone	10	-Redial	25
-Installing the battery	10	-Reviewing the Redial Numbers	25
-Base Station	10	-Storing a Redial Record in Directory	25
Wirelessly Connect Accessories	13	-Transferring a call to another extension	26
-Adding 25055 or 25065 to 25260	13	-Receiving a transferred call from another extension	26
-Adding 25260 to a Another RCA Phone	14	-Ringer on/off and ringer volume	26
Programming the Phone	15	-Speakerphone, handset and headset volume	26
-Standby Screen	15	-Hold	27
-Programming Functions	15	-Conference calls	27
-Select Mode	15	Intercom Calls	28
-Main/Wired Mode	15	-One-touch /memory log	28
-Extension/Wireless Mode	16	-Answering an intercom call	28
-Phone Setting	16	-Page	28
-Date/Time	16	-Auto Standby	28
-Auto Answer Intercom	17	Caller ID (CID)	29
-Dial Mode	17	-Receiving and storing CID records	29
-Area Code	17	-Reviewing CID records	29
-Registration	17	-Saving a CID record to the phone directory	30
-Register	18	-Deleting a CID record	30
-Remove Extension/Wireless	18	-Deleting all call records	30
-Deregistering	18	-Dialing back	30
-2nd Call Alert	19	-Call waiting caller ID	31
-Updated Device List	19	Directory & One-Touch Memory	32
-Display Setting	19	-Adding directory entries	32
-Language	20	-Storing a record in the one-touch/memory buttons	32
- Contrast	20	-Reviewing directory records	33
-Backlight	20	-Editing a name or number stored in the one-touch/ memory log	33
-Sound Setting	20	-Reviewing record in the one-touch/memory	33
-Ring Tone	20	-Editing a directory record	33
-Ring Volume	21	-Copying a directory record	34
-Key Tone	21	-Deleting a directory record	34
-Voice Mail	21	-Deleting all directory records	34
-Call VM	21	-Deleting a one-touch/memory	35
-Settings	21	-Dialing a directory record	35
		-Dialing a one-touch memory/record	35

Table of Contents Cont.

Display Messages	36
Handset Sound Signals	37
<i>-Backup battery operation</i>	37
Troubleshooting Guide	38
<i>-No Dial Tone</i>	38
<i>-Can't Dial Out</i>	38
<i>-Handset Doesn't Ring</i>	38
<i>-Static/Noise/Fading In and Out</i>	38
<i>-Memory Dialing Doesn't Work</i>	38
<i>-Unit Locks Up</i>	38
<i>-Out of Range</i>	38
<i>-Date/Time Setting Default</i>	38
<i>-Caller ID solutions</i>	39
General Product Care	40
Causes of Poor Reception	40
Warranty Assistance	41
Limited Warranty	42-43

Introduction




CAUTION: When using telephone equipment, there are basic safety instructions that should always be followed. Refer to the **IMPORTANT SAFETY INSTRUCTIONS** provided with this product and save them for future reference.


IMPORTANT: Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.

Parts Checklist


Make sure your package includes the following items:




Base & Desk Stand (included assembled)



Corded handset




Handset cord



AC power adaptor



Telephone 2-Line Cords




Short Line Cord

Telephone Jack Requirements

To use this phone, you will need a RJ11C (for a single line) or a RJ14C (for two lines) type modular phone jack, which might look like the one pictured here, installed in your home or office. If you don't have either modular jack, call your local phone company to find out how to get one installed.

If you are setting up a system with multiple phones, only one phone (the unit in **Main/Wired** mode) needs to be plugged into a phone jack. Additional phones can be wirelessly connected to this phone using the **Extension/Wireless** mode.

Wall plate



Modular telephone line jack

Installation

Digital Security System

Your cordless phone uses a digital security system to protect against false ringing, unauthorized access, and charges to your phone line.

INSTALLATION NOTE: Some cordless telephones operate at frequencies that may cause or receive interference with nearby TVs, microwave ovens, and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV, microwave ovens, or VCR. If such interference continues, move the cordless telephone farther away from these appliances.

Certain other communications devices may also use the 1.9 GHz frequency for communication, and, if not properly set, these devices may interfere with each other and/or your new telephone. If you are concerned with interference, please refer to the owner's manual for these devices on how to properly set channels to avoid interference. Typical devices that may use the 1.9 GHz frequency for communication include wireless audio/video senders, wireless computer networks, multi-handset cordless telephone systems, and some long-range cordless telephone systems.


Important Installation Guidelines

- Avoid sources of noise and heat, such as motors, fluorescent lighting, microwave ovens, heating appliances and direct sunlight.
- Avoid areas of excessive dust, moisture and low temperature.
- Avoid other cordless telephones or personal computers.
- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch non-insulated telephone wires or terminals, unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.



Caution: For use only Class (Classe) 2 power source 7.5VDC 400mA

Base Layout




Installing Your Phone

The phone may be connected to one 2-line (RJ14C) or two 1-line (RJ11C) wall jacks to accommodate both lines.

1. If operating the unit in MAIN/EXT mode, choose an area near an electrical outlet and a telephone wall jack (RJ11C), and place your cordless telephone on a level surface, such as a desktop or tabletop, or you may mount it on the wall.
2. Install 5 AAA-size alkaline batteries (not included) for back up power in the event of a power failure.

NOTE: Please use the included power adaptor for normal use; the 25260 is designed to run on the back up batteries for short periods only.



- Insert a flat-head screw driver or similar object into the battery door latch and gently pry upward to release the battery door from the base.
- Insert the batteries inside the battery compartment as shown on the diagram.
- Snap the battery compartment door back into place.

NOTE: If the low battery icon appears in the display, you need to replace the batteries. It is important that you replace them as soon as possible to maintain unit operation when electrical power is off. As a precaution, you may want to write down any stored information you do not want erased.

IMPORTANT: If you are not going to use the telephone for more than 30 days, remove the batteries because they can leak and damage the unit.

3. Plug the power supply cord into the power jack on the back of the base and the other end into an electrical outlet.

CAUTION: To reduce risk of personal injury, fire, or damage use only the T-2757 (base) power adaptor listed in the user's guide. This power adaptor is intended to be correctly orientated in a vertical or floor mount position.

4. Connect the telephone line cords:

If you are connecting to two 1-line phone jacks with two phone cords:

You can use the two included 1-line phone cords to connect the phone lines to the jacks in the back of your phone.

