

45-1/43/10/-2

TOMY

CHAR-G SET CONTENTS

AGES 5+






- A. Four Hubcaps
- B. Charging Plug
- C. Handset & Charger
- Transmitting Aerial.
- E. Charging Indicator Lights
- F. Forward/Wheelie Control Button
- G. Spin Control Button
- H. Receiving Aerial
- I. Char-G Radio Controlled Car
- ON/OFF and Charge Switch.
- K. Charging Socket
- L. Wheelie Roller Ban

REQUIRES 4 "AA" BATTERIES

SETTING UP YOUR CHAR-G

CHOKING HAZARO-Small parts Not for children under 3 years




HUB CAPS: Gently snap off the nub caps from their prastic holding frame. Carefully press the large hub caps into the rear tires and the smaller hub caps into the front tires

G

HAMDSET BATTERIES: Loosen the screw on the back of handset, placing firm downward pressure where "OPEN" is marked, slide the pane: down and lift off. Insent 4 "AA" non-rechargeable batteries as the diagrams on the bottom of the battery compartment indicates. Slide the panel back in place and fasten the screw.


Requires 4 "AA"
Batteries



CHARGING: Only charge the car when it is drained of power and has stopped running. Push the "ON/OFF" switch underneath the car to "CH/OFF". Insert the plug on the handset onto your Char-G's charging socket.



charging (cont.): Hold Char-G onto the handset and press either button on the handset. When the green light goes out after 45 seconds, remove the car and flick the switch on the car's base to the "ON" position. Char-G is ready for action! If the car runs for less than 1 minute after a full charge, replace handset bafferies.



RECHARGEABLE BATTERY: There is a small rechargeable battery pack located inside of Char-G. You should be able to recharge your Char-G numerous times without the need to change the battery pack. Should you find your Char-G no longer holds a charge, it is time to replace the rechargeable battery pack. Contact Tomy via email at "consumer@tomy.com" for information about how to purchase a new pack. To access the pack located inside your Char-G race car, remove the three screws on the underside of the car located in the positions shown on diagram to the left. Remove body of car from chassis. Rechargeable battery pack is located at rear of chassis. The pack contains rechargeable Nickel-Metal Hydride cylindrical cell batteries. Contact your local recycling center for information on where to return the used batteries.



MUST BE RECYCLED OR DISPOSED OF PROPERLY.