o avoid battery leakage:
Do not expose battery to excessive physical shock, vibration, o
Do not disassemble, attempt to repair, or deform the battery.
Do not dispose of battery in a fire.
Do not ouch the terminals of the battery or cause a short bet terminals with a metal object.

BATTERY CHARGING



a Class B digital device, pursuant to Patr 1 3 on URE > 2 on URE | 2 on URE |

Exeter, EX2 SAZ, UK 30-Ngv-2016

When the FusionCore power level gets low, the Power Indicator Lights on the FusionCore will begin to flash at increasingly rapid intervals.

To charge your FusionCore, connect the micro USB charging cable to the FusionCore's USB port. Connect the other end to a powered USB port.


When the battery is charged and the USB is disconnected, the Power Indicator Lights will turn off.


Google, nexus, rinalious, and selv year an ele suberminar of blodge into Samsung, Samsung Galaxy, Samsung Galaxy Notel[Pro, and Samsung Galaxy Tab[Pro are trademarks of Samsung Electronics Co., Ltd. Amazon, Amazon Fire, Kindle Fire, and Fire are trademarks of Amazon Technologies, Inc.



WWW.LIGHTSEEKERS.COM







TOMY

FRONT Oct/05/2016

Back Size: 11"(L) x 8.5"(W) Folded size: 5.5" x 8.5"




Material: 80gsm Woodfree Paper Color: 1C(Black) + 1C(Black) Folding: 1 foldes

- Install the Lightseekers game on your mobile device: lightseekers.com/download
- 2 Enable Bluetooth on your mobile device.
- **3** Launch Lightseekers game






Remove the back cover from your Hero and insert uour FusionCore.



5 Turn on the FusionCore by moving the ON/OFF switch to the "I" position

ON/OFF switch

- 6 Pair your Hero with the Lightseekers game using the in-game prompts.
- Your Hero will instantly appear in the game and light up.



in either of your Hero's hands. The weapon will light up and instantly appear in the game.



To remove the weapon, pull and hold the release lever in the direction of the weapon, then remove the weapon from your Hero's hand.



Using the camera icon in the Lightseekers game, scan the included AR trading cards for in-game bonuses and augmented reality effects. These cards can also be played in the Lightseekers Trading Card Game.

1 HERO CARD — Exclusive to the starter pack, this card represents the Hero you've chosen and offers AR effects and rewards.

ITEM CARD — Exclusive to the starter pack, this card represents your Hero's weapon and offers AR effects and unlocks.

• 3 COMBO CARDS -Scan for AR effects, unlocks, and powerful in-game abilities.

• **1 TRIBUTE CARD** — Scan your unique card and share it with your friends. The more you share it, the more powerful it becomes.

TROUBLESHOOTING TIPS

- If your Hero does not pair with the game, check that your FusionCore is charged and inserted fully into the back of your Hero.
- · If your weapon isn't registering, check that it is properly connected into the port on the Hero's hand.
- · For additional troubleshooting tips and gameplay information, visit lightseekers.com
- To return your "rusionCore to its factory settings set the On/Off switch to the "I" position while holding both trigger buttons down. Keep the trigger buttons held until a Tone is heard. This will take 10 seconds and the lights on the FusionCore will stay on throughout. Set the On/Off switch "O" and then "I" again and your FusionCore will be reset.
- · For product related issues, contact Customer Support at: cs@tomy.com or 1-800-704-8697





App Store Google Play



WWW.LIGHTSEEKERS.COM



inside Front

inside Back