




Vista and Windows 7 Remote control – 2.4 GHz








1. Physical Description and Specification – Text type -Teletext









2. Remote Control Buttons

item	Function	Icon	item	Function	lcon	item	Functio	Icon
							n	
1	Power (Standby)	٢	19	Mouse		35	3	3 DEF
2	Mouse on/off	θ	20	Up	^	36	4	4 GHI
3	Radio	0	21	Down	\sim	37	5	5 JKL
4	Music	a l	22	Left	<	38	6	6 MNO
5	Picture		23	Right	>	39	7	7 PQRS
6	Video		24	Media Record	•	40	8	8 TUV
7	Live TV	ĕ	25	Media Pause	II	41	9	9 WXYZ
8	DVD Menu		26	Media Play	\blacktriangleright	42	*/.	*/.
9	Recorded TV	ĕ	27	RWD	44	43	#	#
10	Guide	E	28	FWD	**	44	Clear	CLEAR
11	Media Center Start	*	29	Replay	H I	45	Enter	ENTER
12/13	Volume Up/Down	+ +	30	Media Stop		46	DVD Subtitle	
14/15	Channel Up/Down	+ \$ _	31	Skip	H	47	Mouse left	θ
16	Browser Back	+	32	0	•]	48	Mouse right	θ
17	More	ī	33	1	1			
18	Volume Mute	0	34	2	2 ABC			

CAUTION:

Any changes of modifications not expressly approved by the grantee of this device could void the users authority to operate the equipment.

This manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE

THIS MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.