## OPERATING INSTRUCTION FOR BLUETOOTH CAR KIT

- 1. Start car engine.
- 2. Insert the Bluetooth Car Kit into car cigarette lighter socket, the red LED power indicator will light up.
- 3. Pairing:
  - Press and hold function key for 2 seconds, the blue light flashes 5 times briefly and rapidly, then the red light and blue blight flash in turn to indicate the headset is ready for pairing.
  - Start the pairing process according to the user's manual of Bluetooth phone.
  - Your phone will find the "CCM Car Kit" after you selected the "Discover" in your Bluetooth phone to search a Bluetooth device. Confirm this.
  - Enter the pass code 0000.
  - You can check the phone if pairing was successful.
  - If pairing was unsuccessful in 60 seconds, headset will leave pairing mode automatically.

### **MAKING A CALL**

- Making the call by using your phone in the normal way.
- For certain phones, if you can not have communication from car kit after you press phone's "send" key, please press and release function key to transfer the call to car kit
- Using voice dialing
  - 1. This function is only available if your phone supports voice dialing.
  - 2. You have to set up voice tag on your phone before activate voice dialing.
  - 3. Press and release function key, you will hear a tone from car kit to indicate that you can say the desired name (voice tag).
  - 5. Say the voice tag.

## **ANSWERING A CALL**

- Press and release function key after you hear the ring tone. The blue light flashes briefly and rapidly 4 times every 3.5 seconds during the conversation. The headset beeps once with the high tone.
- For certain phones, if you can not answer the call by pressing and releasing function key. Please answer the call from your cellphone first, then please press and release function key to transfer the call to car kit.

#### **ENDING A CALL**

- Press and release function key, the blue light flashes every 3 seconds. The car kit beeps once with the high tone.

OR

- End the call by using your phone in the normal way.

# CALL-WAITING

Press and release function key once to switch between calls. The car kit beeps once with the high tone

when pressing function key.

## ADJUSTING THE SPEAKER VOLUME

Press the volume up key to increase or the volume down key to decrease the volume. The car kit beeps once for each adjustment with high tone.

### **MUTE**

- 1. Press and hold either the volume up key or the volume down key for 2 seconds to mute the call. The car kit beeps with the low tone continuously during mute.
- 2. Press and release either the volume up key or the volume down key to resume the call. The car kit beeps twice with the low tone.

NOTICE: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

### FCC ID.: 030BT600

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.