



Customer Experience Center
1-800-331-4331

CAMRY

2009 Navigation System Quick Reference Guide

TABLE OF CONTENTS

LIMITATIONS OF THIS QUICK REFERENCE GUIDE	1
BASIC OPERATION	2
DESTINATION INPUT	3
<i>By Address</i>	<i>3</i>
<i>Voice Recognition Sequence</i>	<i>5</i>
<i>Tips for Using Voice Recognition</i>	<i>5</i>
<i>By Address - Voice Recognition</i>	<i>5</i>
DESTINATION INPUT - POINTS OF INTEREST (POI)	7
<i>Points of Interest by Name</i>	<i>7</i>
<i>Points of Interest by Category</i>	<i>8</i>
<i>Points of Interest by Category - Voice Recognition</i>	<i>9</i>
DESTINATION INPUT - TELEPHONE NUMBER	10
<i>Business or Registered Memory Points</i>	<i>10</i>
REGISTER HOME	11
BLUETOOTH TELEPHONE PAIRING	13
CALLING BY VOICE RECOGNITION	14
ADDITIONAL NAVIGATION FEATURES	15
<i>Search Area</i>	<i>15</i>
<i>Route Preferences</i>	<i>15</i>
<i>3 Routes</i>	<i>15</i>
<i>Screen Preferences</i>	<i>15</i>
<i>Beep Setting</i>	<i>16</i>
<i>Volume Setting</i>	<i>16</i>
<i>Keyboard Setting</i>	<i>16</i>
<i>Screen Transition</i>	<i>16</i>
<i>Freeway Exit Info Mode</i>	<i>16</i>
<i>Estimated Distance and Time</i>	<i>17</i>
<i>Operation of Your Vehicle Emergency Screen</i>	<i>17</i>
VOICE COMMANDS	18
NOTE ON VOICE RECOGNITION	18

LIMITATIONS OF THIS QUICK REFERENCE GUIDE

This Quick Reference Guide is designed to provide information on the basic operation and key features of the navigation system. The Quick Reference Guide is not intended as a substitute for the Navigation Owner's Manual. We strongly encourage you to review the Navigation Owner's Manual so you will have a better understanding of the navigation system capabilities and limitations.

VOICE COMMANDS

Press the voice command button on the steering wheel to activate the voice recognition feature. After you hear a beep, say one of the voice commands listed or say "Help" for additional options. Please refer to the Navigation Owner's Manual for additional information.

NAVIGATION MODE		TELEPHONE MODE
DESTINATION	POI	CALLING
Go home	Nearest "_____"	Dial by Number
Address	ATM	Dial by Name
Delete final destination	Airport	Dial
	Amusement park	Cancel
	Bank	
	Barber shop	
	Car wash	
	Coffee house	
	Convenience store	
	Department store	
	Dry cleaning	
	Ferry Terminal	
	Gas station	
	Golf course	
	Grocery store	
	Historical monuments	
	Home and garden	
	Library	
	Parks	
	Pharmacy	
	Post Office	
	Restaurant**	
	Rest area or rest shop	
	Specialty food store	
	Stadium	
	Theater	
	Tourist information	
	Video rental	
	Zoo	
	Hide Icons	
SCREEN PREFERENCES		FUNCTIONS
Single map	Audio on	
Dual map	Audio off	
Compass mode	Next track	
VOLUME		Previous track
Louder	Seek up	
Softer	Seek down	
	Next disc	
	Previous disc	

* Available during route guidance

** Nearest "_____ Restaurant (American, Chinese, Fast, Italian, French, Japanese, Mexican, Seafood, or Other). Food or restaurant may be used interchangeably.

NOTE ON VOICE RECOGNITION

The navigation system voice recognition feature will compare your spoken words with computer-generated word patterns preprogrammed in the system database. If the system does not provide your intended match, please try a different pronunciation. Voice-activation names are not available for every street and city. Please see the Tips for Using Voice Recognition section on page 5 for more information about this feature.



1 INFO Button

Access Maintenance, Telephone, Calendar, Language, and Screen Settings.

2 MENU Button

Access Voice Guidance Volume, Select User, My Places, Setup and Suspend Guidance.

3 DESTINATION Button

Input the destination by one of several methods and initiate route guidance.

4 MAP/VOICE Button

Repeat the last voice guidance prompt or cancel one touch scroll.

5 CURRENT VEHICLE POSITION Mark

Indicates the current position of the vehicle and its directional heading.

6 ZOOM IN/ZOOM OUT Icons

Touch to magnify or reduce the map scale.

7 DISPLAY Button

Adjust the contrast, brightness or turn off the screen.

8 AUDIO Button

Set the radio station presets, adjust the balance and tone controls.

9 NORTH UP OR COMPASS MODE Icon

Touch to change the map display between North-up or Head-up perspectives.

DESTINATION INPUT

BY ADDRESS



step 1 Press the **DEST** panel button followed by and move to step 3. To change Search Area, touch **Change** and move to step 2.



step 2 Select the appropriate Search Area, then touch OK to confirm the selection.



step 3 Input the house number using the number keys.




step 4 Touch **Street** and input the street name using the letter keys. Touch **More** to see all of the available options.



step 5 Use or to scroll up or down one page if necessary. Touch the desired street.



step 6 Touch **Input City Name** to type in the city name or select from a previously registered city. If the city is not available try the next largest city in the vicinity.




step 7 Use or to scroll up or down one page if necessary. Touch the desired city.



step 8 Select the desired Route Preference by touching the Route Preference icon.



step 9 Select the desired Route Preference(s) for the trip. When the yellow bar appears, the route has been selected. Touch to confirm your selection.



step 10 If necessary, use the arrow keys to adjust the position on the map to put you closer to your destination. Touch to confirm the position.




step 11 Touch .

Quick Tip - Enter the street name without prefixes such as North or the letter N. The system will display all of the options available.

DESTINATION INPUT

VOICE RECOGNITION SEQUENCE



TIPS FOR USING VOICE RECOGNITION

tip 1 Have the full and correct address in mind, so you can speak it as prompted. Example: "19001 South Western Avenue, Torrance, California"

tip 3 Speak at a normal volume and pace, and pronounce words clearly.


tip 5 Numbered street names should be spoken as in these examples:
1st Street, say: "First Street"
15th Street, say: "Fifteenth Street"
190th Street, say: "One Hundred Ninetieth Street"

tip 2 Before using voice recognition, roll up all windows and set the climate control fan on low or off to reduce background noise in the cabin.


tip 4 When saying street names, include North, South, East or West and Street, Avenue, Boulevard, etc. in the name.

tip 6 Say a street address number as single digits. Examples:
125, say: "One two five"
2000, say: "Two zero zero zero zero"
32307, say: "Three two three zero seven"

BY ADDRESS - VOICE RECOGNITION



step 1 Press the voice command button on the steering wheel and wait for the beep. After the beep say, "Address."



step 2 The system will confirm your input by repeating "Address" and displaying the command at the top of the screen.

DESTINATION INPUT


BY ADDRESS - VOICE RECOGNITION




step 3 Press the voice command button on the steering wheel and wait for the beep. After the beep say, "California." For your destination, choose the appropriate state.




step 4 Press the voice command button on the steering wheel and wait for the beep. After the beep say, "Los Angeles." For your destination, choose the appropriate city.



step 5 Press the voice command button on the steering wheel and wait for the beep. After the beep say, "Adams Boulevard." For your destination, choose the appropriate street.



step 6 Press the voice command button on the steering wheel and wait for the beep. After the beep say, "One Zero Zero." For your destination, choose the appropriate numerical address.



step 7 Press the voice command button on the steering wheel and wait for the beep. After the beep say, "Enter destination" or touch .



step 8 Touch **Guide**.

DESTINATION INPUT - POINTS OF INTEREST (POI)

POINTS OF INTEREST BY NAME



step 1 Press the **DEST** panel button followed by  icon to access points of interest by name.



step 2 Input the POI name using the letter keys and then touch **List**.



step 3 Use  or  to scroll up or down one page if necessary. Touch the desired selection.



step 4 Select the desired Route Preference and then touch **Enter**.



step 5 Touch **Guide**.

Quick Tip - If the POI isn't listed in the database verify the spelling and Search Area for accuracy.
Quick Tip - Touching the **Info** button next to the POI name will display the address and telephone number.

DESTINATION INPUT - POINTS OF INTEREST (POI)

POINTS OF INTEREST BY CATEGORY




step 1 Press the **DEST** panel button followed by the **POI Category** icon to access the points of interest by category.



step 2 Touch the **POI Category** icon to search for points of interest in the vicinity.



step 3 Touch the **Travel** icon.




step 4 Touch the **Hotels** icon followed by OK and then touch **Search** to see the points of interest in the vicinity.




step 5 Use **Up** or **Down** to scroll up or down one page if necessary. Touch the point of interest followed by **Enter** and then **Guide**.

DESTINATION INPUT - POINTS OF INTEREST (POI)

POINTS OF INTEREST BY CATEGORY - VOICE RECOGNITION



step 1 Press the voice command button on the steering wheel and wait for the beep. After the beep say, "Nearest hotel." Most POI categories can be found by saying, "Nearest <POI category.>".



step 2 Press the voice command button on the steering wheel and wait for the beep. After the beep say, "Add to destination" or "Replace destination." To see a list say, "Show list."



step 3 Select the point of interest followed by touching **Enter** and then **Guide**.

DESTINATION INPUT - TELEPHONE NUMBER


BUSINESS OR REGISTERED MEMORY POINTS




step 1 Press the **DEST** panel button followed by the **[F10]** icon.



step 2 Touch the **Phone #** icon to input telephone number.




step 3 Input the area code and telephone number using the number keys followed by the **[F10]** icon. It is not necessary to dial "1."



step 4 Select the business or assigned memory point from the screen.



step 5 Select the desired Route Preference and then touch **Enter**.



step 6 Touch **Guide**.

REGISTER HOME



step 1 Press the **MENU** panel button followed by the  icon to register your home. Touch **[Register]** to input your home address.



step 2 Make sure that you are in the desired Search Area. Touch the  icon to begin address input.



step 3 Input the house number using the number keys.

Tip - For security reasons, use a point close to your home instead of your actual home address.



step 4 Touch **[List]** and input the street name using the letter keys. Touch **[List]** to see all of the available options.



step 5 Touch **[Input City Name]** or select from a previously registered city.



step 6 Touch the desired city.



step 7 If necessary use the arrow keys to adjust the position on the map. Touch **Enter** to confirm the position.



step 8 Touch **Icon** at the top left of the screen to change the home icon.



step 9 Touch the desired icon for your home.



step 10 Touch **OK** at the bottom of the screen. Press the **ENT** panel button to complete the registration of your home.

BLUETOOTH TELEPHONE PAIRING



step 1 Press the **INFO** panel button and touch to pair the Bluetooth devices.



step 2 Touch .




step 3 Touch .



step 4 Touch to pair the Bluetooth equipped cell phone.



step 5 In the approved Bluetooth cell phone, input the passkey listed on the screen. Please refer to the cell phone manufacturer's owner's manual for pairing procedures.




step 6 Upon connection, the system will indicate that the pairing process was successful.

Quick Tip - Verify the Bluetooth cell phone has been approved by visiting www.Toyota.Letstalk.com.

Quick Tip - Verify that the Bluetooth feature has been switched ON and visible to other Bluetooth devices.


CALLING BY VOICE RECOGNITION



step 1 Press the voice command button on the steering wheel and wait for the beep. After the beep say, "Dial by number."



step 2 Press the voice command button on the steering wheel and wait for the beep. After the beep say, "Eight, zero, zero, five, five, five, one, two, one, two." Say the numbers individually and at a moderate speed.




step 3 Press the voice command button on the steering wheel and wait for the beep. After the beep say, "Dial." If the incorrect number has been inputted or if you wish not to complete the call, touch **Cancel**.



step 4 The call is active after **Calling** changes to **Talking**.



step 5 To end the call touch **End**.



Some Bluetooth equipped cell phones may or may not show battery or signal strength on the display.



Touch the Mute icon to mute the conversation. When muted the yellow indicator above the icon will appear. Touch the Mute icon to unmute the active call.



Touch the Transfer Call icon to transfer the active call to the paired cell phone for a private conversation.

Quick Tip - A noisy environment may prevent the voice recognition system from understanding your commands. It is recommended that you reduce background noise (including passenger conversation and wind noise) prior to using the Voice Recognition system.

Quick Tip - Speak clearly and at a moderate speed after the beep sound has played.

ADDITIONAL NAVIGATION FEATURES

SEARCH AREA



Prior to inputting the desired address select the appropriate Search Area by pressing [Change]. If the incorrect Search Area is chosen, the system will either find an address that closely matches in that area or will indicate that the address cannot be found.




Select the appropriate Search Area, then touch OK to confirm the selection.

ROUTE PREFERENCES



Once the address has been inputted, select the desired route preference(s) for the trip. For example, if Allow Toll Roads is not selected, the system will route over non-toll roads which may take longer to reach the destination.

3 ROUTES




One of the three routes may be chosen for the trip. Quick 1 offers the shortest route by time; Quick 2 is the second fastest route. Short is the most direct route based upon driven mileage.

* The system does not account for traffic signals or traffic flow.

SCREEN PREFERENCES




Touch [] to select from seven different screen viewing options. Three screen preferences are available when the map is visible and four additional are available during route guidance only. Please refer to the list of screen preferences located below.



Single Map Mode



*Arrow Guidance Mode



Dual Map Mode



*Freeway Exit Info Mode




Compass Mode



*Intersection Guidance Mode



Turn List Mode



* Selections available when in guidance mode.

ADDITIONAL NAVIGATION FEATURES

BEEP SETTING



PRESS INFO > BEEP OFF

Switch off the confirmation tone by touching at the top of the screen. When the yellow bar appears this feature has been disabled.

VOLUME SETTING



PRESS MENU > VOLUME

The Volume feature allows for the adjustment of the voice guidance commands. Touch the desired volume level and touch OK to confirm your selection.

KEYBOARD SETTING



PRESS MENU > SETUP

Set the layout of the keyboard as alphabetical or standard QWERTY keyboard. Touch OK to confirm your selection.

SCREEN TRANSITION



PRESS INFO > SCREEN SETTING

Touch OFF to prevent the system from reverting to the map display. Once the screen transition is switched off, the audio or climate control screen (if equipped) will remain without reverting to the map display. Touch OK to confirm your selection.

FREEWAY EXIT INFO MODE

During Route Guidance on a Freeway or Toll Road, a variety of points of interest such as Gas Stations, Restaurants or Hotels can be viewed during your trip.

To access this feature, select Freeway Exit Info Mode from the Screen Preferences. Upcoming freeway exits will be listed by the number or name along with the POIs in the vicinity of the exit ramp. Select the desired exit from the list to see the POIs at that particular exit.



* This feature is only available while in Route Guidance and travelling on a freeway or Toll Road.

ADDITIONAL NAVIGATION FEATURES

ESTIMATED DISTANCE AND TIME*

The navigation system will provide an estimate of the distance and time to the destination based upon the suggested route during guidance. The system automatically calculates the remaining miles until you arrive at the destination. Based upon the distance traveled, the system will also provide an estimated time until arriving at your destination.

The system can be customized to match your driving habits. To adjust the speed for residential, main streets or freeways please refer to the Navigation Owner's Manual for a complete description of this feature.



* The system does not account for traffic signals or traffic flow.

OPERATION OF YOUR VEHICLE EMERGENCY SCREEN:



Press the DEST button on the navigation face plate. Touch  which will provide four different choices: • Police Stn. • Hospital • Dealer • Fire Stn. Touch to select the desired destination.



Once selected, the system will provide a list of locations sorted by distance. If the vehicle is in motion, the system will route you to the nearest location automatically.