

TV-IP400 TV-IP400W

Quick Installation Guide

Version 09.08.05



TRENDnet[®]
TRENDware, USA
What's Next in Networking

Table of Contents

English	1
1. Prepare for Installation	1
2. Install Hardware	2
3. Configure the Internet Camera	3
4. Using the Internet Camera Wirelessly (TV-IP400W only)	5
Troubleshooting	7

English QIG

1. Prepare for Installation

Thank you for purchasing the TV-IP400/TV-IP400W. This Internet Camera will allow you to view live images from internal and external networks.

This guide will help you set up and configure your Internet Camera. Following the installation instructions should be quick and easy. If you run into problems, please refer to the Troubleshooting section or the more detailed installation procedures on the CD User's Guide. If you need further technical support, please visit www.trendnet.com or call our technical support department by phone.

Verify Package Contents

Please make sure you have everything in the box:



System Requirement

1. 10/100Mbps Ethernet
2. CD-ROM Drive
3. CPU: Intel Pentium III 450MHz or above
4. Memory: 128MB or above
5. Web Browser: Microsoft Internet Explorer 5.0 or above, Netscape Navigator 6.0 or above
6. VGA Resolution: 800 x 600 or above

2. Install Hardware

1. Place the camera on a flat, level surface.
2. Connect the RJ-45 network cable to the Internet Camera then connect the other end of the network cable to a switch or hub.
3. Connect the power adapter to the Internet Camera. Make sure use the power adapter supplied with the Internet Camera.

Note: Using a different power adapter may damage the unit.

TV-IP400




TV-IP400W




3. Configure the Internet Camera

1. Open Internet Browser Window and enter **<http://192.168.0.20>** (camera's default IP address)




Note: The PC's IP (Example 192.168.0.50) address must correspond with the Internet Camera's IP address (Default IP: 192.168.0.20) in the same segment for the two devices to communicate.

2. Click on **System Administration** to access the configuration page.




3. Click **Configuration** and click **Network**. Enter an IP address, Subnet mask, and Default gateway that corresponds with your existing network. Then click the **Save** button to keep the changes




Note: If you need to access the configuration remotely, it is recommended to enter a static IP address and the Internet DNS IP address.

4. Using the Internet Camera Wirelessly (TV-IP400W only)


1. Click **Configuration** and click **Wireless**.



2. From the pull-down menu, select the **SSID** that matches your wireless access point and set **Connection Mode** to **Infrastructure**.



3. Scroll down to the bottom of the page and Click **Save**.



4. Disconnect the CAT5 cable and the power adapter connector from the TV-IP400W.



5. Reconnect the power adapter connector to the TV-IP400W. Allow 5-10 seconds for the TV-IP400W and the wireless Access Point to communicate wirelessly. Then type the **IP Address** that you assigned to the TV-IP400W in your web browser for verification.

Troubleshooting

Q1. The image is blurry, how do I fix this?

A1. You can adjust the Internet Camera's focus by rotating the lens.


Q2. How do I view the Internet Camera's live images within my Local Network?

A2. Open a web browser (Internet Explorer or Netscape), type your Wireless Internet Camera's IP address (i.e.: 192.168.0.20) in the Address bar, and then hit the **Enter** key. The Welcome page of the Internet Camera will appear.


Q3. When I enter the IP address of the camera, the image does not load, why?

A3. Please make sure all the Active X features are enabled for your Internet Explorer.

1. Go to **Tool (on the Tool bar) → Internet options → Security**



2. Click on **Custom Level** and make sure all ActiveX controls are set to **"Enable"** and click **OK**.




3. Once you save the settings, the browser will load again and the image should appear.

Q5. How do I configure my computer's IP address?

A5. For Windows 2000/XP users:

- On the Desktop, right click on **My Network Places** → select **Properties**
→ right click on the **Local Area Connection** → select **Properties**,
the Local Area Connection Properties Window will appear
- Under **General** tab, select **Internet Protocol (TCP/IP)** → click on
Properties button, Internet Protocol (TCP/IP) Properties Window will
appear


1. Select Use the following IP address option and enter the IP, Subnet Mask and Default gateway addresses.
2. Click OK to complete



For Windows 98/ME users:

- On the Desktop, right click on **Network Neighborhood** → select **Properties** → right click on the **Local Area Connection** → select **Properties**, the Local Area Connection Properties Window will appear
- Under **Configuration** tab, select your **Network Adapter (TCP/IP protocol)** → click on **Properties** button, TCP/IP Protocol Properties Window will appear

1. Select **Specify an IP address** option and enter the IP, Subnet Mask addresses.



For detailed information about the TV-IP400/TV-IP400W's configuration and advanced settings, please refer to the User's Guide on the included CD-ROM or to www.TRENDnet.com.

Certifications

This equipment has been tested and found to comply with FCC and CE Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received.
Including interference that may cause undesired operation.



NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.



What's Next in Networking

Product Warranty Registration

Please take a moment to register your product online.
Go to TRENDware's website at <http://www.TRENDNET.com>

TRENDnet Technical Support

US/Canada Support Center

Contact

Telephone: 1(310) 626-6252

Fax: 1(310) 626-6267

Email: support@trendnet.com

Tech Support Hours

7:30am - 6:00pm Pacific Standard Time
Monday - Friday

European Support Center

Contact**Telephone**

Deutsch : +49 (0) 6331 / 268-460

Français : +49 (0) 6331 / 268-461

0800-907-161 (numéro vert)

Español : +49 (0) 6331 / 268-462

English : +49 (0) 6331 / 268-463

Italiano : +49 (0) 6331 / 268-464

Dutch : +49 (0) 6331 / 268-465

Fax: +49 (0) 6331 / 268-466

Tech Support Hours

8:00am - 6:00pm Middle European Time
Monday - Friday

TRENDware International, Inc.

3135 Kashiwa Street. Torrance, CA 90505

<http://www.TRENDNET.com>