# Wireless Keypad User Guide



On each key press, the keypad will beep and the Green LED will blink. When a correct sequence is keyed in, the keypad will chirp and flash the green LED.

Arming or Disarming the Intruder monitoring feature				
To arm both zones 1 and 2, enter your 4 digit Security PIN and then press	Arm			
To arm Zone 1 only (partial arm), enter your 4 digit Security PIN and then press	Part Arm			
To disarm the feature, enter your 4 digit Security PIN and then press	Disarm			

#### Panic Alarm

To activate a Panic or Bogus caller alarm, press and hold the "SOS" button for 2 seconds.



## **Indicating Caregiver arrived**

To indicate Caregiver Arrived, the caregiver should enter the 4 digit caregiver PIN and then press



Assigning a new PIN A new keypad will have the following default PIN					
numbers:	Security PIN '0000'	Caregiver PIN '0000'			
Press 1 ther	new Security PIN, pre n enter your existing 4 nen release "S" after th	digit PIN. Enter a new	S		
Press 2 then	Caregiver PIN, press on enter the existing 4 denoted as the en release "S" after the	ligit PIN. Enter a new 4	S		

D4107132A © Tunstall

### Cleaning and maintenance

Dust the Keypad with a soft cloth which can be moistened with a gentle detergent if required. Ensure no moisture goes behind the keypad.

### **Battery Information**

Typical battery life is 5 years. Your keypad will self report a low battery condition to your monitoring service.

The replacement battery type is a 3 volt Lithium battery, number CR123A. The battery and fitting instructions can be obtained from your monitoring service.

#### **FCC Notice**

Wireless Keypad (Part Number 41004/26)

FCCID: G2X-4100426

This device complies with Part 15 of the FCC Rules Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Supplier Contact:			

D4107132A © Tunstall