

FCC Regulations:

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesirable operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Warranty:

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase and a Return Authorization are required.

Call toll free: **877-579-0469** for more information about our products and services.

An installation video is available online here:
www.ultimateairfreshener.com/installation.html

**2193 Kirkwood Avenue
Naples, FL 34112**

www.ultimateairfreshener.com



User's Manual

Ultimate Air Freshener System

Model: 2011711GTR

INSTALLATION INSTRUCTIONS

RESERVOIR: Fix fluid container in vertical position to an appropriate space either in engine room, driver's cabin, trunk, or cargo area, any place where convenient for supplying air freshener fluid. Using metal mounting bracket, mark location and drill two 5/32" (4mm) diameter holes (It is recommended to use a smaller drill first and then enlarge them to size. Fasten with two sheet metal screws and secure tightly. (Note: if you are using fine thread screws with nuts then enlarge both holes to 1/4" (7mm)). Place fluid container on metal bracket.

NOZZLE: Your air handler unit box will always be located on the passenger side underneath the dash. Select an appropriate location for the nozzle between the blower motor and the evaporator (Hint: the blower motor is always on the right side of the air handler box). In some cases your vehicle might have a cabin filter, if this is your case then you want to place the nozzle in between the cabin filter and the evaporator. When you have found a location mark and drill a hole size 11/32 (8.5mm) (in some cases due to the type of construction you might need to enlarge the hole to 23/64" (9mm) at an angle pointing to the evaporator).

CAUTION RUN DRILL SLOWLY AS IT WILL TRY TO PULL ONCE IT BRAKES THRU THE PLASTIC!

Run the clear tubing through an appropriate location hidden and plug into the nozzle. (Note: Make sure hose is not bent or pinched.)

RECEIVER BOX: Place receiver in a desired location. (Preferably close to the reservoir container) Using the plastic crimp caps, connect the blue wire from the receiver to the red wire provided with the unit and crimp cap tightly. Cut red wire lead to a length that will reach the pump attached to the reservoir container. Connect the end to the red wire on the pig tail provided and crimp cap tightly. Connect the two red wires on the receiver to the red wire provided and cut to length reaching the battery of the vehicle and crimp cap tightly. The end of the red lead connect it to the fuse holder and crimp cap tightly. Connect the fuse wire to the ring terminal and fasten to the positive battery terminal.

Connect the black wire on the receiver to the black wire provided and cut to length reaching the negative on the battery. Connect the black wire on the pig tail from the pump to the black wire provided and cut to length reaching back to the battery. Connect the black wire from the pump and the black wire from the receiver to the ring terminal and fasten to the negative of the battery. (Make sure your wires are away from any sharp edges and keep away from direct contact with engine) (Note: Connect the pigtail to the pump on the reservoir container)

FLUID AROMA: Remove the white cap from the reservoir container and fill with Ultimate Air Freshener scented aromas. (Note: Make sure that you use only Ultimate Air Freshener's products in this unit, as other products could cause harm to the unit and is not recommended due to certain chemicals.

AIR FRESHENER OPERATION

While car's vent is on, briefly press green button on air freshener's remote to dispense fluid when fragrance is desired. Do not press green button on remote more than 4 seconds as the scent could become too strong, and fluid would be wasted. Our aromas are very efficient and will extend your refill duration.

