



How to Use

Step1

Push forward the switch locks on both sides of handle to the head to open the handle.




Lock Postion




Release button Up

UnLock Postion




Step2

Push backward the switch lock to release the device from handle.



Step3


Push forward the switch lock buttons on handle to fixed device.



LED Status

Discharging

Red light blinking	0%~5% power
Yellow light solid	6%~25% power
Green light solid	26%~75% power
Green light solid	≥ 75% power



Press 2 times	Device Charging
---------------	-----------------

Long press for 3s	Stop Charging
-------------------	---------------

Charging

Discharging

Red light blinking	0%~5% power
Yellow light blinking	6%~25% power
Green light blinking	26%~75% power
Green light blinking	≥ 75% power
Green light solid	Charge complete

Please use direct charging

Gun Grip with adapter

Precautions

1. Read all information in this guide before using the device to ensure safe and proper operation.
2. Please use the accessories that have been approved by Urovo and corresponds to this model. Use of any power source, charger, battery, etc. that has not been approved by Urovo may cause a fire, explosion, or other hazards.
3. Please use device and accessories within the specified temperature range. Equipment failure may occur when the ambient temperature is too high or too low.
4. Do not disassemble the product and its accessories. If the equipment or any of its components are not working properly,
5. The battery is made from a flammable and explosive material. Do not disassemble, squeeze, drop and make any other destructive operations on the battery. Do not place the battery in high temperatures.
6. Disposal of used batteries is subject to local relevant documents or policies regarding disposal of used batteries.

Warranty Policy

Thank you for using Urovo smart terminal series products. In the situation of quality problems, which arise from raw materials or production processes, during normal use of purchased products, UROVO TECHNOLOGY LTD. will be responsible for free maintenance within one year from the date of purchase. The company may provide repairs due to the user's failure to use the product according to the provided instructions of the product. However, corresponding service fee and component fee will be charged.

Warranty Terms:

1. Under normal circumstances, the warranty period of the device is 12 months (3 months for accessories), subject to the sales agreement.
2. During the product warranty period, under the normal use conditions (determined by our technical staff), the user will be entitled to a free warranty for damaged or faulty warranty parts.
3. During the warranty period, faults caused by repair, disassembly or modification of the product by a personnel other than our company, improper installation, improper use by the user (failure to follow instructions), serial number damage, accident or natural disaster, will not be covered under the warranty.
4. The warranty will expire immediately if any alterations are made to the warranty card.
5. Please show the equipment SN and purchase certificate for repair. The company reserves the right to interpret the above contents.

Place of Origin: Shenzhen Quality Inspector: 02

UROVO TECHNOLOGY LTD.
Website: en.urovo.com

