


EXHIBIT E
SYSTEM MANUAL

**BRINKS HOME SECURITY
BHS-FOB
Instruction Sheet**



The BHS-FOB is a convenient & effective method for you to turn your Brink's Home Security Alarm System ON, OFF and ON with Motions Off for protection while you are inside your home.

SYSTEM ON: To turn your system ON, press the RED Button.

SYSTEM ON with Motion OFF: To turn your system ON but with the Motion Detector(s) off, press the RED & BLACK Button.

The status LED will illuminate when the battery is good and a button is being pressed.

The status LED will blink when the battery is low and a button is being pressed.

SYSTEM OFF: To turn your system OFF, press the BLACK Button.

PANIC (or MEDICAL) ALARM: Press the RED along with the RED & BLACK Buttons simultaneously (laying the edge of your finger or thumb in the groove that runs between these two buttons, is generally effective) to trigger your Brink's Security System Panic Alarm (or Medical Alarm). Check with your Brink's Installer to see which (if either) of those two alarms are installed as part of your system.

CONSUMER INFORMATION (FCC Notice):

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15, Subpart C of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if installed and used in accordance with the instructions, is designed to provide reasonable protection against harmful interference in a residential installation. There is, however, no guarantee that interference will not occur in a particular installation. If interference generated by this unit is suspected, call Brink's Customer Service at 1-800-445-0872. If it is found that this equipment does cause unacceptable interference to radio or television reception, the user is encouraged to try to correct the interference by one or more of the following measures:

- ◇ Reorient or relocate the receiving antenna.
- ◇ Move the television or radio away from the unit.
- ◇ If necessary, contact Brink's Home Security or an experienced TV/Radio technician for additional suggestions.