



UniFi® | SWITCH L2 **PoE**

Managed L2 Gigabit PoE+
Switch with SFP

Models: US-L2-24-POE, US-L2-48-POE

QUICK START GUIDE

Introduction

Thank you for purchasing the Ubiquiti Networks® UniFi® Switch. This Quick Start Guide is designed to guide you through the installation and also includes the warranty terms.

Package Contents



OR



US-L2-24-POE

US-L2-48-POE



Power Cord



Mounting Brackets
(Qty. 2)



Bracket Screws
(Qty. 8)



Mounting
Screws (Qty. 4)



Cage Nuts
(Qty. 4)



Rubber Feet
(Qty. 4)



UniFi Elite Card



Quick Start
Guide

System Requirements

- Linux, Mac OS X, or Microsoft Windows 7/8/10
- Java Runtime Environment 1.6 (1.8 or newer recommended)
- Web Browser: Google Chrome (Other browsers may have limited functionality)
- UniFi Controller software v5.4.x or above, available at: downloads.ubnt.com/unifi

! **IMPORTANT:** We strongly recommend using UPS backup and power regulation to prevent equipment damage due to stability issues with local AC power.

TERMS OF USE: All Ethernet cabling runs must use CAT6. It is the customer's responsibility to follow local country regulations and indoor cabling requirements.