

User Manual

**Bluetooth Buddy Wireless Speaker**  
*User's Guide for Model ISB385*



**FCC Warnings**

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Additional Warnings and Precautions**

- **WARNING:** Lithium batteries, like all rechargeable batteries, are recyclable and should be recycled or disposed of in normal household waste. Contact your local government for disposal or recycling practices in your area. They should never be incinerated since they might explode.
- **AVIS:** Les piles Lithium ion, comme toutes les autres piles rechargeables, sont recyclables et doivent être étiquetées avec vos déchets ménagers. Contactez votre municipalité pour obtenir des conseils sur les moyens de disposition et de recyclage dans votre région. N'incinerez pas vos piles, car celles-ci peuvent exploser.
- Battery shall not be exposed to excessive heat such as sunshine, fire or the like.
- **Les piles ne doivent pas être exposées à de forte chaleur, tel qu'à la lumière du soleil, au feu ou autres choses de semblable.**
- Batteries should be recycled or disposed of as per state and local guidelines.
- **Piles doivent être recyclées ou éliminées selon les directives éditoriales et locales.**

- **THIS PRODUCT CONTAINS SENSITIVE ELECTRONIC COMPONENTS, AND SHOULD NOT BE HANDLED AS A TOY.**
- **MACHINE WASHING IS NOT RECOMMENDED FOR THIS PRODUCT.**

**FEATURES & CONTROLS**

**FEATURES**


- Motorized mouth sings along to music
- Supports Bluetooth and automatic device reconnecting
- Wireless range: 33 ft.
- Built-in microphone for hands free speakerphone operation

- Aux In (3.5 mm audio input)
- Micro-USB port for battery recharge
- AC/DC power adapter (included)
- Built-in rechargeable lithium ion battery
- Battery life: approx. 4 hours at 50% volume

**Includes**

- Micro-USB to USB charging cable
- AC/DC Power adapter
- 3.5mm Audio Input cable

**Front View**




## POWER & CHARGING

Requires a Micro-USB to USB cable (included).


When the unit is charging, the **LED indicator** on the front of the unit **will display solid red**. When the unit is fully charged, the **LED indicator will turn off**.

1. Using a Micro-USB to USB cable (included), connect the larger **USB plug** to the **USB port** of a powered on computer or USB power adaptor (included).
2. Connect the smaller **Micro-USB plug** into the **Micro-USB port** of the unit. The unit will now charge.

**Note:** Be sure the computer is not in sleep mode.



Use AC/DC Power Adapter to Charge



Use PC to Charge

## BLUETOOTH

### Pairing to a Device and Playing Audio

1. Power on the unit by sliding the **Power Switch** on the rear to the **ON** position.
2. This unit's default mode after being powered on is **Bluetooth Mode**. This is indicated by a **flashing blue LED light** on the front of the unit.
3. Press and hold the **Pair** button. The **blue LED light** will begin to flash quickly. When pairing, remain within 3 feet of the unit.
4. Using the controls on your Bluetooth device, scan for and select **ISB385** in your Bluetooth settings to pair. If your device requests a password, enter the default password **0000**. Refer to the user's manual for your specific device for instructions on pairing and connecting Bluetooth devices.
5. When successfully paired, the **blue LED light** will turn solid.
6. Use the controls on the connected device or the unit to select and play audio, and adjust the volume.
7. Audio played through the connected Bluetooth device will now be heard through the speaker.


After initial pairing, the unit will stay paired unless unpaired manually by the user or erased due to a reset of the device. If your device should become unpaired or you find it is unable to connect, repeat the above steps.

## AUX IN

### Using Aux In (3.5mm Audio Input)

Requires a 3.5mm audio cable (included).

1. Connect a 3.5mm audio cable to the **Aux In Input** on the rear of the unit and the **audio output/headphone jack** on a media player.
2. The unit will automatically detect the input and switch to **Aux In Mode**. This is indicated by a **solid blue LED light** on the front of the unit.
3. Use the controls on the connected device or the unit to select and play audio, and adjust the volume.



## INTERNATIONAL SUPPORT

To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at: [www.iLiveElectronics.com](http://www.iLiveElectronics.com)

Para descargar este Manual del Usuario en inglés, español y francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en: [www.iLiveElectronics.com](http://www.iLiveElectronics.com)

Pour télécharger ce guide de l'utilisateur en anglais, espagnol ou français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur: [www.iLiveElectronics.com](http://www.iLiveElectronics.com)

For Warranty Information and the most up-to-date version of this User's Guide, go to [www.iLiveElectronics.com](http://www.iLiveElectronics.com)

**Customer Service:** 1-888-999-4215 | **Email Support:** [prodinfo@dpiinc.com](mailto:prodinfo@dpiinc.com) | **Email Parts:** [partsinfo@dpiinc.com](mailto:partsinfo@dpiinc.com)

Copyright © 2015 Digital Products International (DPI, Inc.). All other trademarks appearing herein are the property of their respective owners. Specifications are subject to change without notice.

