WRIST BLOOD PRESSURE MONITOR Model: U60GH



Instruction manual

Table of Contents

| Introduction 3 |
|---------------------------|
| Safety Information 4 |
| Product Structure9 |
| Each of component10 |
| Battery installation 11 |
| Setting mode13 |
| Proper use of the unit 16 |
| About blood pressure22 |
| Exceptional situations 25 |
| Care and maintenance27 |
| Specification 30 |
| Warranty information 32 |
| EMC Declaration 34 |
| FCC Compliance41 |

Introduction

Thank you for purchasing the Wrist Blood Pressure Monitor. Please read the manual carefully before you use the unit, and keep the manual well after using.

The unit is compact and easy to use, adopts the oscillometric principle. It measures your blood pressure and pulse rate simply and quickly. The device uses its advanced "Intellisense" for comfortable controlled inflation without the need of pressure presetting or reinflation. This unit is only applied for the adult.

2x90 sets memory function, each measurement result will be displayed on the screen, and automatically stored .This unit has blood classification index, could easy to check your blood pressure.

■ To assure the correct use of the product, basic safety measures should always be followed including the warning and the caution listed in the instruction manual:

Symbol descriptions

The following symbols may appear in this manual, on the label, on the device, or on it's accessories. Some of the symbols represent standards and compliances associated with the device and its use.

MARNING: This alert identifies hazards that may cause serious personal injury or death.

▲ CAUTION: This alert identifies hazards that may cause minor personal injury, product damage, or property damage.



Type B applied part

Manufacturer

SN Specifies serial number



Authorized Representative in the European Community



CE Mark: conforms to essential requirements of the Medical Device Directive 93/42/FFC



<u>DISPOSAL:</u> Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.



Is one of the executive agencies established by the U.S. government in the health and Human Services Department (DHHS) and the Ministry of public health (PHS).

=== Direct current



Operating instructions



Follow instructions for use



CAUTION: Consult accompanying documents

⚠ Those who have arrhythmia, diabetes, blood circulation or apoplexy problem, please use under the physician's instruction.

⚠ Contact your physician for specific information about your blood pressure. Self diagnosis and treatment which use measured results may be dangerous. Follow the instructions of your physician or licensed healthcare provider.

⚠ Please place on a high place where children can't be touched.

A No modification of this equipment is allowed.

⚠ Do not modify this equipment without authorization of the

⚠ If this equipment is modified, appropriate inspection and testing must be conducted to ensure continued safe use of equipment.

⚠ The swallowing of small part like packaging bag, battery, battery cover and so on may cause the suffocation.

A Please don't use a dilution agent, alcohol or petrol to clean the unit. Please don't hit heavily or fall down the product from a high place. Use the right cuff, otherwise it can not work.

Mever leave any low battery in the battery compartment since they may leak and cause damage to the unit.

⚠ Please take off the battery if you won't use in 3 months.

A Replace the new batteries if the unit display a low battery symbol.

Do not mix the old and new batteries.

⚠ Do not use a cellular phone near the unit. It may result in operational failure.

⚠ Do not use the equipment where flammable gas (such as anesthetic gas, oxygen or hydrogen) or flammable liquid (such as alcohol) are present.



▲ WARNING:

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact you local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

Classification


- Internally powered equipment;
- 2. Type B applied part;
- 3. Protection against ingress of water: IPX0;
- 4. Not category AP / APG equipment;
- 5. Mode of operation: Continuous operation;

⚠The user must check that the equipment functions safely and see that it is in proper working condition before being used.


Product structure



Note: the cuff is treated as the applied part.



Each of Component



Instruction

Please read the warranty information in the end of the manual carefully.

Battery installation

■Battery installation and replacement

1. Push the hook on the bottom of the battery cover as picture.



2. Insert two 1. 5V "AAA" batteries in the battery compartment.

♠ Place the batteries "+" and "-"in the right position as indicated.



Battery installation

Pull the battery cover to the main unit.

★ When the battery cover close tightly, could hear "Ka-ka".



Low battery and replacement

When power on, the low battery symbol — will display once the unit start to work, and you must replace with new batteries, otherwise the unit can't work.

Please use 2pcs AAA identical 1.5V alkaline batteries.

Do not use the batteries beyond their expiry date.

Please remove the batteries if you do not need to use for long time.

▲ WARNING:

Dispose of the battery in accordance with all federal, state and local laws. To avoid fire and explosion hazard, do not burn or incinerate the battery.

Setting mode

■How to set----

1. How to set user:

Long press button MEM when power off, the screen will display $\hat{\mathbf{m}}$ or $\hat{\mathbf{m}}$, press button START/STOP, it will be changed between $\hat{\mathbf{m}}$ and $\hat{\mathbf{m}}$, press button MEM when you



confirm the user, then it will enter into the year setting mode.

2.Year setting:

Continue to above step, the screen will display and flash 20XX, the last digit of the year will increase 1 when press button START/STOP each time, you could choose from 2001 to 2099. Press button MEM when you confirm the year, then it will enter into the month and date setting mode.



Year setting

Setting mode

3.Month and date setting

Continue to above step, the screen will display MONTH-DAY and XX-xx, and keep flashing on month , the digit will increase 1 when press button START/STOP each time, you could choose from 1 to 12. Press button MEM when you confirm the month, then it will set the date. Same as the month setting , each time you press button START/STOP, the digit will keep changing from 01 to 31. Press button MEM when you confirm the date, then it will enter into the time setting mode.



Month setting



Date setting

Setting mode

4.Time setting:

Continue to above step, the screen will display TIME and XX: XX, and keep flashing on the digits of hour, the digit will increase 1 when press button START/STOP each time, you could choose from 0 to 23. Press button MEM when you confirm the hour, then the digits of minute start to flash, same as the hour setting, each time you press button START/STOP the digits will keep changing from 00 to 59. Press button MEM when you confirm the minute, then the total setting mode is completed.



hour setting



minute setting

Pre-measurement

Before the measurement

- ●Please keep quiet for 5–10 minutes, and avoid eating, drinking alcohol, smoking, exercising and bathing before taking measurement. All these factors will influence the measurement result.
- Remove watch or other ornaments from the measured wrist.

- •Always measure on the same wrist(normally left).
- •Take measurement regularly at the same time of every day, as blood pressure changes even during the day.
- ■Common factors of wrong measurement
- •Please measure under the same circumstance if compare the blood pressure by different way, especially measure in a quiet environment
- •Make sure you are in a comfortable, relax position and do not activate any of the muscles in the measurement arm during the measurement.
- If put the wrist lower or higher than the heart, a false reading will be obtained.

Note:


- •A loose cuff or a exposed bladder causes false reading.
- •With repeated measurements, blood accumulates in the wrist which can lead to false reading. Consecutive blood pressure measurements should be repeated after 1 minute pause or after the arm has been held up in order to allow the accumulated blood to flow away.

Fitting the cuff

- Roll up sleeve. Make sure your sleeve is not rolled up too tightly on your arm. This may constrict the flow of blood in your arm.
- Wrap the cuff directly against your skin,hold the bottom part of the cuff and wrap it around the wrist so it fits comfortably and securely around your wrist as picture show.







If it is not possible to fit the cuff to your left wrist, it can also be placed on the right. However, all measurements should be made using the same wrist.

Measuring procedure

 Press the START/STOP button, all symbols appear on the display, then 0 flash for 2 seconds, the pump begins to inflate the cuff, the rising pressure in the cuff is shown on the display.



 After the suitable pressure has been reached, the pump stops and the pressure gradually falls. The cuff pressure is displayed. In case that the inflation is not sufficient, the device automatically re-inflates to a higher pressure.



- 3). When the device detects a pulse, the heart symbol ♥ on the display starts to flash.
- 4). When the measurement has been completed, the systolic, diastolic and pulse rate will appear on the display.
- 5). The measurement readings remain on the display until you switch off the device. If no button is pressed for a period of 3 minutes, the device switches off itself in order to save the power.



Note: The symbol ** will be displayed along with the reading if the irregular heartbeat is detected during the measurement.

Discontinuing a measurement

If it is necessary to interrup a blood pressure measurement for any reason (eg. the patient feels unwell) the START/STOP button can be pressed at any time. The device immediately decrease the cuff pressure automatically.

Memory-recall of measurements

This blood pressure monitor automatically stores 2x90 sets measurements value, the oldest record will be replaced by the latest measurement value when more than 90 sets each user.

■Read memory record

Press the MEM button when power off, all symbols appear on the display, then the latest 3 times average value will be shown, press the MEM button again, the last measurement value will be shown, as well as subsequent measurements can be shown one after the other by pressing the MEM button each time.









■Memory -clear of measurements

If you are sure that you want to permanently remove all stored memories. Long press the MEM button to enter into setting mode when power off, press the MEM button for 6 times until CL appears, press the START/STOP button, CL will flash for 3 times to clear all the memories. After this press the MEM button again, M and "no" will be shown on the display which mean that no memory in store.




About blood pressure

■About blood pressure

■Blood pressure is the pressure exerted the arteries.


The systolic blood pressure value represents the blood pressure produced by contraction of the heart muscle.

The diastolic blood pressure value represents the blood pressure produced by relaxation of the heart muscle.




About blood pressure

- ■According to the blood pressure classification by the WHO/ISH.
- SYS lower than 100mmHg (13. 3kPa) is considered as hypotension.



About blood pressure

■Blood pressure type



Exceptional Situation

Error indicators

The following symbol will appear on the display when measuring abnormal.

| Symbol | Cause | Correction | |
|--------------------------|---|--|--|
| E-1 | Weak signal or pressure change | Wrap the cuff properly. | |
| L - ' | suddenly | Remeasure with correct way. | |
| E-2 | External strong | When near cell phone or other high radiant device, the measurement will be failed. | |
| distarbance | | Keep quite and no chatting when measure. | |
| | It appears error during the | Wrap the cuff properly. | |
| F-3 process of inflating | | Remeasure. | |
| E-5 | E-5 Abnormal blood pressure Repeat the measurement after relax for if get unusual readings for 3 times, ple contact you doctor. | | |
| | Low battery | Replace all the worn batteries with new ones. | |

Exceptional Situation

■Trouble removal

| Problem | Check | Cause and solutions | |
|--------------|-------------------------------------|---|--|
| | Check the battery power | Replace new one | |
| No power | Check the polarity position | Installation for proper placement of the batteries polarities | |
| Err and stop | Whether move the wrist when inflate | Keep the wrist and body peaceful | |
| working | Check if chatting when measured | Keep quite when measure | |
| Cuff leak | Whether the cuff wrap too loose | Wrap the cuff tightly | |
| | | | |

Care

Care for the main unit and blood pressure monitor cuff

- Keep the unit in the storage case when no use.
- Clean the unit with soft dry cloth. Do not use any abrasive or volatile cleaners.
- Never immerse the unit or any component in water.



*We won't be responsible for any quality problem if you don't care and maintain the product as instructed.

Care

- Make sure the monitor is off prior to cleaning, a mixture of distilled water and 10 percent bleach could be used.
- Using a spray bottle, moisten a soft cloth towel with the bleach or detergent mix until it is fully saturated.
 Squeeze any excess moisture from the cloth to avoid any dripping or potential oversaturation of the cuff.
- •Wipe all surfaces of the blood pressure monitor cuff thoroughly, making sure to clean the inside and outside of the cuff. Be cautious not to get any moisture in the main unit.
- Using a dry cloth, gently wipe away any excess moisture that may remain on the blood pressure cuff.
 Lay the cuff flat in an unrolled position and allow the cuff to air dry.



Maintenance

• Do not clean the body and cuff with naphtha, thinner or gasoline etc.

 Do not wet the cuff or attempt to clean the cuff with water.



• Store the unit in a clean and dry location .

Do not subject the unit to extreme hot or cold temperature, humidity and direct sunlight.



• Remove the batteries if the unit will not be used in 3 months or longer.





★We won't be responsible for any quality problem if you don't care and maintain the product as instructed.

Specification

| Description | Automatic wrist blood pressure monitor | | |
|---------------------------|--|------------------------------|--|
| Display | LCD digital display | | |
| Measuring principle | Oscillometric method | | |
| Measuring localization | Wrist | | |
| Measurement | Pressure | 0~299 mmHg (0~39.9kPa) | |
| range | Pulse | 40∼199 pulses/min | |
| Acquirecy | Pressure | ±3mmHg (±0.4kPa) | |
| Accuracy | Pulse | ±5% of reading | |
| | Pressure | 3 digits display of mmHg | |
| LCD indication | Pulse | 3 digits display | |
| maleation | Symbol | Memory/Heartbeat/Low battery | |

Specification

| Memory function | 2x90 sets memory of measurement values | | |
|------------------------|---|-------------------|--|
| Power source | 2pcs AAA alkaline battery DC. 3V | | |
| Automatic power off | In 3 minutes | | |
| Main unit weight | Approx. 96g (batter | ies not included) | |
| Main unit size | L69.5mm x W66.5n | nm x H60.5 mm | |
| Main unit lifetime | 10,000 times under normal use | | |
| Battery life | Could be used for 300 times for normal condition | | |
| Accessories | Instruction manual , storage box | | |
| | Temperature | 5~40°C | |
| Operating | Humidity | 15%~85%RH | |
| environment | Air pressure | 86kPa~106kPa | |
| Storage environment | Temperature ~20°C ~55°C . Humidity :10% ~85% avoid crash, sun burn or rain during transportation. | | |

Warranty information

Statement

- The intended use: the unit is intended to be used by adults at home or medical center to measure blood pressure and pulse rate from the wrist
- The unit satisfies the requirements of EN 1060-1:1995+A2:2009 Non-invasive sphygmomanometers, EN 1060-3:1997+A2:2009 Non-invasive sphygmomanometers.
- Blood pressure measurements determined with this device are equivalent to those obtained by a trained observer using the cuff/stethoscope auscultatory method, within the limits prescribed by the American National Standard, manual, electronic, or automated sphygmomanometers.
- The risk of patient and user can be lowered to acceptable level.

Warranty information

Warranty Information

- The unit is guaranteed to be free of defects in workmanship and materials under normal use for a period of Two Years from the date listed on the purchase record.
- For repair under this warranty. Our authorized service agent must be advised of the fault with the period of the warranty. This warranty covers parts and labor only under normal operations. Any defect resulting from natural causes, eg. flood, hurricane etc, is not within this guarantee. This guaranty does not cover damage incurred By use of the unit not in accordance with the instructions, accidental damage, or being tampered with or serviced by unauthorized service agents.
- Monitor subjected to misuse, abuse, and neglect of these manual content, non-instructional purposes; unauthorized repair or modifications will be excluded from this warranty.
- ⚠ The device requires no calibration.
- The device is not repairable and contains no user serviceable parts.

Guidance and manufacturer's declaration - electromagnetic immunity

The "blood pressure monitor" is intended for use in the electromagnetic environment specified below. The customer or the user of the "blood pressure monitor" should ensure that it is used in such an environment.

| Immunity test | IEC 60601 test level | Compliance level | Electromagnetic environment - guidance |
|---|--|--|---|
| Electrostatic discharge (ESD) IEC 61000-4-2 | ±6 kV contact ±8 kV air | ±6 kV contact ±8 kV air | Floors should be wood, concrete or ceramic tile. If floors are covered with synthetic material, the elative humidity should be at least 30 %. |
| Electrical fast transient/burst IEC 61000-4-4 | ±2 kV for power supply lines ±1 kV for input/output lines | ±2 kV for power supply lines ±1 kV for input/output lines | Mains power quality should be that of a typical commercial or hospital environment. |
| Surge IEC 61000-4-5 | ±1 kV differential mode ±2 kV common mode | ±1 kV differential mode ±2 kV common mode | Mains power quality should be that of a typical commercial or hospital environment. |

| Voltage dips, short interruptions and voltage variations on power supply input lines IEC 61000-4-11 | <5 % UT (>95 % dip in UT) for 0,5 cycle 40 % UT (60 % dip in UT) for 5 cycles 70 % UT (30 % dip in UT) for 25 cycles <5 % UT (>95 % dip in UT) for 5 sec | <5 % UT (>95 % dip in UT) for 0,5 cycle 40 % UT (60 % dip in UT) for 5 cycles 70 % UT (30 % dip in UT) for 25 cycles <5 % UT (>95 % dip in UT) for 5 sec | Mains power quality should be that of a typical commercial or hospital environment. If the user of the "blood pressure monitor" requires continued operation during power mains interruptions, it is recommended that the "blood pressure monitor" be powered from an uninterruptible power supply or a battery. | |
|---|---|--|--|--|
| Power frequency (50/60 Hz) magnetic field IEC 61000-4-8 | 3 A/m | 3 A/m | Power frequency magnetic fields should be at levels characteristic of a typical location in a typical commercial or hospital environment. | |
| NOTE UT is the a.c. mains voltage prior to application of the test level. | | | | |

35/41

| Immunity test | IEC 60601 test level | Compliance level | Electromagnetic environment - guidance |
|-------------------------------|--------------------------------|---------------------|---|
| | | | Portable and mobile RF communications equipment should be used no closer to any part of the "blood pressure monitor", including cables, than the recommended separation distance calculated from the equation applicable to the frequency of the transmitter. |
| Conducted RF IEC 61000-4-6 | 3 Vrms 150 kHz to 80 MHZ | 3 V | Recommended separation distance d=1.2 √P d=1.2 √P 80MHz to 800MHz d=2.3 √P 800MHz to 2.5 Ghz |
| Radiated RF IEC 61000-4-3 | 3 V/m 80 MHz to 2,5 Ghz | 3 V/m | where P is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer and d is the recommended separation distance in metres (m). Field strengths from fixed RF transmitters, as determined by an electromagnetic site survey.* should be less than the compliance level in each frequency range.* Interference may occur in the vicinity of equipment marked with the following symbol: |

NOTE 1 At 80 MHz and 800 MHz, the higher frequency range applies.

NOTE 2 These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects and people.

- a Field strengths from fixed transmitters, such as base stations for radio (cellular/cordless) telephones and land mobile radios, amateur radio, AM and FM radio broadcast and TV broadcast cannot be predicted theoretically with accuracy. To assess the electromagnetic environment due to fixed RF transmitters, an electromagnetic site survey should be considered. If the measured field strength in the location in which the "blood pressure monitor" is used exceeds the applicable RF compliance level above, the blood pressure monitor should be observed to verify normal operation. If abnormal performance is observed, additional measures may be necessary, such as reorienting or relocating the "blood pressure monitor".
- b Over the frequency range 150 kHz to 80 MHz, field strengths should be less than [V1] V/m.

Guidance and manufacturer's declaration - electromagnetic emissions

The "blood pressure monitor" is intended for use in the electromagnetic environment specified below. The customer or the user of the "blood pressure monitor" should ensure that it is used in such an environment.

| Emissions test | Compliance | Electromagnetic environment - guidance |
|---|------------|---|
| RF emissions CISPR 11 | Group 1 | The "blood pressure monitor" uses RF energy only for its internal function. Therefore, its RF emissions are very low and are not likely to cause any interference in nearby electronic equipment. |
| RF emissions CISPR 11 | Class B | The "blood pressure monitor" is suitable |
| Harmonic emissions IEC 61000-3-2 | Class A | for use in all establishments, including domestic establishments and those directly connected to the public low-voltage power |
| Voltage fluctuations/ flicker emissions IEC 61000-3-3 | Complies | supply network that supplies buildings used for domestic purposes. |

Recommended separation distances between portable and mobile RF communications equipment and the blood pressure monitor

The "blood pressure monitor" is intended for use in an electromagnetic environment in which radiated RF disturbances are controlled. The customer or the user of the blood pressure monitor can help prevent electromagnetic interference by maintaining a minimum distance between portable and mobile RF communications equipment (transmitters) and the "blood pressure monitor" as recommended below, according to the maximum output power of the communications equipment.

| | eparation distance according to frequency of transmitter m | | | |
|--|---|---|---|--|
| Rated maximum output power of transmitter W | 150 kHz to 80 MHZ $d = \left[\frac{3,5}{V_1}\right]\sqrt{P}$ | 80 MHz to 800 MHZ $d = \left[\frac{3.5}{E1}\right]\sqrt{P}$ | 800 MHz to 2,5 Ghz $d = \left[\frac{7}{E_1}\right]\sqrt{P}$ | |
| 0,01 | 0.12 | 0.12 | 0.23 | |
| 0,1 | 0.38 | 0.38 | 0.73 | |
| 1 | 1.2 | 1.2 | 2.3 | |
| 10 | 3.8 | 3.8 | 7.3 | |
| 100 | 12 | 12 | 23 | |

For transmitters rated at a maximum output power not listed above, the recommended separation distance d in meters (m) can be estimated using the equation applicable to the frequency of the transmitter, where P is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer.

NOTE 1 At 80 MHz and 800 MHz, the separation distance for the higher frequency range applies.

NOTE 2 These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects and people.

FCC Compliance

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WRIST BLOOD PRESSURE MONITOR

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. (Because the size of rating label is too small, we couldn't put the information of FCC Compliance on the rating label .So please kindly find the details on manual.)

Manufactured by Shenzhen Urion Technology Co., Ltd. for DynoSense Corp.100 Century Center Court, Suite 650 San Jose, CA 95112 www.dynosense.com

