

## SAFETY INSTRUCTIONS

- Do not immerse any part of this product in water.
- Plastic bags and small parts may cause choking if ingested. Keep them away from small children and pets.
- Avoid temperatures exceeding 140° F (will cause equipment failure).

## WARRANTY STATEMENT

(1) VXi warrants that your VXi BT1 Bluetooth USB dongle will be free from defects in material and workmanship for one year from the date of purchase. If, during the first year from the date of purchase, your VXi BT1 Bluetooth USB dongle fails to work due to a defect in material or workmanship, VXi will repair or replace the product, at its election, free of charge. Without proof of purchase, the warranty period begins on the date of manufacture. Consumable components (for example, cushions, battery and fuse) are not included in this one-year warranty. (2) The foregoing limited warranty does not cover equipment failure attributable to accident, improper operation, misuse, abuse, or any cause other than defects in the materials or workmanship of VXi's products. (3) VXi's obligations under this warranty are limited to repair or replacement (at our option) of any defective part returned to VXi at the customer's expense. Returned products require a Return Authorization that may be obtained by calling 603-742-8588 or visiting [www.vxicorp.com](http://www.vxicorp.com). Products returned to VXi for repair under this warranty will be return shipped to the customer at VXi's expense. (4) THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not permit the exclusion of implied warranties and the foregoing exclusions may not apply to you. (5) In no event shall VXi be responsible for any other damages whatsoever, including direct, indirect, special, incidental, consequential, or other damages for breach of this or any other warranty, expressed or implied.

## FCC NOTICE TO USERS

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Users are not permitted to make changes or modify the device in any way. Changes or modifications not approved by VXi Corporation will void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antennae.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



VXi CORPORATION  
271 Locust Street, Dover, NH 03820  
603-742-2888 Toll free 800-742-8588  
[www.vxicorp.com](http://www.vxicorp.com)

© 2013 VXi Corporation


PN 1X5-DAJ-V0.1 Printed in China

# BT1 Bluetooth Dongle

## USER GUIDE



## INSTALLATION



### Step #1

#### 1) Headset Pairing Mode:

Put the headset in to pairing mode (voice prompt 'Discovering'; should be heard in the headset).

#### 2) Insert The BT1 Into A USB Port On The Computer:

Plug the dongle into an available computer USB port.

#### 3) Pairing Mode:

The dongle will initialize and go into pairing mode while the computer loads the necessary driver.

#### 4) Headset Will Connect To The Dongle:

The headset should connect with the dongle either during the initialization process or shortly after.

#### 5) Headset Connected:

Once connected you should hear the voice prompt "Your headset is connected".

Note: If the dongle and headset do not pair the first time, unplug the dongle and repeat this procedure.

#### 6) Configure The PC:

It may be necessary to go into the PC's sound settings to prioritize the headset as the primary Microphone and/or Speaker. Please visit [www.vxicorp.com/usb](http://www.vxicorp.com/usb) for information on configuring your specific operating system.

### Step #2

