

# **User's guide for a RKE RF SYSTEM**

**Type designation: 736 744-A**

**Trade mark : VALEO**

**Car Manufacturer : GM (Saturn)**

## **User's manual and Compliance Statement:**

The compliance statement for the transmitter( FCC ID: N5F736744-A) will be integrated in the vehicle owner's manual. It will read:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

## **Description**

The system called RKE (Remote Keyless Entry) has two separate units : a transmitter and a receiver.

Its function consists in enabling the remote control of the door lock and unlock of a car by operating on the controls of a central unit.

The transmitter electronic circuit is introduced in a key which is attached to the ignition key.

## **Door lock**

To lock the doors, press and release the lock button on the key

## **Door unlock**

To unlock the doors, press and release the unlock button on the key