# 7 inch TV Tablet



MANUAL BOOK >>>

Tablet PC TV Manual

#### NOTE:

This manual will introduce the main function, operation method and other information. Please read this manual carefully before using the Tablet PC.

- 1. Do not store the table pc in hot, cold, dusty and humid environment.
- Please prevent the product fall down from high and crash with hard objects. The user should take the responsibility for artificial or other force majeure causing the damage of the product.
- 3. Avoiding using the table pc under dry environment in case of static.
- 4. Please charge the battery under below situation:
  - A There is no battery logo on the table;
  - B Tablet pc power off automatically.
  - C Operating but no response.

# CAUSTION: This product using 2000mA/5V or1500mA/5V charger, We DO NOT take any responsibility for the damage of user using other charger.

- 5. Do not put heavy object on table pc or damage it.
- We do not shoulder the responsibility of data damage and lose by fix it or wrong operation
- 7. The storage capacity on OS will be smaller than the standard data complies the requirement. Because the software of tablet pc takes some space.
- If the table can not use normally because of the change or damage of storage. Users can format the table pc on PC.

**NOTE:** This manual and some software will be updated occasionally. If the info does not conform to the real product, please take the real product as standard.

# ♦ Using Instruction



- 1, TV Antenna
- 2, Front Camer
- 3. Rear Camera
- 4, Sound Volume up button
- 5, Sound Volume down button
- 6, Power button
- 7, TF card
- 8, Micro USB JACK
- 9. Mini HDMI JACK
- 10, Earphone JACK
- 11, MIC
- 12, Reset hole

#### ◆ Main Function:

- 1. 7 Inch HD wide screen (1024\*600), Capacitive touch screen.
- This product using Android4.2 OS, inner Wi-Fi and wireless module. It support surfing the internet, mail, online games, weather report, map and other apps.
- It supports all versions of Android apps. It also supports many formats of image viewer, e-book, music, video and games. It can meet your all kinds of entertainment requirements.
  - 4. Inner G-Sensor, Users can choose the best viewing angle and can play the G-Sensor games  $^{\circ}$
- 5. Support multi video format for HD 1080P (1920X1080), AVI, RM, RMVB, FLV, WMV. MPG, FLV, HD 1080P max and so on.
- 6. Support multi audio format MP3、WMA、MP2、OGG、AAC、
- M4A, MA4, FLAC, 3GP, WAV and so on.
  - 7. Support HD JPEG, BMP, GIF and so on,
  - Storge device: Support TF card to max 32GB and also support U flash disk
  - Support jacks: Earphone, Micro USB, TF card, power jack, USB LAN and so on.
    - 10. HDMI
    - 11. Support HD photo and videotape
- Support DIGITAL TV BROADCASTING (DVB-T2 or ISDB-T or ATSC)

## ◆ FAQ

•Power on and unlock: Long pres " or seconds, The product will enter the system desk. The screen was locked and press to to right and then entering the menu. Please refer to below pictures.








- Power saving mode.: Short press to and the system enter SLEEP mode and lock the screen. Pressing to again and the screen light in 1 second
- Power off: Pressing the power on/off key for 3 seconds. Choosing power off and the system power off automatically.

[NOTES] The product will alarm when low battery. The product will power off automatically if not charging. Please check the power if can not power on.



# ♦ WIFI Setting

• WIFI: Pressing functional menu, Pressing "setting" and choosing "Wi-Fi". The system will search WIFI automatically and there will be a WIFI logo if searched.



• Setting WIFI and connect with the internet: Pressing the WIFI user's name Such as "shenzhou02" and show to enter the pass word. Entering the correct password and choose "Connect". The system will connect with the internet automatically. Please refer to below picture



## • Add-on 3G USB Dongle

 Shutdown the WIFI on setting menu. Inserting 3G USB-DONGLE into HOST jack, The product will connect with the 3G signal automatically.
 The product connected successfully when there is a 3G logo

### ◆ APK Installer

 This product support the third party apps based on Android, Most of the can be loaded from the net. Copy the apps into Flash or T-flash or USB flash disk and install. Pressing "App installer.





## ♦ Email

Pressing the "EMAIL" logo when connecting with WIFI or 3G:

#### Refer to below picture



• If having email account, entering the user account and password and then pressing the "Next". If not have an email account, please register an account and then log in.

## Setting

 pressing the setting logo an main menu. It sets (WIFI, sound, display, location, apps) and other functions. Refer to below pictures.





# ◆ Digital TV

pressing the TV logo on main menu. It open ther digital TV menu. Refer to below pictures.



 When use tv function first time, The program will have the following tips.



● Press the "Yes" or press search LOGO on TV menu, The program will enter SEARCH function, reference as shown below.



Press the "search" to start the program search.



●Later search program is done, you can see the list of programs.



 Select the program you want to watch play TV program as shown below.



Enjoy your TV program.

#### ■ FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning

the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help. To assure continued compliance, any changes or modifications not expressly approved by the party Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

## RF warning statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

#### Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.