



INSTALLATION



Insert the Sykport Wi-Fi Key all the way into the SD slot of the ColorTouch Thermostat. The 'cut corner' of the Key's circuit board faces up as shown in figure 1.




A Locking Clip is included for added security. The Locking Clip helps prevent unauthorized removal of the Skyport Key. Please refer to the steps below for installation of the Locking Clip.



With the thermostat removed from the backplate, insert the Skyport Key. Install the Locking Clip as shown in figure 2.



The Locking Clip is seated all the way down next to the circuit board as shown in figure 3. Reinstall the thermostat on the backplate.



Package Contents: 1) Skyport Wi-Fi Key, 1) Locking Clip, 1) Instruction Sheet

This device must be installed properly and operated more than 20 cm from the human body.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



