


## Before You Begin

- Verify all of the contents of your accessory package
- Review safety guidelines in Owner's Manual
- Place Liquid Crystal TV so the rear connectors are accessible
- Install AA batteries into the VIZIO Remote Control
- Write down your VX42L Serial Number (located on the back)

### Contents:




Power Cord



VIZIO VX42L User Manual, VIP Brochure and Registration Card.



Remote Control  
Includes 2 AA Batteries




AV Cable

## The Best Connection

For the best quality picture, we recommend using HDMI, DTV, RGB or Component inputs when possible. These are the only inputs capable of high definition (HD). Using these inputs does not guarantee high definition unless a high definition source is connected. However, not all equipment is capable of these connections. TV, AV and S-Video are not capable of HD signals.

+ Both DTV and TV share the same port. The television will automatically register which input type is connected.



## Four Easy Steps Simply follow our color-coded Step Charts and you're done.

### 1) Choose items to connect to your VX42L

- Determine which type of Signal Source and any Additional Equipment you wish to connect to your VX42L.
- The colored dots under each Signal Source and Additional Equipment indicate which type of connections you may use to connect to your VX42L.

| Signal Sources |         |           |                   |               | Additional Equipment |                |     |     |             |              |     |              |
|----------------|---------|-----------|-------------------|---------------|----------------------|----------------|-----|-----|-------------|--------------|-----|--------------|
| Cable          | Antenna | Cable Box | Digital Cable Box | Satellite Box | Computer             | Digital Camera | DVD | DVR | Game System | Sound System | VCR | Video Camera |
|                |         |           | ○                 | ○             |                      |                | ○   | ○   |             |              |     |              |
|                |         |           | ○                 | ○             |                      |                | ○   | ○   |             |              |     |              |
| ●              | ●       | ●         |                   |               |                      |                |     | ●   |             |              | ●   |              |
|                |         |           |                   |               | ●                    |                |     |     |             |              |     |              |
|                |         |           | ●                 | ●             |                      |                | ●   | ●   | ●           |              |     |              |
|                |         |           | ●                 | ●             |                      |                | ●   | ●   | ●           |              |     |              |
|                |         |           |                   |               |                      |                | ●   | ●   | ●           |              | ●   |              |
|                |         |           |                   |               |                      |                |     |     |             | ○            |     |              |

### 2) Choose equipment connection methods

- Using the colored dots from Step One, follow the row across to Step Two to match up the colored dots to the same colored connection method.
- Chose ONLY one method for each piece of equipment.

| Connection Methods  |
|---|
| <b>HDMI 1</b><br>TYPE: Digital High Definition<br>QUALITY: Best Digital     |
| <b>HDMI 2</b><br>TYPE: Digital High Definition<br>QUALITY: Best Digital     |
| <b>DTV / TV</b><br>TYPE: Cable/Antenna<br>QUALITY: Best Digital/Good Analog |
| <b>RGB</b><br>TYPE: RGB Analog<br>QUALITY: Best Analog                      |
| <b>COMPONENT 1</b><br>TYPE: Component Analog<br>QUALITY: Better Analog      |
| <b>COMPONENT 2</b><br>TYPE: Component Analog<br>QUALITY: Better Analog      |
| <b>AV1 or S-VIDEO</b><br>TYPE: Analog<br>QUALITY: Good Analog               |
| <b>AV2</b><br>TYPE: Analog<br>QUALITY: Good Analog                          |
| <b>OPTICAL</b><br>TYPE: Digital Audio Out<br>QUALITY: Best Digital          |
| <b>AUDIO OUT</b><br>TYPE: Analog Audio Out<br>QUALITY: Good Analog          |


### 3) Select cables and make connections

- Once you have determined the connection methods from Step Two, follow the row to Step Three to determine what kind of cables you need and what the connections look like on your equipment.
- Following the color-coded system, use the appropriate cables and connect your Signal Source and Additional Equipment to the color-coded inputs on your VX42L. (Refer to **Connection Map** at bottom of page.)
- Once connected, turn on your VX42L and all your equipment.

| My Equipment Has       | My VX42L Has           | Cable Needed                       |
|------------------------|------------------------|------------------------------------|
| HDMI                   | HDMI                   | HDMI*                              |
| HDMI OR DVI            | HDMI                   | HDMI* or HDMI* to DVI* & RCA Audio |
| Coaxial (RF)           | Coaxial (RF)           | Coaxial (RF) Cable*                |
| VGA and Optional Audio | VGA and Optional Audio | VGA Cable* & Stereo mini-jack      |
| Component & Stereo RCA | Component & Stereo RCA | Component & Stereo RCA Cable*      |
| Component & Stereo RCA | Component & Stereo RCA | Component & Stereo RCA Cable*      |
| A/V RCA or S-Video     | A/V RCA or S-Video     | A/V RCA Cable or S-Video Cable*    |
| A/V RCA                | A/V RCA                | A/V RCA Cable                      |
| Optical Audio          | Optical Audio          | Optical Audio Cable**              |
| Audio                  | Audio                  | Stereo RCA Cable                   |

### 4) Use your VX42L

- Fill in the Connection Reference Chart below, noting how you will connect your equipment/signal source to your VX42L.
- If you are using the DTV/TV input, turn over this guide and follow the programming instructions and then return to this last step.
  - If you are not using the DTV/TV input continue to next step.
  - Press the INPUT button on your remote. The INPUT menu will appear. (See image below.)
  - Continue pressing the INPUT button until you reach the corresponding connection.
- (To program TV Channels, see back.)



**To Use This Chart:** Write your equipment or signal source into the squares corresponding to your connection method.



① HDMI Cable, DVI-HDMI cable, VGA cable, Audio mini-jack and Component Cable are not included. These cables are available at [www.VIZIO.com](http://www.VIZIO.com) (View back for more details).

② Please Note: When using S-Video in the AV1 input, your TV will automatically recognize it and the screen will read AV1.

For help with connecting components to your VIZIO TV, visit <http://ceaconnections.guide.com/> for an interactive guide.

## 3 WAYS TO GET HDTV

- 1) Off-Air antenna (using the DTV antenna input). To see if you are able to receive HD signals off-air and for help choosing the right antenna, visit [www.antennaweb.org](http://www.antennaweb.org).
- 2) Cable - Subscribe to HD programming through your local cable company (HD cable box required).
- 3) Satellite - Subscribe to HD programming through Direct TV or Dish Network (HD satellite receiver required).




VIZIO provides wall mounts & Installation Services. (See Install with a Pro details on back) Visit [www.VIZIO.com](http://www.VIZIO.com) or call 1-888-849-4623 to order today.

## Program your TV


**Programming your VX42L is a simple TWO STEP process.**  
All you need is your Remote Control.

### STEP 1

Connect your Signal Source to the **DTV/TV** connection, go to **STEP 2**.



**DTV/TV**




**Please Note:**  
• Be sure the batteries in your remote are inserted correctly.

### STEP 2

**On your Remote Control...**

- 1 Turn on the TV, the Initial Setup screen should appear. If this screen does not appear see User Manual Chapter 3 for TV Tuner Setup.
- 2 Select Language; English, Français, Español.
- 3 Press **▲** or **▼** once to select Cable or Antenna. Select Cable if you are using cable from the wall or Air if you are using an antenna.
- 4 Press **▶** to continue to the next screen.
- 5 Press **OK** on remote to scan for channels. Scanning for available channels could take several minutes.
- 6 Once scanning is finished, programming is complete.
- 7 For more detailed information see Chapter 3 of your User Manual.



For advanced setups, refer to chapter 3 of your VX42L User Manual.

## Programming Your Cable or Satellite Box Remote

Consult your Cable or Satellite Owner's Manual to determine if you need a 3, 4 or 5-digit code. If your Cable or Satellite Box requires:

- 3-digits, please use "627" (This code usually works with DISHNetwork.)
- 4-digits, please use "1758", "0178" or "0128"
- 5-digits, please use "11758", "10178" or "10128" (These codes usually work for DIRECTV.)

► **Install with a Pro**  
Know your VIZIO is at its Best.  
Choose from four different levels of installation



### ► Basic

- Setting up and connecting your VIZIO TV to your existing home theater or audio system located in the same room
- Programming of your VIZIO remote and 1 other remote to operate your display and cable or satellite box
- Up to 20 minutes of educational demonstration and orientation
- 1 year warranty on the installation

### ► Deluxe

- Includes the Basic service plus wall mounting with surface-routing cabling
- Removing the stand from your VIZIO TV
- Mounting and securing the TV to the wall
- Neatly surface-routing cables from your video and audio equipment

### ► Premium

- Includes the Basic service plus wall mounting with in wall cabling
- Removing the stand from your VIZIO TV
- Mounting and securing the TV to the wall
- Concealing your video and audio cables in a standard frame wall
- Concealing your power cable with track molding if necessary

### ► All-Inclusive HDTV off-air Installation

- Includes equipment and installation for local off-air HDTV broadcast
- HDTV antenna optimized for your location
- Up to 125 feet of antenna cabling
- If needed up to 2 diplexers, antenna mount, mast, pre-amplifier, splitters
- Connecting antenna to your VIZIO TV

### ► Extended Service Plans

We recommend you register your VIZIO product either at our website [www.vizio.com](http://www.vizio.com) or fill in your registration card and mail it in. For peace of mind and to protect your investment beyond the standard warranty, VIZIO offers on-site extended warranty service plans. Extended service plans are offered at 2, 3, 4 and 5 years. These plans give you additional coverage during the standard warranty period. Visit our website or call us to purchase a plan.

[www.vizio.com](http://www.vizio.com)

CALL 800-988-4196  
FOR EXTENDED WARRANTY SERVICES

## ► Optional Components



### ENHANCE YOUR VIZIO EXPERIENCE.

When it comes to components and accessories, don't settle for less than VIZIO. We offer a full line of products specifically designed to accentuate your VX42L. To learn more about how you can enhance your VIZIO experience, call 888-849-4623 or visit [www.vizio.com](http://www.vizio.com).



### VIZIO HIGH-DEFINITION CERTIFIED CABLES

Our VIZIO Certified HD cables carry the same standards of excellence as all our VIZIO products. Available in: DVI, HDMI and Component in lengths of 2, 5, and 10 meters.



### VIZIO CERTIFIED MOUNTS

FLUSH MOUNT- turn your HDTV into a work of art  
TILT MOUNT- adjust your HDTV for the most comfortable viewing position  
ARTICULATING ARM- position your HDTV exactly where you want it