



Error/System Messages

This appendix describes the Talkman error/system messages, and what to do when you hear one.

The following are common Talkman error/system messages that you can hear in your headset. If the message you heard is not listed here, record it and report it to your System Administrator.

Battery is getting low.

This message indicates that the battery level is getting low.

Recommended Action

- As soon as possible, without interrupting data collection, turn the Talkman terminal off by pressing and holding the yellow play/pause button until the LED turns red and then goes off.
- Go to the battery storage area. (This is normally wear you get your Talkman terminal.)

- Take the battery off the Talkman terminal.
- Replace the battery with another charged battery

Battery is getting low, Change battery.

This message indicates that your battery is starting to lose its charge

Recommended Action

- Turn the Talkman terminal off by pressing and holding the yellow play/pause button until the LED turns red and then goes off.
- Return to battery storage area and change the battery

Battery failure is imminent. Change battery now.

This message indicates that your battery is starting to lose its charge

Recommended Action

- Turn the Talkman terminal off by pressing and holding the yellow play/pause button until the LED turns red and then goes off.
- Return to battery storage area and change the battery

Noise sampling procedure failed.

This message indicates that the Talkman terminal was unable to complete its noise sampling procedure

Recommended Action

- Move to a different location where the noise is different.
- Try to turn on your Talkman terminal again.
- If the problem persists, contact your system administrator.

Noise sampling procedure timed out.

This message indicates that the Talkman terminal was unable to complete its noise sampling procedure.

Recommended Action

- Move to a less noisy area and try again.
- If the problem persists, contact your system administrator.

It's too noise to operate now.

This message indicates that the Talkman terminal is unable to hear voice due to the noisy environment.

Recommended Action

- Move to a less noisy area and try again.
- If the problem persists, contact your system administrator.

Task load failed.

This message indicates that the Talkman terminal detected an error in the updated task file, and so did not update the task, but kept the current task.

Recommended Action

- Try to change the task again.
- If the problem persists, contact your system administrator.