

Product registration

Thank you for purchasing an 808 product. We pride ourselves on the quality and reliability of all our electronic products, but if you ever need service or have a question our customer service staff stands ready to help. Contact us at www.808audio.com.
PURCHASE REGISTRATION: Registering Online will allow us to contact you in the unlikely event a safety notification is required under the Federal Consumer Safety Act. **Register Online at: www.808audio.com. Click on Product Registration and Fill Out the Brief Questionnaire.**

Enregistréregistro del productotreatment du produit
Gracias por comprar un producto 808. Nos enorgullecemos la calidad y fiabilidad de todos nuestros productos electrónicos, pero si alguna vez necesita servicios técnicos o si tiene alguna pregunta nuestro personal de atención al cliente está a su disposición para ayudarle. Comuníquese con nosotros en www.808audio.com.
REGISTRO DE COMPRA: El registre en línea nos permitirá comunicarnos con usted en el caso de tener que enviarle algún aviso de seguridad en virtud de la Ley Federal de Seguridad del Consumidor. **Registre el producto en línea en: www.808audio.com. Haga clic en Registro del producto y responda al cuestionario.**

Enregistrement du produit
Merci d'avoir acheté un produit 808. Nous sommes fiers de la qualité et de la fiabilité de tous nos produits électroniques, mais en cas de nécessité de réparation ou pour toute question le personnel de notre service clientèle est prêt à vous aider. Contactez-nous sur www.808audio.com.
ENREGISTREMENT D'ACHAT: Enregistrer votre produit en ligne nous permettra de communiquer avec vous pour tout avis de sécurité au sujet du produit en vertu du Federal Consumer Safety Act (Loi fédérale de protection du consommateur). **Enregistrez votre produit en ligne sur: www.808audio.com. Cliquez sur Enregistrement produit et remplissez le court questionnaire.**

ENE/F

It is important to read this manual prior to using your new product for the first time.

Es importante leer este manual antes de usar por vez primera su equipo.

Nous vous recommandons de lire ce manuel d'instructions avant d'utiliser votre nouveau produit pour la première fois.

Regulatory Information

may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.The device can be used in portable exposure condition without restriction.

Industry Canada Regulatory Information

This device complies with Industry Canada license-exempt RSS standards.(Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. The user is cautioned that this device should be used only as specified within this manual to meet RF exposure requirements. Use of this device in a manner inconsistent with this manual could lead to excessive RF exposure condition.

Industry Canada Regulatory Information
CAN ICES-3 (B)/NMB-3 (B)
Avis d'Industrie Canada
CAN ICES-3 (B)/NMB-3 (B)


General controls

- (6) Charge**
 - Micro USB input jack for recharging the speaker.

- (7) Aux In**
 - Line level input jack for analog audio playback.

Pairing

Pair the SP890-A with your phone/device to create an audio streaming link between the two devices. Your devices must be paired before music can be played.


**Important**: Make sure that your phone/device supports *Bluetooth A2DP** (Advanced Audio Distribution Profile) before proceeding. **A2DP (Advanced Audio Distribution Profile) is a technology enabling to stream stereo sound from an audio source (phone, PC, laptop, tablet, mp3 player) to a stereo speaker or headset via Bluetooth. To do so, both devices must support this profile.*

- If the SP890-A is off, slide the ON/OFF switch to ON to turn it on.
- If this is the first time you are turning on SP890-A, the Pair indicator blinks in blue rapidly. This indicates that SP890-A is ready to be paired. If the Pair indicator does not blink rapidly, press and hold the Pair button for 3 seconds.
- While the SP890-A is in pairing mode, select 808 Hex SL from the list of Bluetooth devices of your phone.
- If your phone asks for a password/ pin code, enter 0000 and press **OK**.
- Upon successful pairing, the SP890-A will beep once. It is now ready to use with your phone.

When you turn it on, the SP890-A reconnects automatically with the last paired device. When you leave the Bluetooth operating range, with the SP890-A turned ON, it disconnects. When you come back into the Bluetooth operating range, press the **Pair** button to reconnect to the last paired device. The SP890-A will beep once it has been successfully re-paired.

- Go to your phone's music player and play a track by pressing "Play". If the SP890-A is connected, the music will be heard directly in the speaker. See your phone's manual if needed.
- To adjust the volume of your audio: Use the – and + buttons of the speaker. You can also use the volume controls on your phone.

English



WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

Some of the following information may not apply to your particular product; however, as with any electronic product, precautions should be observed during handling and use.

- Read these instructions.
- Keep these instructions.
- Use all warnings.
- Follow all instructions.

- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/ apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when unused for



Portable Cart Warning

- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, should be placed on the apparatus.
- Always leave sufficient space around the product for ventilation. Do not place product in or on a bed, rug, or in a bookcase or cabinet that

Introduction

The SP890-A is a portable wireless speaker featuring a portable design and compact footprint.

Users can stream music wirelessly from any cell phone, tablet, computer, laptop or mp3 player supporting *Bluetooth A2DP*.

The integrated rechargeable battery ensures 4 hours of non-stop, maximum-volume music, and up to 8 hours of moderately played melodies.

The SP890-A comes with a 3.5 mm stereo jack cable for devices that do not support *Bluetooth A2DP*.



Auxiliary source

- Plug one end of the supplied 3.5 mm stereo jack cable into the Aux In and the other end into the output of your music player.
- Press "Play" on your music player to stream music directly via the SP890-A and use the controls on your music player directly.

Important:

The SP890-A needs to be paired with your *Bluetooth A2DP* phone/device before you can stream music to the speaker. Please refer to the Pairing section for details on how to pair with the SP890-A.

- Go to your phone's music player and play a track by pressing "Play". If the SP890-A is connected, the music will be heard directly in the speaker. See your phone's manual if needed.
- To adjust the volume of your audio: Use the – and + buttons of the speaker. You can also use the volume controls on your phone.

IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ AND SAVE THIS FOR FUTURE REFERENCE

- long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

ADDITIONAL SAFETY INFORMATION

- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, should be placed on the apparatus.
- Always leave sufficient space around the product for ventilation. Do not place product in or on a bed, rug, or in a bookcase or cabinet that

may prevent air flow through vent openings.

- Do not place lighted candles, cigarettes, cigars, etc. on the product.
- Care should be taken so that objects do not fall into the product.
- Do not attempt to disassemble the cabinet. This product does not contain customer serviceable components.
- The marking information is located at the bottom panel of apparatus.
- The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
- No naked flame sources such as lighted candles should be placed on the apparatus.
- Only use this in moderate climates.

long periods of time.

Charging

- Before you start using your speaker, you need to charge its built-in battery. Connect the supplied micro USB cable to the Charge jack on the back of the SP890-A. Connect the other end of the cable to a USB power source (like a computer or a USB charger).
- The Charge indicator on the front of the SP890-A will turn solid red while the speaker is charging. It turns green when the speaker is fully charged.

The integrated rechargeable battery ensures 4 hours of non-stop, maximum-volume music, and up to 8 hours of moderately played melodies.

The SP890-A comes with a 3.5 mm stereo jack cable for devices that do not support *Bluetooth A2DP*.



Warranty information

12 Month Limited Warranty Applies to 808 Audio Products

VOXX Accessories Corporation (the Company) warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 12 months from the date of original purchase, such defect(s) will be repaired or replaced with reconditioned product (at the Company's option) without charge for parts and repair labor.

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s),

transportation prepaid, to the Company at the address shown below.

This Warranty does not extend to the elimination of externally generated static or noise, to correction of antenna problems, loss/interruptions of broadcast or internet service, to costs incurred for installation, removal or reinstallation of product, to corruptions caused by computer viruses, spyware or other malware, to loss of media, files, data or content, or to damage to tapes, discs, removable memory devices or cards, speakers, accessories, computers, computer peripherals, other media players, home networks or vehicle electrical systems.

This Warranty does not apply to any product or part thereof which, in the

opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or deface ment of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH

be disposed of separately from the household waste.


Precautions for the unit

- Do not use the unit immediately after transportation from a cold place to a warm place; condensation problems may result.
- Do not store the unit near fire, places with high temperature or in direct sunlight. Exposure to direct sunlight or extreme heat (such as inside a parked car) may cause damage or malfunction.
- Clean the unit with a soft cloth or a damp chamois leather. Never use solvents.
- The unit must only be opened by qualified personnel.


However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

General controls

Bottom view




Front view



Side view



Rear view



Regulatory Information

FCC Information

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by VOXX Accessories Corporation could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions (1) This device

- (1) ON/OFF switch**

Fast flash in blue	Ready for pairing
Very slow flash in blue	In Standby mode

Solid blue	Reconnecting to the most recently connected device
Solid white	<i>Bluetooth</i> connection established
	AUX input connected

- (3) – / + button**
- Press to adjust volume on the speaker. You may also need to adjust the volume on your device.

(4) Charge indicator

Solid red	Charging
Solid green	Battery full
Off	USB charger is disconnected

- (5) Pair button**
- Press and hold for 3 seconds to activate pairing mode. If the speaker is already connected and you would like to connect to a different device, press and hold for 3 seconds to break the current connection and initiate pairing.

legal rights and you may also have other rights which vary from state to state.

Recommendations before returning your product for a warranty claim:

- Properly pack your unit. Include any remotes, memory cards, cables, etc. which were originally provided with the product. However DO NOT return any removable batteries, even if batteries were included with the original purchase. We recommend using the original carton and packing materials. Ship to the address shown below.
- Note that product will be returned with factory default settings. Consumer will be responsible to restore any personal preference settings.

Audiovox Return Centre
Attn: Service Department.
150 Marcus Blvd.
Hauppauge N.Y. 11788

1-800-645-4994

For Canada Customers, please ship to: Audiovox Return Centre
o Genco
6685 Kennedy Road,
Unit#3, Door 14,
Mississauga, Ontario
L5T 3A5

Español



ADVERTENCIA: PARA EVITAR PELIGRO DE CHOQUE ELÉCTRICO O INCENDIO, NO EXPOÑA ESTE PRODUCTO A LA LLUVIA O LA HUMEDAD.

Alguna de la siguiente información quizá no se aplique a su producto en particular. Sin embargo, como con cualquier producto electrónico, se deben tomar precauciones durante su manejo y uso.

- Lea estas instrucciones.
- Conservé estas instrucciones.
- Tome en cuenta todas las

advertencias.

- Siga todas las instrucciones.
- No use este aparato cerca de agua.
- Limpie solamente con un paño seco.
- No bloquee ninguna de las aperturas de ventilación. Instale de acuerdo con las instrucciones del fabricante.
- No instale cerca de fuentes de calor tales como radiadores, registros de calor, estufas, u otros aparatos (incluyendo amplificadores) que produzcan calor.
- Use solamente con el carro, soporte, trípode, consola, o mesa especificados por el fabricante, o vendidos con el aparato. Cuando se utiliza un carro, tenga precaución al mover la combinación de carro/aparato para evitar lesiones ocasionadas por volcadura.
- Desconecte este aparato durante tormentas eléctricas o cuando no sea utilizado por largos periodos de tiempo.
- Refiera todo el servicio a personal de servicio calificado. El servicio es requerido cuando el aparato ha sido dañado de alguna forma, tal como daño a la clavija o al cable de corriente, cuando se ha derramado líquido o han caído objetos dentro del aparato, el aparato ha sido expuesto a lluvia o humedad, no funciona normalmente, o ha sido tirado.

- Carro/aparato para evitar lesiones ocasionadas por volcadura.
- Desconecte este aparato durante tormentas eléctricas o cuando no sea utilizado por largos periodos de tiempo.
- Refiera todo el servicio a personal de servicio calificado. El servicio es requerido cuando el aparato ha sido dañado de alguna forma, tal como daño a la clavija o al cable de líquido o han caído objetos dentro del aparato, el aparato ha sido expuesto a lluvia o humedad, no funciona normalmente, o ha sido tirado.

INFORMACION ADICIONAL DE SEGURIDAD

- El aparato no debe quedar expuesto a goteos o salpicaduras de líquidos,

FAVOR DE GUARDAR ESTO PARA UNA REFERENCIA FUTURA

- y, por lo tanto, no se deben colocar sobre el aparato objetos que contengan líquidos, como por ejemplo vasos.
- Siempre deje suficiente espacio para ventilación alrededor del producto. No ponga el producto en la cama, alfombra, librero o gabinete que pueda obstruir la corriente de aire a través de aperturas de ventilación.
- No pongan velas, cigarrillos o cigarros encendidos encima de producto.
- Tome precauciones para evitar que caigan objetos dentro del producto.
- No intente desensamblar el gabinete. Este producto no contiene componentes que requieran servicio por parte del cliente.
- La información de señalamiento está ubicada en la parte inferior del aparato.

- No se deberá obstruir la ventilación cubriendo las aperturas de ventilación con elementos tales como periódicos, paños, cortinas, etcétera.
- Ninguna fuente de flama abierta, tal como velas encendidas, deberá colocarse sobre el aparato.
- El uso del aparato en climas moderados.

Información importante sobre la batería
Advertencia: su producto contiene una materia y un sistema de carga que están diseñados para trabajar a temperaturas que no excedan de 50°C (122°F). Dejar este producto en un automóvil cerrado o en la cajuela de un automóvil donde las temperaturas puedan exceder de 50°C puede resultar en daño permanente a la batería, fuego o explosión. Por favor retire su producto del automóvil al salir; no coloque el producto en la cajuela de su automóvil, y no deje su producto en alguna ubicación donde la temperatura pueda exceder de 50°C.

en daño permanente a la batería, fuego o explosión. Por favor retire su producto del automóvil al salir; no coloque el producto en la cajuela de su automóvil, y no deje su producto en alguna ubicación donde la temperatura pueda exceder de 50°C.

Ecología
Su producto debe ser eliminado apropiadamente de conformidad con las leyes y regulaciones locales. Debido a que este producto contiene una batería, esta debe ser eliminada en forma separada del desecho del hogar.

Precauciones para la unidad

- No utilice la unidad inmediatamente después de llevarla de un lugar frío a un lugar caliente puesto que podría producirse algún problema de condensación.

Especificación

Cumplimiento con Bluetooth: *Bluetooth* version 3.0, EDR

Perfiles Bluetooth Soportados:

- A2DP 1.0 (Perfil de Distribución de Audio Avanzado) (Advanced Audio Distribution Profile)

Rango de Operación: 10 metros norma Bluetooth

Frecuencia: 2.4 GHz

Batería y Vida de la Batería:

- Tipo de batería: batería de ion litio
- Tiempo de reproducción de música (nivel de volumen máximo): 4 horas
- Tiempo de reproducción de música (volumen medio): 8 horas
- Tiempo de carga: 4 horas

Características de Audio:

- Compatible con cualquier teléfono Bluetooth A2DP, PC, laptop, tableta o reproductor mp3
- Receptáculo de entrada auxiliar de 3.5 mm para equipos distintos a Bluetooth A2DP, reproductores mp3, iPods o computadoras

Tamaño y peso:

- Alto: 180 mm
- Largo: 63.5 mm
- Ancho: 63.5 mm
- Peso: 0.85 lbs

Accesorios:

- Cable de receptáculo estéreo de 3.5 mm
- Cable micro USB

La palabra, marca y logos *Bluetooth*® son marcas registradas propiedad de *Bluetooth SIG, Inc.* y cualquier uso de tales marcas por VOXX Accessories Corporation es bajo licencia. Otras marcas comerciales y nombres de marca son aquellos de sus respectivos propietarios.

Introducción

La SP890-A es una bocina inalámbrica portátil que cuenta con un diseño pottable y un tamaño compacto.

Los usuarios pueden transmitir inalámbricamente música desde cualquier teléfono celular, tableta, laptop o reproductor mp3 que soporte *Bluetooth A2DP*.

Las baterías recargables integradas aseguran 4 horas de música a volumen máximo sin parar, y hasta 8 horas de reproducción de melodías a volumen moderado.

La SP890-A viene con un cable de receptáculo estéreo de 3.5 mm para dispositivos que no soporten *Bluetooth A2DP*.

Carga

- Antes de comenzar a usar su bocina, usted necesita cargar su batería integrada. Conecte el cable micro USB suministrado al receptáculo de carga en la parte posterior de la SPConecte el otro extremo del cable a una fuente de poder USB (como una computadora o un cargador USB).
- El indicador de Carga al frente de la SP890-A se tornará rojo sólido mientras la bocina esté cargando. Se torna verde cuando la bocina está completamente cargada.

Importante:

La batería deberá estar completamente cargada ante de usarla por primera vez.

Una vez que la batería esté completamente descargada, recargue inmediatamente (independientemente de si usted planea usar la batería o no) para maximizar la vida de la batería. Si usted no planea usar la batería por un periodo de tiempo prolongado (una semana o más), le recomendamos cargar completamente la batería. Para periodos mayores de almacenaje, por favor recargue la batería por lo menos una vez cada dos meses para mantener la misma en condición óptima.



Lightbulb icon



BC

Specification

Bluetooth Compliance : *Bluetooth* version 3.0, EDR

Supported Bluetooth Profiles :

- A2DP 1.0 (Advanced Audio Distribution Profile)

Operating Range : 10 meters *Bluetooth* standard

Frequency :

2.4 GHz

Battery and Battery Life :

- Battery type : Lithium Ion battery
- Music playing time (maximum volume level) : 4 hours
- Music playing time (medium volume) : 8 hours
- Charging time : 4 hours

Industry Canada Regulatory Information

CAN ICES-3 (B)/NMB-3 (B)

Avis d'Industrie Canada

CAN ICES-3 (B)/NMB-3 (B)

Specification

Bluetooth Compliance : *Bluetooth* version 3.0, EDR

Supported Bluetooth Profiles :

- A2DP 1.0 (Advanced Audio Distribution Profile)

Operating Range : 10 meters *Bluetooth* standard

Frequency :

2.4 GHz

Battery and Battery Life :

- Battery type : Lithium Ion battery
- Music playing time (maximum volume level) : 4 hours
- Music playing time (medium volume) : 8 hours
- Charging time : 4 hours

Industry Canada Regulatory Information

CAN ICES-3 (B)/NMB-3 (B)

Avis d'Industrie Canada

CAN ICES-3 (B)/NMB-3 (B)

Reconnecting

- If the SP890-A is off, slide the ON/OFF switch to ON to turn it on.
- If this is the first time you are turning on SP890-A, the Pair indicator blinks in blue rapidly. This indicates that SP890-A is ready to be paired. If the Pair indicator does not blink rapidly, press and hold the Pair button for 3 seconds.
- While the SP890-A is in pairing mode, select 808 Hex SL from the list of Bluetooth devices of your phone.
- If your phone asks for a password/ pin code, enter 0000 and press **OK**.
- Upon successful pairing, the SP890-A will beep once. It is now ready to use with your phone.

When you turn it on, the SP890-A reconnects automatically with the last paired device. When you leave the Bluetooth operating range, with the SP890-A turned ON, it disconnects. When you come back into the Bluetooth operating range, press the **Pair** button to reconnect to the last paired device. The SP890-A will beep once it has been successfully re-paired.

- Go to your phone's music player and play a track by pressing "Play". If the SP890-A is connected, the music will be heard directly in the speaker. See your phone's manual if needed.
- To adjust the volume of your audio: Use the – and + buttons of the speaker. You can also use the volume controls on

