

## Quick Start Guide



# trio :)

Stealth G4 10.1"

Follow the easy steps shown inside to get  
your Trio Tablet up and running.

**trio :)**



[recyclingourtablets.com](http://recyclingourtablets.com)

## More Information

To find out more about your Trio Tablet and its cool features, check out the user manual on the Trio website:

**[www.triotablets.com/manuals](http://www.triotablets.com/manuals)**

Click on:

**Trio**



## STEP 1: CHECK OUT THE CONTROLS

Before you do anything else, take a good look around your TRIO Tablet and find out where all the control buttons and other items of interest are.

### Front

Front Camera



### Back

Headphone Jack

microSD slot

Reset aperture

Mic.

USB/Charger Port

Volume (+ / -)

Power on/off

Rear Camera



Speaker


## STEP 2: CHARGE THE BATTERY

You need to charge up the battery before you use your TRIO Tablet for the first time.

Connect the charger to your TRIO, using the USB/Charger cable. The cable plugs in to the USB/Charger Port at the top of your Tablet.



The connection should look like this:



Plug the charger into a power outlet. The screen will display a flashing battery symbol for a few seconds to show that the battery is charging. Keep the battery on charge for 6 to 8 hours to make sure that it is fully charged.

## STEP 3: POWER UP

When the battery is fully charged, switch on your TRIO Tablet. To do this, press and hold the power on/off button until the Trio:) logo appears:



The logo remains until the startup step is finished; the startup screen then appears:



Touch the screen at the lock symbol and swipe sideways. This will unlock your tablet and display the desktop screen. At the bottom of the desktop screen you will see the following symbol:



Touch this symbol and the Apps screen appears. Touch any icon on the Apps screen and it will open the application that you have chosen. You are now up and running!

## FCC Information and Copyright

This equipment (FCCID: 2ACH9HM-1406M) has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**FCC RF warning** statement: the device has been evaluated to meet general RF exposure requirement , The device can be used in portable exposure condition without restriction.