




TOP AND CABINET PARTS

For Model: LLV6144BN0
(Almond)

AUTOMATIC
WASHER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS

For Model: LLV6144BN0
(Almond)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
1 357213 Nut, Push-In (2)	8 3356311 Screw & Washer, Lid Switch (2)	18 21258 Bearing, Lid Hinge (2)
2 3358214 Top	9 3352629 Switch, Lid	19 3361396 Lid
3 62750 Spacer, Cabinet To Top (4)	13 3351355 Screw, Lid Hinge Mounting (4)	20 358684 Strike, Lid Switch
5 63425 Cabinet	14 21097 Pad, Lid Hinge (2)	22 93770 Bumper, Lid (2)
6 62780 Clip, Top & Cabinet & Rear Panel (2)	15 54584 Hinge, Lid (L.H.)	28 384435 Screw, 10-16 x 1/2 (4)
	16 54583 Hinge, Lid (R.H.)	31 90016 Clip, Harness
	17 19119 Bumper, Lid Hinge	


LITERATURE AND OPTIONAL PARTS

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<u>LITERATURE PARTS</u>		
LIT3360057 Sheet, Installation Instructions	<u>OPTIONAL PARTS NOT INCLUDED</u>	
LIT3357468 Guide, Use and Care	<u>PAINT, TOUCH-UP (1/2oz.)</u>	
LIT3361368 Energy Guide	72017 White	<u>OIL</u>
LIT3361187 Label, Wiring Diagram	72107 Almond	350572 Oil, Gearcase (16 Oz.)
LIT4313896 Manual, (Washer) Do-It-Yourself	72110 Golden Harvest	<u>LUBRICANT</u>
	<u>PAINT, PRESSURIZED SPRAY (13 oz.)</u>	
	350941 Leveler (Thinner)	285208 Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)
	350938 Primer, Gray	<u>SEALER</u>
	350930 White	285195 Sealer, Gasket (.20 Fl. Oz.) (6 ml)
	350956 Almond	<u>SHIPPING KIT</u>
	261890 Golden Harvest	3348675 Shipping Kit
	<u>PAINT, BULK (1 qt.)</u>	
	799344 White (Uncut)	<u>ACCESSORY PARTS</u>
	978883 Almond (Uncut)	63580 Fabric Dispenser
	261891 Golden Harvest (Uncut)	89121 Stand-Pipe Kit
		367031 Drain Protector
		285320 Siphon Break Kit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROLS AND REAR PANEL PARTS




For Model: LLV6144BN0
(Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS

For Model: LLV6144BN0
(Almond)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS

For Model: LLV6144BN0
(Almond)

Illus. No.	Part No.	DESCRIPTION
1	3355758	Cap, Agitator
2	358237	Screw & Washer (5-16-24 x 1)
3	3349019	Clothes Mover
4	3350830	Agitator
5	3360611	Tub Ring & Gasket
6	3359586	Gasket, Tub Ring
7	387868	Balance Ring
8	387867	Clip, Balance Ring (8)
9	3351001	Cam Driven
10	387091	Dog, Agitator Clutch
11	357574	Seal, Agitator
12	21366	Nut, Spanner
13	387713	Basket
14	62941	Filter, Plate (Includes Illus. 15)
15	62942	Lock, Filter
16	63125	Tub
17	389140	Block, Basket Drive
18	383727	Gasket, Centerpost
19	3347780	Hose, Pressure Switch
22	3350389	Spacer, Thrust
23	3347290	Cap, Barrier
24	3348855	Seal, Inner Cap

MISCELLANEOUS PARTS




Illus. No.	Part No.	DESCRIPTION
1	3359460	Miscellaneous Parts Bag
2	16123	Washer, Inlet Hose (1-1/16 x 5/8) (4)
4	3359452	Nut, Lock (3/8-16)
5	389102	Foot, Front (2)
7	356138	Clamp, Hose

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Model: LLV6144BN0
(Almond)



Illus. No.	Part No.	DESCRIPTION
1	388951	Brake & Drive Tube (Complete) (Refer to Page 11 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3350115	Clutch (Complete)
6	388190	Band & Lining, Clutch (Includes Illus. 7 & 8)
7	62646	Cap, Clutch Spring (2)
8	3354731	Spring, Clutch
9	3360630	Gearcase (Complete) (Refer To Page 12 For Further Breakdown)
10	3357334	Screw, Gearcase To Base (3)


Illus. No.	Part No.	DESCRIPTION
11	62611	Plate, Motor Mount To Gearcase
12	62691	Grommet, Motor (4)
13	3352470	Coupling, Motor & Isolation
15	3355454	Clip, Anti-Rattle
16	3357334	Screw
17	3349637	Retainer, Motor (2)
18	3349282	Shield, Tub To Motor
19	3349643	Motor, Main Drive
20	62850	Switch, Main Drive Motor
21	62700	Retainer, Pump (2)
22	3352492	Pump (Complete)
23	3387485	Screw, 10-16 x 5/8
24	3351341	Shield, Motor
25	9420601	Screw, 10-16 x 5/16
26	357021	Capacitor
27	357030	Clamp, Capacitor



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

For Model: LLV6144BN0
(Almond)




Illus. No.	Part No.	DESCRIPTION
1	98610	Screw, Bracket Mounting (10-16 x 5/8) (6)
2	64067	Bracket, Spring Outer (2)
3	63907	Spring Suspension,(3)
4	389350	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
6	3348727	Link, Leveling Mechanism (2)
7	62597	Spring, Leveling Mechanism
8	62837	Pin, Knurled
9	62596	Foot, Rear (2)
13	3347047	Bearing, Centerpost (2)
14	357409	Seal, Centerpost (3)
15	388492	Spring, Counterweight
16	62568	Pad, Plate
17	389299	Plate, Suspension (Includes Illus. 16)
18	62602	Pad, Base
19	3359886	Base Assembly (Includes Illus. 6, 7, 8, 9, 18 & 26)
21	3359452	Nut, Lock (3/8-16)
22	389102	Foot, Front (2)
23	356934	Seal, Centerpost (2)
24	285203	Centerpost Bearing Kit (Includes Illus. 13, 14 & 23)
25	63134	Ring, Sound Deadening
26	63806	Retainer, Suspension Spring

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS


For Model: LLV6144BN0
(Almond)

RETAINER CLIPS



Illus. No.	Part No.	DESCRIPTION
1	3349557	Clip, Harness
2	62749	Clip, Harness
3	3347812	Clip, Harness
4	3352501	Clip, Harness
5	90016	Clip, Harness
6	3390496	Clip, Harness
7	3359836	Wiring Harness
9	3369366	Block, Disconnect (Black) (Timer)
10	3354924	Terminal, Female
11	62889	Receptacle, Terminal (3-Way) (Lid Switch)
12	94614	Terminal, Female
13	353424	Plug, Terminal (3-Way) (Power Cord)
14	94613	Terminal, Male
15	62505	Block, Disconnect (Motor)
17	3347243	Block, Disconnect (Temperature Switch)
18	63523	Protector, Harness
19	3371761	Terminal


WIRING HARNESS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WATER SYSTEM PARTS

For Model: LLV6144BN0
(Almond)




WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector (Not Included)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE AND DRIVE TUBE PARTS

For Model: LLV6144BN0
(Almond)



Illus. No.	Part No.	DESCRIPTION
1	388951	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	91939	Seal, Oil
4	356427	Seal, Drive Tube
5	356937	Spacer, Drive Tube
6	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8	64232	Brake Shoe
9	62703	"T" Bearing, Spin Tube
10	62648	Cap, Brake Spring (2)
11	62647	Spring, Brake
12	62909	Sleeve, Brake Spring
13	63023	Cam, Brake Release
14	63022	Sleeve, Cam
15	64194	Driver, Brake Cam
16	90368	Ring, Retaining


FOLLOWING PARTS NOT ILLUSTRATED

285208 Lubricant
(Use Only In Brake Shoe Assembly On Roller & Pin)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GEARCASE PARTS

For Model: LLV6144BN0
(Almond)



Illus. No.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	62685	Cover, Gearcase
3	62787	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389243	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring (2)
10	62676	Spring, Agitate
11	62533	Gear, Agitate
12	62619	Washer, Agitate Gear
13	62580	Cam Follower
14	62581	Cam, Agitate
15	389240	Shaft, Agitator
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389229	Bottom and Pinion, Gearcase
20	3360263	Gear, Main Drive
21	285352	Seal, Thrust Plug
22	90864	Screw, Gearcase Cover Mounting (8) (10-24 x 3/8)
23	95082	Ring, Retaining
24	285292	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	62534	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

GC-215

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST