




# COOKTOP PARTS

For Models: RF362LXTQ1, RF362LXTT1, RF362LXTS1, RF362LXTB1  
(Designer White) (Designer Biscuit) (Black Stainless) (Black)

30" ELECTRIC CERAN  
FREESTANDING RANGE  
SELF CLEAN OVEN



Illus. No.	Part No.	DESCRIPTION
1	9762996	Literature Instructions, Installation Template, Anti-Tip
	9757142	English/Spanish
	9757143	English/French
	9763001	Owners Manual
	W10117605	Tech Sheet
	9762761	Safer Cooking Tips


Illus. No.	Part No.	DESCRIPTION
2	W10035930	Spring, Locator
3	3196170	Screw
4		Cooktop
	9763330	White
	9763331	Biscuit
	9763332	Black

Illus. No.	Part No.	DESCRIPTION
5		Element, Surface
	8523047	2400/1000W LF,RF
	8273994	1200W LR,RR
6	8272791	Bracket, Element
7	3196169	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: RF362LXTQ1, RF362LXTT1, RF362LXTS1, RF362LXTB1  
(Designer White) (Designer Biscuit) (Black Stainless) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	W10009080	Black Left
	W10009090	Black Right
	W10009040	White Left
	W10009050	White Right
	W10009060	Biscuit Left
	W10009070	Biscuit Right
2	9757609	Nameplate
3		Panel, Control
	W10117602	Black
	W10117601	Biscuit
	W10117600	White
	W10117603	Stainless


Illus. No.	Part No.	DESCRIPTION
4		Switch, Infinite
	9758060	Front (LF,RF)
	3148951	Rear (RR,LR)
5	8523265	Light, Ind. (2)
6	3196068	Lens, Light (2)
7		Knob, Infinite (4)
	9761964	Black
	9761962	White
	9761963	Biscuit
8	8523280	Shield, Heat

Illus. No.	Part No.	DESCRIPTION
9		Screw
	3196166	White
	8281194	Biscuit
	3196168	Black
10	8272473	Cover, Upper
11	9762095	Brkt-Mntg, Console
12		Control, Range
	W10108100	Black
	W10108090	White
	W10108110	Biscuit
13	3196178	Screw
14	9762078	Brkt-Mntg, EOC
15	3400882	Screw
16	8273564	Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Models: RF362LXTQ1, RF362LXTT1, RF362LXTS1, RF362LXTB1  
 (Designer White) (Designer Biscuit) (Black Stainless) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS


For Models: RF362LXTQ1, RF362LXTT1, RF362LXTS1, RF362LXTB1  
(Designer White) (Designer Biscuit) (Black Stainless) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9760407	Brkt-Mntg,Dr Hnge	18	9760314	Rail, Base (2)	38	3196165	Screw
2	8273905	Support, Corner LR	19	W10058460	Foot, Rear (2)	39	3196168	Screw
3		Panel, Side (2)	20	9761490	Insulation	40	3196178	Screw
	8053830	White-Textured	21	9761512	Clip- Mounting	41	3196174	Screw
	8272519	Biscuit-Textured	22	9758238	Retainer, Side (2)	42	3196179	Screw
	8053832	Black-Textured	23	8273902	Sensor, Oven	44	W10031780	Screw
4	9761013	Latch, Door	24	3195736	Support, Front (2)	45	W10067840	Screw
5	W10078380	Rod, Latch	25	3195987	Support, Corner RR	46	3400016	Screw
6	W10107820	Latch Asy, Rear	26	3196548	Fuse, Thermal	47	3196566	Screw
8	9757340	Element, Broil	27	3196172	Screw	48	9757262	Switch - Door
9	9758541	Element, Bake	28	3186116	Support, Oven (2)	49	9757239	Rod - Door Switch
10	8522416	Seal, Oven Door	29	3186034	Bracket, Service			Rear Mount
11	9758701	Spacer, Door	30	9761958	Block, Terminal	50	9761301	Screen - Catalyst
12	3196560	Screw	31	8274034	Back, Main			
13	W10114344	Glide, Drawer (2)	32	112432	Nut (3)			
14	3196037	Foot, Front (2)	33	9761299	Vent Tube Asm	<b><u>INSULATION</u></b>		
15	9761517	Clip,Door Mntg(2)	34	3196701	Light Socket Assy		8272616	Insulation, Wrap
16	8054068	Tray, Insulation	35	311255	Bulb, Oven Light		8272612	Insulation, Back
17	3196576	Clip, Panel (6)	36	9758283	Cover, Box		8272613	Insulation, Vent

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DRAWER & BROILER PARTS

For Models: RF362LXTQ1, RF362LXTT1, RF362LXTS1, RF362LXTB1  
 (Designer White) (Designer Biscuit) (Black Stainless) (Black)



Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	9761031	Drawer, Storage
3	9758200	Bracket, Drawer(2)
4		Rivet, Push (2)
	3196814	White
	3196813	Black
	3196815	Almond


Illus. No.	Part No.	DESCRIPTION
5		Drawer Front
	8053339	White
	8272501	Biscuit
	8053341	Black
6	8053334	Glide, Drawer (2)

Illus. No.	Part No.	DESCRIPTION
7	3196168	Screw
8	9755798	Panel(Stls. Model)
9	9757219	Handle(Stls.Model)
10	W10031790	Screw(Stls. Model)
11	9781235	Clip(Stls. Model)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: RF362LXTQ1, RF362LXTT1, RF362LXTS1, RF362LXTB1  
(Designer White) (Designer Biscuit) (Black Stainless) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Trim, Top
	9762391	Black
	9761976	Biscuit
	9761975	White
	9762394	Black/Stainless Model
2	3196164	Screw
3		Handle, Door
	9761983	Black
	9761984	Biscuit
	9761982	White
	9761985	S.Steel
4	9761344	Liner, Door
5	8522414	Seal, Window
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass
8	8272618	Insulation, Door

Illus. No.	Part No.	DESCRIPTION
9	9761357	Retainer, Insltn
10		Hinge, Door (2)
	9761493	White/Biscuit Mdl.
	9761496	Stainless Model
11		Glass, Outer Door
	w10075990	Black
	W10075980	White
	W10076000	Biscuit
	9756435	Stainless Mdl.
12		Trim, Side
	W10128571	Black Left
	W10128562	Black Right
	W10128573	Biscuit Left
	W10131044	Biscuit Right
	W10128572	White Left
	W10128563	White Right

Illus. No.	Part No.	DESCRIPTION
13	3196160	Screw
14		Trim, Bottom
	8523177	Black
	8523178	Biscuit
	8523175	White
	8523180	Stainless
15	W10031790	Screw
16	W10113759	Strap, Door
17	3196025	Clip, Door Glass
18	3196794	Bracket, Window(2)
19	3196165	Screw
20	W10031780	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

For Models: RF362LXTQ1, RF362LXTT1, RF362LXTS1, RF362LXTB1  
(Designer White) (Designer Biscuit) (Black Stainless) (Black)

Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)		

## SPLICING WIRES--25FT.

### LENGTH

242828	Wire, Black	12 Ga. 150° c
242821	Wire, Blue	14 Ga. 150°c
242822	Wire, Brown	14 Ga. 150°c
242830	Wire, Brown	14 Ga. 200°c
242823	Wire, Green	14 Ga. 150°c
242824	Wire, Orange	14 Ga. 150°c
242825	Wire, Red	14 Ga. 150°c
242831	Wire, Red	14 Ga. 200°c
242827	Wire, Yellow	14 Ga. 150°c

## REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

Illus. No.	Part No.	DESCRIPTION
<b><u>INSULATION</u></b>		
	261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
	240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

## **PAINT, TOUCH-UP (1/2oz.)**

72017	White
72107	Almond
511873	White Porcelain (2 Oz.)

## **PAINT, PRESSURIZED SPRAY (12 oz.)**

350930	White
350956	Almond
285006	Superior Black
206922	Primer (White)

## **PAINT, BULK (1 qt.)**

799344	White (Uncut)
978883	Almond (Uncut)

Illus. No.	Part No.	DESCRIPTION
<b><u>ACCESSORY PARTS</u></b>		
	241430	Foil, Aluminum Oven (18" x 25')
	3191048	Cleaner, Glass

## **ANTI-TIP KIT**

W10017440	Anti-Tip Kit
-----------	--------------

## **WIRING HARNESS PARTS**

W10115055	Harness, Wire (Cooktop Left)
W10115056	Harness, Wire (Cooktop Right)
W10084660	Harness, Wire (Sensor)
W10117606	Harness, Wire (Main)
8523279	Wire, Ground
8524132	Shield, Wiring
313660	Clip, Ground Wire
3196173	Screw
3196154	Screw, Ground

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST