




# CABINET PARTS

For Model: WED5300SQ, WED5300ST0  
(White) (Biscuit)

29" ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Model: WED5300SQ0, WED5300ST0  
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	12		Plug, Hinge Hole	35	3402341	Door, Rear
	8577188	Installation Instructions		3404413	White	36		Door, Front
	W10042960	Sheet, Cycle Feature		3404415	Biscuit		3402335	White
	8578183	Use & Care Guide	15	3394083	Clip, Front Panel (2)		3402337	Biscuit
	8528187	Wiring Diagram	16	3392100	Foot, Dryer	37		Handle, Door
				279810	Foot – Optional (Extended Length Package Of 2) (Not Included)		8566059	White
							8566071	Biscuit
						38	3406129	Seal & Bearing Assembly
						39	279393	Terminal Block Kit (For Terminal Block)
			17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)	40	3393008	Screw, 10–16 x 1/2
						41	3397659	Block, Terminal
			18		Cabinet (Includes Illus. 4)	51	8066217	Hinge, Top (2)
				8530603	White	53	691366	Idler & Pulley Assembly
				8530606	Biscuit	56	8066065	Belt, Drive
			19	98234	Clip, Ground	57	348780	Base, Motor
			20	690363	Lock, Front Top (2)	58	3400500	Bolt, 5/16–18 x 3/4
			21		Panel, Front	59	8066184	Pulley, 60 Hz.
				3403444	White	62	8066206	Motor Assembly 60 Hz.
				8282481	Biscuit	63	660658	Clamp, Motor
			23	685203	Clip, Felt Pad (3)	64	3404162	Clamp, Motor (W/Shield)
			24	3389441	Catch, Door Assembly	67	3405246	Seal, Door
			27	342055	Screw, 8–18 x 1/2	68	697776	Screw, 10–32 x 5/8 (External Ground)
			28	3405514	Hinge, Door			
			33	3403431	Strike, Door			

**Following May Be Purchased**


**DO-IT-YOURSELF REPAIR MANUALS**

677818 Dryer

2	343641	Screw, 10–16 x 1/2
3	693995	Screw, Hex Washer Head
4	8541400	Bracket, Cabinet
5	3396795	Cover, Block
6		Plug, Strike Hole
	3403630	White
	3403632	Biscuit
7	3396805	Panel, Rear
10	3406109	Door Switch Assembly
11	697773	Screw, 6–20 x 7/8

# TOP AND CONSOLE PARTS

For Model: WED5300SQ0, WED5300ST0  
(White) (Biscuit)



**WIRING HARNESS PARTS**

- 34**: Console panel wiring harness connector
- 9**: Console panel wiring harness connector
- 23**: Console panel wiring harness connector
- 18**: Console panel wiring harness connector

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS


For Model: WED5300SQ0, WED5300ST0  
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console	11	8536939	Clip, Spring	29	8533971	Screw, 8-18 x 5/16
4		Cap, End (L.H.)	13	688983	Screw, 8-18 x 5/8	30	357213	Nut, Push-In (2)
	8271365	White	14	8533951	Screw, Grounding	31	8299867	Harness, Wiring
	8271368	Biscuit	16		Top	32	3977456	Switch, Push-To-Start
6	388326	Screw, Console		8557930	White	33		Timer Knob Assembly
7	693995	Screw, Hex Head	18	94614	Terminal		8566061	White
8		Cap, End (R.H.)	21	8299778	Timer, 60 Hz.		8566064	Biscuit
	8271359	White	23	3394427	Clip, Harness	34	3936144	Connector
	8271362	Biscuit	26		Knob, Push-To-Start	35	8544895	Bracket, Control Panel, Control
9	3395683	Housing, Connector (Motor)		8566065	White	36		White
10		Screen, Lint		8566068	Biscuit		8578844	White
	8557857	White					8579482	Biscuit
	8557858	Biscuit						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

For Model: WED5300SQ0, WED5300ST0  
(White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8-18 x 5/8
3	3388703	Washer-Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8-18 x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	3387134	Thermostat, Internal-Bias
9	3977393	Thermal Cut-Off (Includes Illus. 15)
10	694089	Wheel, Blower (Includes Illus. 22)

Illus. No.	Part No.	DESCRIPTION
11	8577230	Housing, Blower
12	8066155	Clip
13	343641	Screw, 10-16 x 1/2
14	8541818	Box, Heater
15	3977767	Thermostat, 221°F (105°C)
17	8565582	Element, Heater
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
24	8066086	Drum Hole Plug
25	3390647	Screw, 8-18 x 1/2
41	690997	Ring, Tri

Illus. No.	Part No.	DESCRIPTION
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397590	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	3403491	Bulkhead
62	692526	Ring, Bearing
63	97787	Screw, 11-16 x 3/4
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

For Model: WED5300SQ0, WED5300ST0  
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

## ACCESSORY PARTS

279948	Kit, Dryer Repair
3404351	Dry Rack
8522199	Kit, Dryer Vent Testing

## PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit

## PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
350938	Primer, Gray

## PAINT, BULK (1 qt.)

799344	White (Uncut)
--------	---------------