WIDEX UNIQUE

USER INSTRUCTIONS THE WIDEX UNIQUE™ FAMILY

U-FS model Receiver-in-the-ear



Your Widex® hearing aid

To be filled out by the hearing care professional)

Your hearing aid series:

PROGRAM	
Universal	Audibility Extender
🗆 Quiet	Audibility Extender
Transport	Audibility Extender
🗆 Urban	Audibility Extender
Party	Audibility Extender
Music	Audibility Extender
	Audibility Extender
□ M+T	Audibility Extender
SPECIAL PROGRAMS	
🗆 Zen	Audibility Extender

PROGRAM	
Phone	□ Audibility Extender
SMARTTOGGLE PROGRAMS	
□ Zen+	Audibility Extender
Phone+	Audibility Extender

NOTE

Read this booklet and the booklet "Ear-sets for Widex hearing aids" carefully before your start using your hearing aid.

CONTENTS

YOUR WIDEX HEARING AID	7
Welcome to Widex	7
Important safety information	10
THE HEARING AID	13
Indications for use	
Intended use	14
The battery	14
Sound signals	19
How to tell right from left	21
Turning the hearing aid on and off	22
Putting on and removing your hearing aid	24
Sound adjustment	
Programs	
Using a phone with hearing aids	
CLEANING	36
Tools	

36
39
41
45
45

Your Widex Hearing Aid

Welcome to Widex

Congratulations on your new hearing aid.

Use your hearing aid regularly, even if it takes some time getting used to it. Infrequent users don't usually get the full benefit of a hearing aid.

NOTE

Your hearing aid and its accessories may not look exactly as illustrated in this booklet. We also reserve the right to make any changes we consider necessary.

Your hearing aid at a glance

The illustration shows your hearing aid without the ear-set. For further information on the ear-set see the ear-set manual. The ear-set consists of an earwire and an ear-tip, and it is the part of your hearing aid that you wear inside your ear.



1. On/off switch

- 2. Battery drawer with nail grip
- 3. Program button
- 4. LED & Right/left identification

Important safety information

Read these pages carefully before you begin using your hearing aid.



- Take your hearing aids out when you are not using them. This
 will help to ventilate the ear canal and prevent ear infections.
- Contact your doctor or hearing care professional immediately if you suspect you may have an ear infection.
- Do not expose your hearing aids to extreme temperatures or high humidity, and dry them quickly if they get wet, or if you perspire heavily.
- Remove your hearing aids before showering, swimming or using a hair dryer.

- Do not wear your hearing aids when applying perfume, spray, gels, lotion or cream.
- Do not dry your hearing aid in a microwave oven this will ruin it.
- Never use other people's hearing aids and never allow others to use yours, as this could damage your hearing.
- Never use your hearing aids in environments where there may be explosive gases, such as in mines, etc.
- Keep hearing aids, their parts, accessories and batteries away from children.
- Never try to open or repair the hearing aid yourself. Contact your hearing care professional if you need to have your hearing aid repaired.
- Your hearing aid is very powerful and it can play sounds that exceed a level of 132 dB. There may therefore be a risk of damaging your remaining hearing.

Your hearing instruments should be stored and transported within the temperature and humidity ranges of -20°C to +40°C (-4°F to 104°F) and 10%-95% rH.

Storage and transportation up to $60^{\circ}C$ (140°F) with 10%-95% rH can be accepted in shorter periods (duration of max. of 2 weeks).

Your hearing instruments are designed to operate from 0°C (32°F) to 50°C (122°F).

The hearing aid

Indications for use

The hearing aids are indicated for individuals with a range of hearing loss from minimal (10dB HL) to severe-to-profound (100 dB HL)] and all hearing loss configurations.

They are to be programmed by licensed hearing care professionals (audiologists, hearing aid specialists, otolaryngologists) who are trained in hearing (re)habilitation as well as tinnitus management.

Intended use

The hearing aids are intended as air conduction amplification devices to be used in everyday listening environments. The hearing aids may be equipped with the Zen program intended to provide a relaxing sound background (i.e. music/noise source) for adults who desire to listen to such a background in quiet.

The battery

Use a type 312 zinc-air battery for your hearing aid.

Always use a fresh, new battery that is precisely the kind recommended by your hearing care professional.

NOTE

Check that the battery is completely clean and free of any residue before inserting it in the hearing aid. Otherwise your hearing aid may not function as expected.

Dispose of used batteries as indicated on the packaging and take note of the expiry date.




- Never attempt to recharge your hearing aid batteries, as they could explode.
- Never leave a flat battery in the hearing aids while storing them. It could leak and ruin your hearing aid.

Low battery indication

When the battery is flat, a sound signal will play. If the battery drains suddenly there may however be no warning. We recommend carrying a spare battery with you wherever you go.

Changing the battery


To change the battery, do as follows:



Use the nail grip to gently swing the battery door open and remove the old battery.



Take the adhesive tab off the new battery and make sure there is no sticky substance left on it. Let it "breathe" for 60 seconds. Now place the new battery in the drawer as shown.



Close the drawer. If it doesn't close easily, the battery is not placed correctly.

If you are not using the hearing aid for a few days, remove the battery.

NOTE

Avoid dropping your hearing aid - hold the hearing aid above a soft surface while changing the battery.

Sound signals

Your hearing aid plays sounds to inform you that certain features have been activated or that you have changed programs. These sounds may be spoken messages or tones, depending on your needs and preferences.

Program 1	Message/one short beep
Program 2	Message/two short beeps
Program 3	Message or three short beeps
Program 4	Message/one short and one long beep
Program 5	Message/one long beep and two short beeps
Zen+	Message/tone

Ask your hearing care professional to turn these sounds signals off if you don't need them.

Lost partner

(Only available in wireless 440-series)

Your hearing care professional can turn on a feature in your hearing aid that warns you whenever it loses contact with the hearing aid in the opposite ear. You will hear a spoken message in your ear.

How to tell right from left

The hearing aid for your right ear has a red mark. The hearing aid for your left ear has a blue mark.

Turning the hearing aid on and off

To turn the hearing aid on, close the battery lid. The hearing aid will play a sound signal to indicate that it is on, unless your hearing care professional has deactivated this function.



To turn off the hearing aid, push the battery lid downwards.



NOTE


You can also cup the hearing aid in your hand to verify that it is turned on. If it's on, it will whistle.

Don't forget to turn off the hearing aid when it is not in use.

Putting on and removing your hearing aid

Insert the ear-set in the ear while holding the lower part of the tube. Pulling the outer ear upwards and backwards at the same time can be helpful.

Then place the hearing aid behind the ear. The hearing aid should rest comfortably on the ear, close to your head.



Your hearing aid can be fitted using different types of ear-sets. See the separate ear-set manual for more information about your ear-set.


NOTE

If the hearing aid doesn't feel comfortable, or if it doesn't fit properly, causing irritation, redness or the like, contact your hearing care professional.

Removing the hearing aid

Start by removing the hearing aid from behind the ear.

Then take the ear-set carefully out of the ear canal while you hold the lower part of the tube.



Sound adjustment

Your hearing aid adjusts the sound automatically according to your sound environment.

If you have a remote control, you can also adjust the sound manually to achieve more comfort or more audibility, depending on your needs and preferences. For more information on how this works, consult your hearing care professional.

Depending on the hearing aid settings and features, any sound adjustment you make will affect both hearing aids.

Each time you operate the volume control, you will hear a beeptone unless your hearing care professional has deactivated this function. When you reach the maximum or minimum setting, you will hear a steady tone.

To mute your hearing aid do as follows:

 Keep pressing the lower part of the volume key on the remote control until you can hear the steady sound

To turn the sound on again:

- Press the upper part of the volume key or
- Change program

Any adjustment of the volume will be cancelled when you turn off your hearing aid or if you change program.

Programs

PROGRAM	USE
Universal	For everyday use
Quiet	Special program for listening in quiet en- vironments
Transport	For listening in situations with noise from cars, trains, etc.
Urban	For listening in situations with changing sound levels (in supermarkets, noisy workplaces or similar)
Party	For listening in situations with many people talking at the same time

PROGRAM	USE
Music	For listening to music
T	With this program you listen through the hearing aid's telecoil, which allows you to listen directly to the sound without background noise (requires a teleloop system)
M+T	This program is a combination of the hearing aid's microphone and the tele- coil. You listen to the sound source, but can also hear other sounds
SPECIAL PRO- GRAMS	

PROGRAM	USE
Zen	Plays tones or noise for tinnitus relief
Phone	This program is designed for listening to phone conversations
SMARTTOGGLE PROGRAMS	
Zen+	This program is similar to Zen but allows you to listen to different types of tones or noise

PROGRAM	USE
Phone+	This program lets you listen to the phone and avoid the surrounding sounds. One of your hearing aids transmits the phone conversation to the other, so that you can listen with both ears

NOTE

You can only have one SmartToggle program on your hearing aid.

Depending on your hearing loss, your hearing care professional can activate the Audibility Extender feature. Ask your hearing care professional if you could benefit from this.

If your needs and preferences change over time, your hearing care professional can easily change your program selection

Changing programs

To change programs, simply push the program button.



NOTE

The Phone+ program can't be accessed using a remote control.


Zen+

To access this program, press and hold the program button for more than one second. A quicker press then allows you to cycle through the available Zen styles. To exit the program, press and hold down the program button for more than one second.

Phone+

To access this program, press and hold the program button for more than one second. To leave it repeat the same procedure.

Using a phone with hearing aids



Cleaning

Tools

You will receive the following cleaning tools with your hearing aid. Use them as indicated in the Cleaning section.



Cleaning the hearing aid

Cleaning your hearing aid every day will make it more efficient and more comfortable to wear.



Wipe the hearing aid with a soft cloth (for example the cloth you received from your hearing care professional).

If the microphone openings are still blocked, contact your hearing care professional.

Dry your hearing aid quickly if it gets wet, or if you perspire heavily. Some people use a special dehumidifier like Widex Dry-Go to help keep their hearing aids dry and clean. Ask your hearing care professional if this is right for you.

Leave the battery compartment open to ventilate the hearing aid.

For information on how to clean your ear-set, see the ear-set manual.



- Do not use any kind of liquid or disinfectant to clean your hearing aid.
- Clean and inspect your hearing aid every day after use to check that it is not broken. If the hearing aid breaks while you are wearing it, leaving small fragments in your ear canal, contact your doctor. Never try to take out the fragments yourself.

Accessories

Accessories

You can use a variety of accessories with your hearing aid. To see whether you could benefit from using these accessories, ask your hearing care professional.

Name	Use
RC-DEX	remote control
TV-DEX	for listening to TV and audio
PHONE-DEX*	for easy landline use
FM+DEX	for streaming audio and FM signals

Name	Use
T-DEX	for connecting hearing aids to mobile phones via a telecoil
UNI-DEX	for connecting hearing aids to mobile phones
CALL-DEX	for easy wireless connection to mobile phones
COM-DEX	for wireless connection to mobile phones and other devices via bluetooth

Accessories

*Available in some countries only.

Troubleshooting

These pages contain advice on what to do if your hearing aid stops working or if it doesn't work as expected. If the problem persists, contact your hearing care professional.

Problem	Possible cause	Solution
The hearing aid is completely silent	It is not turned on	Make sure the bat- tery drawer is completely closed
	The battery does not work	Insert a new bat- tery

Problem	Possible cause	Solution
The hearing aid volume is not pow-	Your ear is blocked by earwax	Contact your doc- tor
erful enough	Your hearing may have changed	Contact your hear- ing care professio- nal/doctor
The hearing aid whistles continu- ously	Your ear is blocked by earwax	Contact your doc- tor
Your two hearing aids are not work- ing in synchrony	The connection be- tween the hearing aids is lost	Turn them off and on again

Problem	Possible cause	Solution
The hearing aids do not respond with a corresponding change in volume or program to the control device	a. The device is used beyond the trans- mission range b. Strong electro- magnetic interfer- ence in the vicinity c. The device and the hearing aids are not matched	a. Move the device closer to the hear- ing aids. b. Move away from known source of EM interference c. Check with your hearing care pro- fessional to make sure the device is matched with hearing aids

Problem	Possible cause	Solution
You hear "interrup- ted" speech (on and off) from the hearing aids or no speech (muted) from the transmit- ting hearing aid.	 a. The battery in one of the hearing aids has expired b. Strong electromagnetic interference in the vicinity 	a. Replace battery in one or both hearing aids b. Move away from known sources of interference

NOTE

This information covers only the hearing aid. See the "Ear-sets for Widex hearing aids" user manual for information specific to your ear-set. If the problems persist, contact your hearing care professional for assistance.

Regulatory information

FCC and IC statements and EC directives

FCC ID: TTY-UFS

IC: 5676B-UFS

Federal Communications Commission Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

NOTE:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Changes or modifications to the equipment not expressly approved by Widex could void the user's authority to operate the equipment.

Industry Canada Statement / Déclaration d'industrie Canada

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device. Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada.

Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Directive 1999/5/EC

Hereby, Widex A/S declares that this U-FS is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

A copy of the Declaration of Conformity according to 1999/5/EC can be found at:

http://widex.com/doc



Information regarding disposal



Electrical and electronic equipment (EEE)

contains materials, components and substances that can be hazardous and present a risk to human health and the environment when waste electrical and electronic equipment (WEEE) is not handled correctly.

Do not dispose of hearing aids, hearing aid accessories and batteries with ordinary household waste. Hearing aids, batteries and hearing aid accessories should be disposed of at sites intended for waste electrical and electronic equipment, or given to your hearing care professional for safe disposal. Proper disposal helps to protect human health and the environment.

Symbols

Symbols

Symbols commonly used by Widex A/S in medical device labelling (labels/IFU/etc.)

Symbol	Title/Description
	Manufacturer The product is produced by the manufacturer whose name and address are stated next to the symbol. If appropriate, the date of manufacture may also be
	stated.

Symbol	Title/Description
	Catalogue number
REF	The product's catalogue (item) number.
Consult instructions for use	
L	The user instructions contain important cautionary information (warnings/precautions) and must be read before using the product.
	Warning
∕!∖	Text marked with a warning symbol must be read before using the product.

Symbol	Title/Description
X	WEEE mark
<u>/</u>	"Not for general waste"
	When a product is to be discarded, it must be sent to a designated collection point for recycling and re- covering to prevent to prevent the risk of harm to the environment or human health as a result of the presence of hazardous substances.
()	CE mark
עכ	The product is in conformity with the requirements set out in European CE marking directives.

Symbol	Title/Description
	RCM mark
Ø	The product complies with electrical safety, EMC and radio spectrum regulatory requirements for products supplied to the Australian or New Zealand market.
(((a))) Interference	
	Electromagnetic interference may occur in the vicini- ty of the product.

