



# 日業香港有限公司

## SOLAR LOYAL LIMITED

### SL-9105 2.4G Android TV Box Controller Manual

Thank you very much for purchasing 2.4G game controller. This game controller is one of peripheral equipments for your personal computer ,PS3 console, It has complete function keys to make your game controller more powerful. Before using this controller, please read this manual and retain it for future reference.


#### Content


1. 2.4G controller
2. Nano Receiver\*1
3. Manual
4. USB charging cable

#### FEATURE

1. 2.4G wireless technology
2. Operation range up to 10M
3. Built in LI-polymer battery
4. Soft handgrip
5. 2 joystick and 2 Trigger
6. Compatible with Windows XP

#### Button function:





### 1. Direction button

8-way point of view control button

### 2. Fire Buttons

There are six keys including 1, 2,3,4,5,6, they are used to control other actions of your role. L-trigger and R-trigger are used analog signal. It can be set in special function according to different games.

### 3. Function Buttons

Pressing button 10 can start the game or the game will pause in some special games. Button 9 is "BACK" button.

### 4. Left and right 3D stick

They are set in the different game according to the customer favorite.

### 5. MODE button

Button "PS" is mode button or Converse mode

### 7. Turbo setting .

7.1 Hold the key which you want to set it into turbo function, then press turbo key one time. Then it is set in Turbo station.

7.2 Hold the key which you have set turbo function, then press turbo key it can clear turbo setting.

## Operation

1. Plug the receiver into one of USB port of your device , Turn on your device.
2. Press PS button within 5 seconds, 4 port Led will rapid flash ,
3. When one of one Port Led light ,paired successfully
4. Mode change and indicate :
  - 4.1 Default mode is Xinput , 1<sup>ST</sup> port LED&2<sup>ST</sup> port LED will light ,
  - 4.2 Hold the "PS" button for 6 seconds, it turn to D-input mode successfully, 1<sup>ST</sup> port LED&3<sup>ST</sup> port LED will light
  - 4.3 You can press the "Home" button once to change to digital mode when it is in Dinput mode ,4<sup>st</sup> LED will be off. In this mode D-pad function are same as Left joystick,
  - 4.4 It can recognized automatically when operation on PS3 console, no need to change mode.

5. When you use on PS3 console ,you can use on it directly

**Notice:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for

help.