


TransPad Pen Instruction

Model: TP-001

Battery: LR44


Using your TransPad Pen

1. A specially designed TransPad Pen is included for use with the TransPad. The cap end of the TransPad Pen contains a stylus tip that you can use on your PDA. You don't have to switch between the TransPen and the PDA stylus to work with TransPad.
2. Open the TransPad Pen and install the button cell battery in the battery holder with the plus (+) end upward.



Replacing the Ink Cartridge

1. Use the special clip that is stored in the storage pocket of the TransPad portfolio.
2. Fit the tip of the TransPad Pen into the notch of this tool and then extract the ink cartridge as show in this diagram.



FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received; including interference that may cause undesired operation.

Federal Communications Commission (FCC) Statement

This Equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.