




Hunter
Bluetooth Headset

User Manual

Product Indication



- 1. Neck stabilizer
- 2. Receiver line
- 3. USB charging port
- 4. MIC
- 5. Indicator light
- 6. Multifunction button
- 7. Ear tip
- 8. Volume down/Previous track
- 9. Volume up/Next track

1

Product Specification

Bluetooth Standard	Bluetooth V4.1
Operation Range	10m
Talk Time	4.5-6.5 hours
Playing Time	4-6 hours
Standby Time	200 hours
Charging Time	1.5 hours
Charging Voltage	DC/5V

Charging

Please fully charge the headset before using for the first time.

1. Connect the USB charging cable to the USB charge port of the headphone.
2. The indicator light will turn red when charging.
3. The indicator light will turn blue when charging is completed.

2

ON/OFF

Power on:

With the earphone off, press the multifunction button for about 2 seconds, the headphone will vibrate, the red light and blue light start flashing alternately. You will also hear a notification tone.

Power off:

In the state of power-on, long press the multifunction button until the indicator turns off, the headphone will vibrate at the same time. You will also hear a notification tone.

Pairing Mode

1. Press the multifunction button for about 2 seconds until the red light and blue light start flashing alternately.
2. Turn on the Bluetooth function on your phone.
3. Search for the Bluetooth devices and select "Mpow Hunter".
4. Enter the code "0000" if needed.
5. If pairing is successful, you will hear a notification tone, the blue indicator light will flash every 5 seconds.

3

※

- I. Please make sure the headphone is off before pairing.
- II. Automatic Connect: Turn on the headphone, the headphone will connect to the last connected phone automatically if the Bluetooth function of the phone is on. Please make sure the Bluetooth function of your phone is on before turning on the headphone.

Call Mode

Answering a call

Short press the multifunction button.

Ending a call

Short press the multifunction button.

Rejecting a call

Press the multifunction button for about 2 seconds.

Redialing the last called number

Double press the multifunction button.

Call mute function

Double press the multifunction button to mute on/mute off during the phone call.

Call transfer

Long press the multifunction button to transfer the voice receiver from the cellphone or the Bluetooth headphone during the phone call.

4

Music Mode

Playing Music

Short press "MFB" button to play/pause music.

Previous /Next Track

Previous Track: Long press the button "-" for 1 second.

Next Track: Long press the button "+" for 1 second.

Volume Control

Volume Up: Short press the "+" button.

Volume Down: Short press the "-" button.

Correct disposal of this product



(Waste Electrical & Electronic Equipment)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household user should contact either the retailer where they purchased this product or their local government office for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

5

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.