



HX-P340

©2015 HMDX. All Rights Reserved.

IB-HXP340

HMDX

HEY. HAVE WE SEEN YOU HERE BEFORE?

Register your speaker at www.hmdxaudio.com. *Information like where you bought it and how you're using it is like gold for the people who make these speakers. Do them a solid, will ya?*

Por manual de instrucciones e información de garantía en español visitenos en www.hmdxaudio.com.

The HMDX Dynamite has friends -like, lots of them. Check them all out at www.hmdxaudio.com.

Setup is pretty easy, but we put a manual together just in case you need it. It's full of information and sarcasm—just like that English teacher you had that crazy semester.

PACKAGE CONTENTS



Quick start guide & legal card



Speaker



Charging Cord

JUST CHARGE IT

Charging the speaker is so easy you've probably figured it out by now, but just in case, you've got two options: your computer or a wall outlet.


1. The cord that came with the speaker — the one with the USB on one end and the Micro USB on the other — will work with your computer.
2. If you want to use the wall outlet, you'll need to pick up a power cord with a Micro USB the next time you're at the store or use any USB AC adaptor, including the one for your cell.

Now go get ready for an epic night while your speaker does too. It needs about 3 hours of me time for 5 hours of party time.



CONTROL YOUR DESTINY...OR AT LEAST YOUR SPEAKER

1. The power cord goes here
2. That's the power switch
3. Volume Up / Next Track
4. Push it to play, push it again to pause
5. Volume down / previous track



BLUETOOTH® CONNECTION: IT'S A SETUP

Like any amazing couple, this one starts with a connection—one between your device and the speaker's *Bluetooth*.

Here's how it works:

1. We know you're probably going to think, "derp" with this one, but we have to say it: Make sure the smartphone, tablet or computer you want to hook up to the speaker has *Bluetooth*. (There. We got that out of the way.)
2. Switch on the speaker and look for the little blinking light.
3. Do whatever your device needs you to do on its end. (We don't know what you're using. We're not spies.)
4. Look for **HMDX Dynamite** in your device's *Bluetooth* list or click **YES**—whatever pops up on your device—and **BAM!** you're connected.

5. Now hit **PLAY** on your speaker and crank it up—or down if you're lame.

You're probably only going to have to do this once, unless your device goes through a major I-just-dropped-it-in-the-pool kind of reboot. The device and *Bluetooth* will find each other every time just as long as the speaker is set to *Bluetooth* and your device's *Bluetooth* is, you know—on.


If you're connecting to a computer, you may have some extra steps on that end. You'll have to get that information from the computer company.

Depending on your device you may be prompted to enter a pairing code.

If prompted, enter "0000" as the code.

Press and hold **PLAY/PAUSE** for 5 seconds to activate pairing mode.

ALLOW US TO SHED SOME LIGHT

	What It Looks Like	What it Means
CHARGE	Solid RED	Charging
	Light Off	Ready to Party (Light will only show when unit is plugged in)
	Quick Flash BLUE	Looking for Bluetooth
	Slow Flash BLUE	Connected

HELLO? SPEAKERPHONE? YES!

When friends call asking to join the party—and you know they will—answer the phone without disconnecting from your HMDX Dynamite. Yes, that's right. Your speaker is a speakerphone too. How amazing is that?

Here's how it works:

1. Make sure your phone and the speaker are connected through *Bluetooth* and not on a "break."
2. Answering and ending a call works the same way: simply click the PLAY/PAUSE button on your Dynamite.
3. If you'd rather not talk, hold down the PLAY/PAUSE button on your Dynamite for three seconds to ignore the call.

THE COOLEST PART: The Dynamite knows when a call is coming in and pauses the music before ringing. When you hang up, the music starts where it left off—and so does the party. If it's you making the call, just start dialing from your phone, and the Dynamite automatically does its hands-free thing. Isn't it refreshing to know your speaker totally gets you?

CHECK OUT THE CHART BELOW FOR A GUIDE ON CALL HANDLING

Situation	Short Press Play/Pause Button	Long Press Play/Pause Button
1 st Incoming call	Pick-Up call	Reject call
On call	End call	Move call from speaker to device
2 nd Incoming call	Call 1 on Hold, Pick-Up call 2	Reject call 2
Both calls Active	Hang up call 1, Switch to call 2	Switch between 1 st call and 2 nd call

COMING CLEAN

A soft, dry towel is all you need to clean off your speaker. Using water, harsh cleaners or anything else only starts messing with the mechanics inside. So, yeah, don't do it.

STUFF THE GOVERNMENT MAKES US SAY

FCC Disclaimer:

Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications not expressly approved by HMDX could void the user's authority to operate this equipment.

ONE YEAR LIMITED WARRANTY

For detailed Warranty Instructions and Information visit:

[http:// www.hmdxaudio.com/customer-support/warranty-1yr](http://www.hmdxaudio.com/customer-support/warranty-1yr)

To obtain warranty service on your HMDX product, contact a Consumer Relations Representative by telephone at 1-800-573-3000 (USA) 1-888-225-7378 (CAN) or you can email cservice@hmdxaudio.com (USA) or cservice@homedicsgroup.ca (CAN) for assistance. Please be sure to have the model number of the product available. Representatives are available 8:30 am – 7:00pm EST (USA) 8:30am-5:00pm EST (CAN) Monday-Friday.

STUFF OUR LAWYERS MAKE US SAY

IMPORTANT SAFEGUARDS:

When using an electrical product, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

- Close supervision is necessary when this product is used by, on or near children, invalids or disabled persons.
- **WARNING: Do not place speakers too close to ears. May cause damage to ear drums, especially in young children.**
- Use this product only for its intended use as described in this manual. Do not use attachments not recommended by HMDX.
- HMDX is not liable for any damage caused to Smartphones, iPod/MP3 player or any other device.
- Do not place or store this product where it can fall or be dropped into a tub or sink.
- Do not place or drop into water or any other liquid.
- Not for use by children. THIS IS NOT A TOY.
- Never operate this product if it has a damaged cord, plug, cable or housing.
- Turn off product when not in use.
- Keep away from heated surfaces.
- Only set on dry surfaces. Do not place on surface wet from water or cleaning solvents.

Warning: This product contains chemicals known to the State of California to cause cancer, birth defects and other reproductive harm.

SAVE THESE INSTRUCTIONS

CAUTION: Please read all instructions carefully before operating.

- Never leave the product unattended, especially if children are present.
- Never cover the product when it is in operation.
- This unit should not be used by children without adult supervision.
- Always keep the product away from high temperature and fire

A MESSAGE FROM THE ENVIRONMENT

WARNING:

This product has an internal, non-replaceable lithium battery. Please dispose in accordance with your local state, province and country guidelines.

This product contains small parts that may present a choking hazard for young children.

CAUTION: All servicing of this product must be performed by authorized HMDX Service Personnel only

Note: The most up-to-date version of the HMDX Rave user guide can always be found at www.hmdxaudio.com

Por manual de instrucciones e Información de garantía en español visítenos en www.hmdxaudio.com

Contact Information:

- Manufacturer: Wonders Technology Co., Ltd.
DOSS Industrial Zone, Qiping Kengdu Industrial Area Guihua
Village, Guanlan
Town Baoan District, Shenzhen, China
Telephone No: 86-755-2752-0683
Fax No: 86-755-2752-0228
E-mail: LIANGBO8899@126.COM